
PyLink Documentation

Release 0.11.1

Square Embedded Software Team

Sep 24, 2021

1	Installation	3
2	Tutorial	5
3	Command-Line Tool	7
4	PyLink	11
5	Protocols	57
6	Unlocking	61
7	Bindings	63
8	Extras	93
9	Troubleshooting	107
10	Serial Wire Debug	109
11	About	117
	Python Module Index	119

PyLink is a Python package that enables you to control your J-Link from Python. This library was developed at [Square](#) to enable us to leverage our J-Link as a part of our test infrastructure, which was written in Python.

Getting started is as simple as:

```
>>> import pylink
>>> jlink = pylink.JLink()
>>> jlink.open(serial_no=123456789)
>>> jlink.product_name
J-Trace Cortex-M
```

Installation

Warning: This package requires the [J-Link Software and Development Pack](#) provided by SEGGER. If you do not currently have the development pack installed, you must install it first before using this Python package.

Note: This library is known to support Python versions 2.4 - 2.7. Support for versions higher than 2.7 is not guaranteed.

1.1 Basic Installation

Installing PyLink with **pip**:

```
$ pip install pylink-square
```

Or use **easy_install**:

```
$ easy_install pylink-square
```

1.2 Building From Source

Clone the project into a local repository, then navigate to that directory and run:

```
$ python setup.py install
```

This will give you the tip of **master** (the development branch). While we strive for this to be stable at all times, some bugs may be introduced, so it is best to check out a release branch first before installing.

```
$ git checkout release-major.minor
$ python setup.py install
```

1.3 External Dependencies

In order to use this library, the [J-Link Software and Development Pack](#) provided by SEGGER is required. Once you have a copy of the development pack, you can start using PyLink. PyLink will automatically find the library if you installed it using one of the installers available from SEGGER's site, but for best results, you should also do one of the following depending on your operating system:

1.3.1 On Mac

```
# Option A: Copy the library file to your libraries directory.
cp libjlinkarm.dylib /usr/local/lib/

# Option B: Add SEGGER's J-Link directory to your dynamic libraries path.
$ export DYLD_LIBRARY_PATH=/Applications/SEGGER/JLink:$DYLD_LIBRARY_PATH
```

1.3.2 On Windows

Windows searches for DLLs in the following order:

1. The current directory of execution.
2. The Windows system directory.
3. The Windows directory.

You can copy the `JLinkARM.dll` to any of the directories listed above. Alternatively, add the SEGGER J-Link directory to your `%PATH%`.

1.3.3 On Linux

```
# Option A: Copy the library to your libraries directory.
$ cp libjlinkarm.so /usr/local/lib/

# Option B: Add SEGGER's J-Link library path to your libraries path.
$ export LD_LIBRARY_PATH=/path/to/SEGGER/JLink:$LD_LIBRARY_PATH
```

Tutorial

In this tutorial, assume that the serial number of the J-Link emulator being connected to is 123456789, and that the target device is an Mkxxxxxxxxxxx7.

2.1 Connecting to an Emulator

```
>>> import pylink
>>> jlink = pylink.JLink()
>>> jlink.open(123456789)
>>> jlink.product_name
J-Trace Cortex-M
>>> jlink.oem
>>> jlink.opened()
True
>>> jlink.connected()
True
>>> jlink.target_connected()
False
```

2.2 Updating the Emulator

```
>>> jlink.update_firmware()
1
```

2.3 Connecting to a Target CPU

```
>>> jlink.connect('MKxxxxxxxxxxx7')
>>> jlink.core_id()
50331903
>>> jlink.device_family()
3
>>> jlink.target_connected()
True
```

2.4 Flashing from a File

```
>>> jlink.flash_file('/path/to/file', address)
1337
>>> jlink.memory_read8(0, 1337)
[ 0, 0, .... ]
```

2.5 Flashing from a List of Bytes

```
>>> data = [1, 2, 3, 4]
>>> jlink.flash(data, 0)
4
>>> jlink.memory_read8(0, 4)
[1, 2, 3, 4]
```

2.6 Unlocking a Device

Note: Currently unlock is only supported for Kinetis on SWD.

```
>>> pylink.unlock(jlink, 'Kinetis')
True
```

Command-Line Tool

PyLink ships with a command-line interface that provides common functionality. After you've installed the package, the command should be readily available for use.

Python interface for SEGGER J-Link.

```
usage: pylink [-h] [--version] [-v]
             {emulator,info,firmware,flash,unlock,erase,license} ...
```

Options:

--version	show program's version number and exit
-v, --verbose	increase output verbosity

Sub-commands:

emulator query for information about emulators or support

Query for information about emulators or support.

```
usage: pylink emulator [-h] (-l [{usb,ip}] | -s SUPPORTED | -t)
```

Options:

-l, --list	list all the connected emulators
	Possible choices: usb, ip
-s, --supported	query whether a device is supported
-t, --test	perform a self-test

info get information about the J-Link

Get information about the J-Link.

```
usage: pylink info [-h] [-p] [-j] [-s SERIAL_NO | -i IP_ADDR]
```

Options:

-p, --product	print the production information
-j, --jtag	print the JTAG pin status
-s, --serial	specify the J-Link serial number
-i, --ip_addr	J-Link IP address

firmware modify the J-Link firmware

Modify the J-Link firmware.

```
usage: pylink firmware [-h] (-d | -u) [-s SERIAL_NO | -i IP_ADDR]
```

Options:

-d, --downgrade	downgrade the J-Link firmware
-u, --upgrade	upgrade the J-Link firmware
-s, --serial	specify the J-Link serial number
-i, --ip_addr	J-Link IP address

flash flash a device connected to the J-Link

Flashes firmware from a file to a device connected to a J-Link.

```
usage: pylink flash [-h] [-a ADDR] -t {jtag,swd} -d DEVICE
                    [-s SERIAL_NO | -i IP_ADDR]
                    file
```

Positional arguments:

file	file to flash onto device
-------------	---------------------------

Options:

-a, --addr	start address to flash from
-t, --tif	target interface (JTAG SWD) Possible choices: jtag, swd
-d, --device	specify the target device name
-s, --serial	specify the J-Link serial number
-i, --ip_addr	J-Link IP address

unlock unlock a connected device

Unlocks a device connected to a J-Link. Note that this will erase the device.

```
usage: pylink unlock [-h] -t {jtag,swd} -d DEVICE [-s SERIAL_NO | -i IP_ADDR]
                    {kinetis}
```

Positional arguments:

name	name of MCU to unlock Possible choices: kinetis
-------------	--

Options:

-t, --tif	target interface (JTAG SWD) Possible choices: jtag, swd
-d, --device	specify the target device name
-s, --serial	specify the J-Link serial number
-i, --ip_addr	J-Link IP address

erase erases the device connected to the J-Link

Erases the target device.

```
usage: pylink erase [-h] -t {jtag,swd} -d DEVICE [-s SERIAL_NO | -i IP_ADDR]
```

Options:

-t, --tif	target interface (JTAG SWD) Possible choices: jtag, swd
-d, --device	specify the target device name
-s, --serial	specify the J-Link serial number
-i, --ip_addr	J-Link IP address

license manage the licenses of your J-Link

Manage the licenses of the J-Link.

```
usage: pylink license [-h] (-l | -a ADD | -e) [-s SERIAL_NO | -i IP_ADDR]
```

Options:

-l, --list	list the licenses of the J-Link
-a, --add	add a custom license to the J-Link
-e, --erase	erase the custom licenses on the J-Link
-s, --serial	specify the J-Link serial number
-i, --ip_addr	J-Link IP address

Copyright 2017 Square, Inc.

The PyLink package provides a Pythonic interface for interacting with the J-Link C SDK. This interface is provided through the `JLink` class, which provides several of the functions provided by the native SDK. Some methods require a specific interface, a target being connected, or an emulator being connected, and will raise errors as appropriate if these conditions are not met.

In lieu of return codes, this library uses the object-oriented paradigm of raising an exception. All exceptions are inherited from the `JLinkException` base class.

4.1 Exceptions

This submodule defines the different exceptions that can be generated by the `JLink` methods.

exception `pylink.errors.JLinkDataException` (*code*)

Bases: `pylink.enums.JLinkDataErrors`, `pylink.errors.JLinkException`

J-Link data event exception.

exception `pylink.errors.JLinkEraseException` (*code*)

Bases: `pylink.enums.JLinkEraseErrors`, `pylink.errors.JLinkException`

J-Link erase exception.

exception `pylink.errors.JLinkException` (*code*)

Bases: `pylink.enums.JLinkGlobalErrors`, `exceptions.Exception`

Generic J-Link exception.

exception `pylink.errors.JLinkFlashException` (*code*)

Bases: `pylink.enums.JLinkFlashErrors`, `pylink.errors.JLinkException`

J-Link flash exception.

exception `pylink.errors.JLinkRTTException` (*code*)

Bases: `pylink.enums.JLinkRTTErrors`, `pylink.errors.JLinkException`

J-Link RTT exception.

exception `pylink.errors.JLinkReadException` (*code*)

Bases: `pylink.enums.JLinkReadErrors`, `pylink.errors.JLinkException`

J-Link read exception.

exception `pylink.errors.JLinkWriteException` (*code*)

Bases: `pylink.enums.JLinkWriteErrors`, `pylink.errors.JLinkException`

J-Link write exception.

4.2 Library

This submodule defines a `Library`. This is not needed unless explicitly specifying a different version of the J-Link dynamic library.

class `pylink.library.Library` (*dllpath=None*)

Bases: `object`

Wrapper to provide easy access to loading the J-Link SDK DLL.

This class provides a convenience for finding and loading the J-Link DLL across multiple platforms, and accounting for the inconsistencies between Windows and nix-based platforms.

`__standard_calls__`

list of names of the methods for the API calls that must be converted to standard calling convention on the Windows platform.

`JLINK_SDK_NAME`

name of the J-Link DLL on nix-based platforms.

`WINDOWS_JLINK_SDK_NAME`

name of the J-Link DLL on Windows platforms.

`JLINK_SDK_NAME = 'libjlinkarm'`

`WINDOWS_32_JLINK_SDK_NAME = 'JLinkARM'`

`WINDOWS_64_JLINK_SDK_NAME = 'JLink_x64'`

`dll()`

Returns the DLL for the underlying shared library.

Parameters `self` (`Library`) – the `Library` instance

Returns A `ctypes` DLL instance if one was loaded, otherwise `None`.

classmethod `find_library_darwin()`

Loads the SEGGER DLL from the installed applications.

This method accounts for the all the different ways in which the DLL may be installed depending on the version of the DLL. Always uses the first directory found.

SEGGER's DLL is installed in one of three ways dependent on which which version of the SEGGER tools are installed:

Versions	Directory
< 5.0.0	/Applications/SEGGER/JLink\ NUMBER
< 6.0.0	/Applications/SEGGER/JLink/libjlinkarm.major.minor.dylib
>= 6.0.0	/Applications/SEGGER/JLink/libjlinkarm

Parameters `cls` (`Library`) – the `Library` class

Returns The path to the J-Link library files in the order they are found.

classmethod `find_library_linux()`

Loads the SEGGER DLL from the root directory.

On Linux, the SEGGER tools are installed under the `/opt/SEGGER` directory with versioned directories having the suffix `_VERSION`.

Parameters `cls` (`Library`) – the `Library` class

Returns The paths to the J-Link library files in the order that they are found.

classmethod `find_library_windows()`

Loads the SEGGER DLL from the windows installation directory.

On Windows, these are found either under:

- `C:\Program Files\SEGGER\JLink`
- `C:\Program Files (x86)\SEGGER\JLink.`

Parameters `cls` (`Library`) – the `Library` class

Returns The paths to the J-Link library files in the order that they are found.

classmethod `get_appropriate_windows_sdk_name()`

Returns the appropriate JLink SDK library name on Windows depending on 32bit or 64bit Python variant.

SEGGER delivers two variants of their dynamic library on Windows:

- `JLinkARM.dll` for 32-bit platform
- `JLink_x64.dll` for 64-bit platform

Parameters `cls` (`Library`) – the `Library` class

Returns The name of the library depending on the platform this module is run on.

load (`path=None`)

Loads the specified DLL, if any, otherwise re-loads the current DLL.

If `path` is specified, loads the DLL at the given `path`, otherwise re-loads the DLL currently specified by this library.

Note: This creates a temporary DLL file to use for the instance. This is necessary to work around a limitation of the J-Link DLL in which multiple J-Links cannot be accessed from the same process.

Parameters

- `self` (`Library`) – the `Library` instance
- `path` (`path`) – path to the DLL to load

Returns `True` if library was loaded successfully.

Raises `OSError` – if there is no J-LINK SDK DLL present at the path.

See also:

[J-Link Multi-session.](#)

load_default ()

Loads the default J-Link SDK DLL.

The default J-Link SDK is determined by first checking if `ctypes` can find the DLL, then by searching the platform-specific paths.

Parameters `self` (`Library`) – the `Library` instance

Returns `True` if the DLL was loaded, otherwise `False`.

unload()

Unloads the library's DLL if it has been loaded.

This additionally cleans up the temporary DLL file that was created when the library was loaded.

Parameters **self** (`Library`) – the `Library` instance**Returns** `True` if the DLL was unloaded, otherwise `False`.

4.3 JLock

This submodule defines a `JLock`. This acts as a lockfile-like interface for interacting with a particular emulator in order to prevent multiple threads or processes from creating instances of `JLink` to interact with the same emulator.

class `pylink.jlock.JLock` (*serial_no*)Bases: `object`

Lockfile for accessing a particular J-Link.

The J-Link SDK does not prevent accessing the same J-Link multiple times from the same process or multiple processes. As a result, a user can have the same J-Link being accessed by multiple processes. This class provides an interface to a lock-file like structure for the physical J-Links to ensure that any instance of a `JLink` with an open emulator connection will be the only one accessing that emulator.

This class uses a PID-style lockfile to allow acquiring of the lockfile in the instances where the lockfile exists, but the process which created it is no longer running.

To share the same emulator connection between multiple threads, processes, or functions, a single instance of a `JLink` should be created and passed between the threads and processes.

name

the name of the lockfile.

path

full path to the lockfile.

fd

file description of the lockfile.

acquired

boolean indicating if the lockfile lock has been acquired.

IPADDR_NAME_FMT = `'pylink-ip-{}.lck'`**SERIAL_NAME_FMT** = `'pylink-usb-{}.lck'`**acquire()**

Attempts to acquire a lock for the J-Link lockfile.

If the lockfile exists but does not correspond to an active process, the lockfile is first removed, before an attempt is made to acquire it.

Parameters **self** (`JLock`) – the `JLock` instance**Returns** `True` if the lock was acquired, otherwise `False`.**Raises** `OSError` – on file errors.**release()**

Cleans up the lockfile if it was acquired.

Parameters **self** (`JLock`) – the `JLock` instance

Returns `False` if the lock was not released or the lock is not acquired, otherwise `True`.

4.4 JLink

This submodule provides the definition for the `JLink` class, which is the interface to the J-Link.

class `pylink.jlink.JLink` (*lib=None, log=None, detailed_log=None, error=None, warn=None, unsecure_hook=None, serial_no=None, ip_addr=None, open_tunnel=False*)

Bases: `object`

Python interface for the SEGGER J-Link.

This is a wrapper around the J-Link C SDK to provide a Python interface to it. The shared library is loaded and used to call the SDK methods.

ADAPTIVE_JTAG_SPEED = 65535

AUTO_JTAG_SPEED = 0

INVALID_JTAG_SPEED = 65534

MAX_BUF_SIZE = 336

MAX_JTAG_SPEED = 50000

MAX_NUM_CPU_REGISTERS = 256

MAX_NUM_MOES = 8

MIN_JTAG_SPEED = 5

add_license (**args, **kwargs*)

Adds the given `contents` as a new custom license to the J-Link.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **contents** – the string contents of the new custom license

Returns `True` if license was added, `False` if license already existed.

Raises `JLinkException` – if the write fails.

Note: J-Link V9 and J-Link ULTRA/PRO V4 have 336 Bytes of memory for licenses, while older versions of 80 bytes.

breakpoint_clear (**args, **kwargs*)

Removes a single breakpoint.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **handle** (`int`) – the handle of the breakpoint to be removed

Returns `True` if the breakpoint was cleared, otherwise `False` if the breakpoint was not valid.

breakpoint_clear_all (**args, **kwargs*)

Removes all breakpoints that have been set.

Parameters **self** (`JLink`) – the `JLink` instance

Returns True if they were cleared, otherwise False.

breakpoint_find (*args, **kwargs)

Returns the handle of a breakpoint at the given address, if any.

Parameters

- **self** (JLink) – the JLink instance
- **addr** (int) – the address to search for the breakpoint

Returns A non-zero integer if a breakpoint was found at the given address, otherwise zero.

breakpoint_info (*args, **kwargs)

Returns the information about a set breakpoint.

Note: Either `handle` or `index` can be specified. If the `index` is not provided, the `handle` must be set, and vice-versa. If both `index` and `handle` are provided, the `index` overrides the provided `handle`.

Parameters

- **self** (JLink) – the JLink instance
- **handle** (int) – option handle of a valid breakpoint
- **index** (int) – optional index of the breakpoint.

Returns An instance of `JLinkBreakpointInfo` specifying information about the breakpoint.

Raises

- `JLinkException` – on error.
- `ValueError` – if both the `handle` and `index` are invalid.

breakpoint_set (*args, **kwargs)

Sets a breakpoint at the specified address.

If `thumb` is `True`, the breakpoint is set in THUMB-mode, while if `arm` is `True`, the breakpoint is set in ARM-mode, otherwise a normal breakpoint is set.

Parameters

- **self** (JLink) – the JLink instance
- **addr** (int) – the address where the breakpoint will be set
- **thumb** (bool) – boolean indicating to set the breakpoint in THUMB mode
- **arm** (bool) – boolean indicating to set the breakpoint in ARM mode

Returns An integer specifying the breakpoint handle. This handle should be retained for future breakpoint operations.

Raises

- `TypeError` – if the given address is not an integer.
- `JLinkException` – if the breakpoint could not be set.

capabilities

Returns a bitwise combination of the emulator's capabilities.

Parameters **self** (JLink) – the JLink instance

Returns Bitfield of emulator capabilities.

clear_error()

Clears the DLL internal error state.

Parameters **self** (*JLink*) – the *JLink* instance

Returns The error state before the clear.

close()

Closes the open J-Link.

Parameters **self** (*JLink*) – the *JLink* instance

Returns None

Raises *JLinkException* – if there is no connected *JLink*.

code_memory_read(*args, **kwargs)

Reads bytes from code memory.

Note: This is similar to calling `memory_read` or `memory_read8`, except that this uses a cache and reads ahead. This should be used in instances where you want to read a small amount of bytes at a time, and expect to always read ahead.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **addr** (*int*) – starting address from which to read
- **num_bytes** (*int*) – number of bytes to read

Returns A list of bytes read from the target.

Raises *JLinkException* – if memory could not be read.

comm_supported(*args, **kwargs)

Returns true if the connected emulator supports `comm_*` functions.

Parameters **self** (*JLink*) – the *JLink* instance

Returns True if the emulator supports `comm_*` functions, otherwise False.

compatible_firmware_version

Returns the DLL's compatible J-Link firmware version.

Parameters **self** (*JLink*) – the *JLink* instance

Returns The firmware version of the J-Link that the DLL is compatible with.

Raises *JLinkException* – on error.

compile_date

Returns a string specifying the date and time at which the DLL was translated.

Parameters **self** (*JLink*) – the *JLink* instance

Returns Datetime string.

connect(*args, **kwargs)

Connects the J-Link to its target.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **chip_name** (`str`) – target chip name
- **speed** (`int`) – connection speed, one of {5-12000, 'auto', 'adaptive'}
- **verbose** (`bool`) – boolean indicating if connection should be verbose in logging

Returns `None`

Raises

- `JLinkException` – if connection fails to establish.
- `TypeError` – if given speed is invalid

connected()

Returns whether a J-Link is connected.

Parameters **self** (`JLink`) – the `JLink` instance

Returns `True` if the J-Link is open and connected, otherwise `False`.

connected_emulators (`host=1`)

Returns a list of all the connected emulators.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **host** (`int`) – host type to search (default: `JLinkHost.USB`)

Returns List of `JLinkConnectInfo` specifying the connected emulators.

Raises `JLinkException` – if fails to enumerate devices.

connection_required (`func`)

Decorator to specify that a target connection is required in order for the given method to be used.

Parameters **func** (`function`) – function being decorated

Returns The wrapper function.

core_cpu (`*args, **kwargs`)

Returns the identifier of the core CPU.

Note: This is distinct from the value returned from `core_id()` which is the ARM specific identifier.

Parameters **self** (`JLink`) – the `JLink` instance

Returns The identifier of the CPU core.

core_id (`*args, **kwargs`)

Returns the identifier of the target ARM core.

Parameters **self** (`JLink`) – the `JLink` instance

Returns Integer identifier of ARM core.

core_name (`*args, **kwargs`)

Returns the name of the target ARM core.

Parameters **self** (`JLink`) – the `JLink` instance

Returns The target core's name.

coresight_configuration_required (*func*)

Decorator to specify that a coresight configuration or target connection is required in order for the given method to be used.

Parameters **func** (*function*) – function being decorated

Returns The wrapper function.

coresight_configure (**args, **kwargs*)

Prepares target and J-Link for CoreSight function usage.

Parameters

- **self** (*JLink*) – the JLink instance
- **ir_pre** (*int*) – sum of instruction register length of all JTAG devices in the JTAG chain, close to TDO than the actual one, that J-Link shall communicate with
- **dr_pre** (*int*) – number of JTAG devices in the JTAG chain, closer to TDO than the actual one, that J-Link shall communicate with
- **ir_post** (*int*) – sum of instruction register length of all JTAG devices in the JTAG chain, following the actual one, that J-Link shall communicate with
- **dr_post** (*int*) – Number of JTAG devices in the JTAG chain, following the actual one, J-Link shall communicate with
- **ir_len** (*int*) – instruction register length of the actual device that J-Link shall communicate with
- **perform_tif_init** (*bool*) – if `False`, then do not output switching sequence on completion

Returns `None`

Note: This must be called before calling `coresight_read()` or `coresight_write()`.

coresight_read (**args, **kwargs*)

Reads an Ap/DP register on a CoreSight DAP.

Wait responses and special handling are both handled by this method.

Note: `coresight_configure()` must be called prior to calling this method.

Parameters

- **self** (*JLink*) – the JLink instance
- **reg** (*int*) – index of DP/AP register to read
- **ap** (*bool*) – True if reading from an Access Port register, otherwise `False` for Debug Port

Returns Data read from register.

Raises `JLinkException` – on hardware error

coresight_write (**args, **kwargs*)

Writes an Ap/DP register on a CoreSight DAP.

Note: `coresight_configure()` must be called prior to calling this method.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **reg** (`int`) – index of DP/AP register to write
- **data** (`int`) – data to write
- **ap** (`bool`) – True if writing to an Access Port register, otherwise `False` for Debug Port

Returns Number of repetitions needed until write request accepted.

Raises `JLinkException` – on hardware error

cp15_present (`*args, **kwargs`)

Returns whether target has CP15 co-processor.

Returns `True` if the target has CP15 co-processor, otherwise `False`.

cp15_register_read (`*args, **kwargs`)

Reads value from specified coprocessor register.

Parameters

- **cr_n** (`int`) – CRn value
- **op_1** (`int`) – Op1 value
- **cr_m** (`int`) – CRm value
- **op_2** (`int`) – Op2 value

Returns An integer containing the value of coprocessor register

Raises `JLinkException` – on error

cp15_register_write (`*args, **kwargs`)

Writes value to specified coprocessor register.

Parameters

- **cr_n** (`int`) – CRn value
- **op_1** (`int`) – Op1 value
- **cr_m** (`int`) – CRm value
- **op_2** (`int`) – Op2 value
- **value** (`int`) – value to write

Returns An integer containing the result of the command

Raises `JLinkException` – on error

cpu_capability (`*args, **kwargs`)

Checks whether the J-Link has support for a CPU capability.

This method checks if the emulator has built-in intelligence to handle the given CPU capability for the target CPU it is connected to.

Parameters

- **self** (`JLink`) – the `JLink` instance

- **capability** (*int*) – the capability to check for

Returns True if the J-Link has built-in intelligence to support the given *capability* for the CPU it is connected to, otherwise False.

cpu_halt_reasons (**args, **kwargs*)

Retrieves the reasons that the CPU was halted.

Parameters **self** (*JLink*) – the *JLink* instance

Returns A list of *JLinkMOEInfo* instances specifying the reasons for which the CPU was halted. This list may be empty in the case that the CPU is not halted.

Raises *JLinkException* – on hardware error.

cpu_speed (**args, **kwargs*)

Retrieves the CPU speed of the target.

If the target does not support CPU frequency detection, this function will return 0.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **silent** (*bool*) – True if the CPU detection should not report errors to the error handler on failure.

Returns The measured CPU frequency on success, otherwise 0 if the core does not support CPU frequency detection.

Raises *JLinkException* – on hardware error.

custom_licenses

Returns a string of the installed licenses the J-Link has.

Parameters **self** (*JLink*) – the *JLink* instance

Returns String of the contents of the custom licenses the J-Link has.

detailed_log_handler

Returns the detailed log handler function.

Parameters **self** (*JLink*) – the *JLink* instance

Returns None if the detailed log handler was not set, otherwise a *ctypes.CFUNCTYPE*.

device_family (**args, **kwargs*)

Returns the device family of the target CPU.

Parameters **self** (*JLink*) – the *JLink* instance

Returns Integer identifier of the device family.

disable_dialog_boxes (**args, **kwargs*)

Disables showing dialog boxes on certain methods.

Warning: This has the effect of also silencing dialog boxes that appear when updating firmware / to confirm updating firmware.

Dialog boxes will be shown for a brief period of time (approximately five seconds), before being automatically hidden, and the default option chosen.

Parameters **self** (*JLink*) – the *JLink* instance

Returns None

disable_reset_inits_registers (*args, **kwargs)

Disables CPU register initialization on resets.

When `.reset()` is called, the CPU registers will be read and not initialized.

Parameters `self` (`JLink`) – the `JLink` instance

Returns `True` if was previously enabled, otherwise `False`.

disable_reset_pulls_reset (*args, **kwargs)

Disables RESET pin toggling on the JTAG bus on resets.

When `.reset()` is called, it will not toggle the RESET pin on the JTAG bus.

Parameters `self` (`JLink`) – the `JLink` instance

Returns `None`

disable_reset_pulls_trst (*args, **kwargs)

Disables TRST pin toggling on the JTAG bus on resets.

When `.reset()` is called, it will not toggle the TRST pin on the JTAG bus.

Parameters `self` (`JLink`) – the `JLink` instance

Returns `None`

disable_soft_breakpoints (*args, **kwargs)

Disables software breakpoints.

Note: After this function is called, `software_breakpoint_set()` cannot be used without first calling `enable_soft_breakpoints()`.

Parameters `self` (`JLink`) – the `JLink` instance

Returns `None`

disassemble_instruction (instruction)

Disassembles and returns the assembly instruction string.

Parameters

- `self` (`JLink`) – the `JLink` instance.
- `instruction` (`int`) – the instruction address.

Returns A string corresponding to the assembly instruction string at the given instruction address.

Raises

- `JLinkException` – on error.
- `TypeError` – if `instruction` is not a number.

enable_dialog_boxes (*args, **kwargs)

Enables showing dialog boxes on certain methods.

Note: This can be used for batch or automated test running.

Parameters `self` (`JLink`) – the `JLink` instance

Returns None

enable_reset_inits_registers (*args, **kwargs)

Enables CPU register initialization on resets.

When `.reset()` is called, it will initialize the CPU registers.

Parameters **self** (JLink) – the JLink instance

Returns True if was previously enabled, otherwise False.

enable_reset_pulls_reset (*args, **kwargs)

Enables RESET pin toggling on the JTAG bus on resets.

When `.reset()` is called, it will also toggle the RESET pin on the JTAG bus.

Parameters **self** (JLink) – the JLink instance

Returns None

enable_reset_pulls_trst (*args, **kwargs)

Enables TRST pin toggling on the JTAG bus on resets.

When `.reset()` is called, it will also toggle the TRST pin on the JTAG bus.

Parameters **self** (JLink) – the JLink instance

Returns None

enable_soft_breakpoints (*args, **kwargs)

Enables software breakpoints.

Note: This should be called before calling `software_breakpoint_set()`.

Parameters **self** (JLink) – the JLink instance

Returns None

erase (*args, **kwargs)

Erases the flash contents of the device.

This erases the flash memory of the target device. If this method fails, the device may be left in an inoperable state.

Parameters **self** (JLink) – the JLink instance

Returns Number of bytes erased.

erase_licenses (*args, **kwargs)

Erases the custom licenses from the connected J-Link.

Note: This method will erase all licenses stored on the J-Link.

Parameters **self** (JLink) – the JLink instance

Returns True on success, otherwise False.

error

DLL internal error state.

Parameters `self` (`JLink`) – the `JLink` instance

Returns The DLL internal error state. This is set if any error occurs in underlying DLL, otherwise it is `None`.

error_handler

Returns the error handler function.

Parameters `self` (`JLink`) – the `JLink` instance

Returns `None` if the error handler was not set, otherwise a `ctypes.CFUNCTYPE`.

etm_register_read (`*args`, `**kwargs`)

Reads a value from an ETM register.

Parameters

- `self` (`JLink`) – the `JLink` instance.
- `register_index` (`int`) – the register to read.

Returns The value read from the ETM register.

etm_register_write (`*args`, `**kwargs`)

Writes a value to an ETM register.

Parameters

- `self` (`JLink`) – the `JLink` instance.
- `register_index` (`int`) – the register to write to.
- `value` (`int`) – the value to write to the register.
- `delay` (`bool`) – boolean specifying if the write should be buffered.

Returns `None`

etm_supported (`*args`, `**kwargs`)

Returns if the CPU core supports ETM.

Parameters `self` (`JLink`) – the `JLink` instance.

Returns `True` if the CPU has the ETM unit, otherwise `False`.

exec_command (`cmd`)

Executes the given command.

This method executes a command by calling the DLL's `exec` method. Direct API methods should be prioritized over calling this method.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `cmd` (`str`) – the command to run

Returns The return code of running the command.

Raises `JLinkException` – if the command is invalid or fails.

See also:

For a full list of the supported commands, please see the SEGGER J-Link documentation, [UM08001](#).

extended_capabilities

Gets the capabilities of the connected emulator as a list.

Parameters `self` (`JLink`) – the `JLink` instance

Returns List of 32 integers which define the extended capabilities based on their value and index within the list.

extended_capability (*args, **kwargs)

Checks if the emulator has the given extended capability.

Parameters

- **self** (JLink) – the JLink instance
- **capability** (int) – capability being queried

Returns True if the emulator has the given extended capability, otherwise False.

features

Returns a list of the J-Link embedded features.

Parameters **self** (JLink) – the JLink instance

Returns ['RDI', 'FlashBP', 'FlashDL', 'JFlash', 'GDB']

Return type A list of strings, each a feature. Example

firmware_newer (*args, **kwargs)

Returns whether the J-Link's firmware version is newer than the one that the DLL is compatible with.

Note: This is not the same as calling `not jlink.firmware_outdated()`.

Parameters **self** (JLink) – the JLink instance

Returns True if the J-Link's firmware is newer than the one supported by the DLL, otherwise False.

firmware_outdated (*args, **kwargs)

Returns whether the J-Link's firmware version is older than the one that the DLL is compatible with.

Note: This is not the same as calling `not jlink.firmware_newer()`.

Parameters **self** (JLink) – the JLink instance

Returns True if the J-Link's firmware is older than the one supported by the DLL, otherwise False.

firmware_version

Returns a firmware identification string of the connected J-Link.

It consists of the following:

- Product Name (e.g. J-Link)
- The string: compiled
- Compile data and time.
- Optional additional information.

Parameters **self** (JLink) – the JLink instance

Returns Firmware identification string.

flash (*args, **kwargs)

Flashes the target device.

The given `on_progress` callback will be called as `on_progress(action, progress_string, percentage)` periodically as the data is written to flash. The action is one of Compare, Erase, Verify, Flash.

Parameters

- **self** (*JLink*) – the JLink instance
- **data** (*list*) – list of bytes to write to flash
- **addr** (*int*) – start address on flash which to write the data
- **on_progress** (*function*) – callback to be triggered on flash progress
- **power_on** (*boolean*) – whether to power the target before flashing
- **flags** (*int*) – reserved, do not use

Returns Number of bytes flashed. This number may not necessarily be equal to `len(data)`, but that does not indicate an error.

Raises *JLinkException* – on hardware errors.

flash_file (*args, **kwargs)

Flashes the target device.

The given `on_progress` callback will be called as `on_progress(action, progress_string, percentage)` periodically as the data is written to flash. The action is one of Compare, Erase, Verify, Flash.

Parameters

- **self** (*JLink*) – the JLink instance
- **path** (*str*) – absolute path to the source file to flash
- **addr** (*int*) – start address on flash which to write the data
- **on_progress** (*function*) – callback to be triggered on flash progress
- **power_on** (*boolean*) – whether to power the target before flashing

Returns Integer value greater than or equal to zero. Has no significance.

Raises *JLinkException* – on hardware errors.

flash_write (*args, **kwargs)

Writes data to the flash region of a device.

The given number of bits, if provided, must be either 8, 16, or 32.

Parameters

- **self** (*JLink*) – the JLink instance
- **addr** (*int*) – starting flash address to write to
- **data** (*list*) – list of data units to write
- **nbits** (*int*) – number of bits to use for each unit

Returns Number of bytes written to flash.

flash_write16 (*args, **kwargs)

Writes halfwords to the flash region of a device.

Parameters

- **self** (*JLink*) – the JLink instance
- **addr** (*int*) – starting flash address to write to
- **data** (*list*) – list of halfwords to write

Returns Number of bytes written to flash.

flash_write32 (**args, **kwargs*)

Writes words to the flash region of a device.

Parameters

- **self** (*JLink*) – the JLink instance
- **addr** (*int*) – starting flash address to write to
- **data** (*list*) – list of words to write

Returns Number of bytes written to flash.

flash_write8 (**args, **kwargs*)

Writes bytes to the flash region of a device.

Parameters

- **self** (*JLink*) – the JLink instance
- **addr** (*int*) – starting flash address to write to
- **data** (*list*) – list of bytes to write

Returns Number of bytes written to flash.

get_device_index (*chip_name*)

Finds index of device with chip name

Parameters

- **self** (*JLink*) – the JLink instance
- **chip_name** (*str*) – target chip name

Returns Index of the device with the matching chip name.

Raises *JLinkException* – if chip is unsupported.

gpio_get (**args, **kwargs*)

Returns a list of states for the given pins.

Defaults to the first four pins if an argument is not given.

Parameters

- **self** (*JLink*) – the JLink instance
- **pins** (*list*) – indices of the GPIO pins whose states are requested

Returns A list of states.

Raises *JLinkException* – on error.

gpio_properties (**args, **kwargs*)

Returns the properties of the user-controllable GPIOs.

Provided the device supports user-controllable GPIOs, they will be returned by this method.

Parameters **self** (*JLink*) – the JLink instance

Returns A list of `JLinkGPIODescriptor` instances totalling the number of requested properties.

Raises `JLinkException` – on error.

gpio_set (*args, **kwargs)

Sets the state for one or more user-controllable GPIOs.

For each of the given pins, sets the the corresponding state based on the index.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **pins** (`list`) – list of GPIO indices
- **states** (`list`) – list of states to set

Returns A list of updated states.

Raises

- `JLinkException` – on error.
- `ValueError` – if `len(pins) != len(states)`

halt (*args, **kwargs)

Halts the CPU Core.

Parameters **self** (`JLink`) – the `JLink` instance

Returns `True` if halted, `False` otherwise.

halted (*args, **kwargs)

Returns whether the CPU core was halted.

Parameters **self** (`JLink`) – the `JLink` instance

Returns `True` if the CPU core is halted, otherwise `False`.

Raises `JLinkException` – on device errors.

hardware_breakpoint_set (*args, **kwargs)

Sets a hardware breakpoint at the specified address.

If `thumb` is `True`, the breakpoint is set in THUMB-mode, while if `arm` is `True`, the breakpoint is set in ARM-mode, otherwise a normal breakpoint is set.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **addr** (`int`) – the address where the breakpoint will be set
- **thumb** (`bool`) – boolean indicating to set the breakpoint in THUMB mode
- **arm** (`bool`) – boolean indicating to set the breakpoint in ARM mode

Returns An integer specifying the breakpoint handle. This handle should sbe retained for future breakpoint operations.

Raises

- `TypeError` – if the given address is not an integer.
- `JLinkException` – if the breakpoint could not be set.

hardware_info

Returns a list of 32 integer values corresponding to the bitfields specifying the power consumption of the target.

The values returned by this function only have significance if the J-Link is powering the target.

The words, indexed, have the following significance:

0. If 1, target is powered via J-Link.
1. Overcurrent bitfield: 0: No overcurrent. 1: Overcurrent happened. 2ms @ 3000mA 2: Overcurrent happened. 10ms @ 1000mA 3: Overcurrent happened. 40ms @ 400mA
2. Power consumption of target (mA).
3. Peak of target power consumption (mA).
4. Peak of target power consumption during J-Link operation (mA).

Parameters

- **self** (*JLink*) – the JLink instance
- **mask** (*int*) – bit mask to decide which hardware information words are returned (defaults to all the words).

Returns List of bitfields specifying different states based on their index within the list and their value.

Raises *JLinkException* – on hardware error.

hardware_status

Retrieves and returns the hardware status.

Parameters **self** (*JLink*) – the JLink instance

Returns A *JLinkHardwareStatus* describing the J-Link hardware.

hardware_version

Returns the hardware version of the connected J-Link as a major.minor string.

Parameters **self** (*JLink*) – the JLink instance

Returns Hardware version string.

ice_register_read (**args, **kwargs*)

Reads a value from an ARM ICE register.

Parameters

- **self** (*JLink*) – the JLink instance
- **register_index** (*int*) – the register to read

Returns The value read from the register.

ice_register_write (**args, **kwargs*)

Writes a value to an ARM ICE register.

Parameters

- **self** (*JLink*) – the JLink instance
- **register_index** (*int*) – the ICE register to write to
- **value** (*int*) – the value to write to the ICE register

- **delay** (*bool*) – boolean specifying if the write should be delayed

Returns None

index

Retrieves and returns the index number of the actual selected J-Link.

Parameters **self** (*JLink*) – the JLink instance

Returns Index of the currently connected J-Link.

interface_required (*interface*)

Decorator to specify that a particular interface type is required for the given method to be used.

Parameters **interface** (*int*) – attribute of JLinkInterfaces

Returns A decorator function.

invalidate_firmware (**args, **kwargs*)

Invalidates the emulator's firmware.

This method is useful for downgrading the firmware on an emulator. By calling this method, the current emulator's firmware is invalidated, which will make the emulator download the firmware of the J-Link SDK DLL that this instance was created with.

Parameters **self** (*JLink*) – the JLink instance

Returns None

Raises *JLinkException* – on hardware error.

ir_len (**args, **kwargs*)

Counts and returns the total length of instruction registers of all the devices in the JTAG scan chain.

Parameters **self** (*JLink*) – the JLink instance

Returns Total instruction register length.

jtag_configure (**args, **kwargs*)

Configures the JTAG scan chain to determine which CPU to address.

Must be called if the J-Link is connected to a JTAG scan chain with multiple devices.

Parameters

- **self** (*JLink*) – the JLink instance
- **instr_regs** (*int*) – length of instruction registers of all devices closer to TD1 than the addressed CPU
- **data_bits** (*int*) – total number of data bits closer to TD1 than the addressed CPU

Returns None

Raises *ValueError* – if *instr_regs* or *data_bits* are not natural numbers

jtag_create_clock (**args, **kwargs*)

Creates a JTAG clock on TCK.

Note: This function only needs to be called once.

Parameters **self** (*JLink*) – the JLink instance

Returns either 0 or 1.

Return type The state of the TDO pin

jtag_flush (*args, **kwargs)
Flushes the internal JTAG buffer.

Note: The buffer is automatically flushed when a response from the target is expected, or the buffer is full. This can be used after a `memory_write()` in order to flush the buffer.

Parameters **self** (JLink) – the JLink instance

Returns None

jtag_send (*args, **kwargs)
Sends data via JTAG.

Sends data via JTAG on the rising clock edge, TCK. At on each rising clock edge, one bit is transferred in from TDI and out to TDO. The clock uses the TMS to step through the standard JTAG state machine.

Parameters

- **self** (JLink) – the JLink instance
- **tms** (int) – used to determine the state transitions for the Test Access Port (TAP) controller from its current state
- **tdi** (int) – input data to be transferred in from TDI to TDO
- **num_bits** (int) – a number in the range [1, 32] inclusively specifying the number of meaningful bits in the `tms` and `tdi` parameters for the purpose of extracting state and data information

Returns None

Raises ValueError – if `num_bits < 1` or `num_bits > 32`.

See also:

[JTAG Technical Overview](#).

licenses

Returns a string of the built-in licenses the J-Link has.

Parameters **self** (JLink) – the JLink instance

Returns String of the contents of the built-in licenses the J-Link has.

log_handler

Returns the log handler function.

Parameters **self** (JLink) – the JLink instance

Returns None if the log handler was not set, otherwise a `ctypes.CFUNCTYPE`.

memory_read (*args, **kwargs)

Reads memory from a target system or specific memory zone.

The optional `zone` specifies a memory zone to access to read from, e.g. `IDATA`, `DDATA`, or `CODE`.

The given number of bits, if provided, must be either 8, 16, or 32. If not provided, always reads `num_units` bytes.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **addr** (*int*) – start address to read from
- **num_units** (*int*) – number of units to read
- **zone** (*str*) – optional memory zone name to access
- **nbits** (*int*) – number of bits to use for each unit

Returns List of units read from the target system.

Raises

- *JLinkException* – if memory could not be read.
- *ValueError* – if *nbits* is not *None*, and not in 8, 16, or 32.

memory_read16 (**args, **kwargs*)

Reads memory from the target system in units of 16-bits.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **addr** (*int*) – start address to read from
- **num_halfwords** (*int*) – number of half words to read
- **zone** (*str*) – memory zone to read from

Returns List of halfwords read from the target system.

Raises *JLinkException* – if memory could not be read

memory_read32 (**args, **kwargs*)

Reads memory from the target system in units of 32-bits.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **addr** (*int*) – start address to read from
- **num_words** (*int*) – number of words to read
- **zone** (*str*) – memory zone to read from

Returns List of words read from the target system.

Raises *JLinkException* – if memory could not be read

memory_read64 (**args, **kwargs*)

Reads memory from the target system in units of 64-bits.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **addr** (*int*) – start address to read from
- **num_long_words** (*int*) – number of long words to read

Returns List of long words read from the target system.

Raises *JLinkException* – if memory could not be read

memory_read8 (**args, **kwargs*)

Reads memory from the target system in units of bytes.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **addr** (*int*) – start address to read from
- **num_bytes** (*int*) – number of bytes to read
- **zone** (*str*) – memory zone to read from

Returns List of bytes read from the target system.

Raises *JLinkException* – if memory could not be read.

memory_write (**args, **kwargs*)

Writes memory to a target system or specific memory zone.

The optional *zone* specifies a memory zone to access to write to, e.g. *IDATA*, *DDATA*, or *CODE*.

The given number of bits, if provided, must be either 8, 16, or 32.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **addr** (*int*) – start address to write to
- **data** (*list*) – list of data units to write
- **zone** (*str*) – optional memory zone name to access
- **nbits** (*int*) – number of bits to use for each unit

Returns Number of units written.

Raises

- *JLinkException* – on write hardware failure.
- *ValueError* – if *nbits* is not *None*, and not in 8, 16 or 32.

memory_write16 (**args, **kwargs*)

Writes half-words to memory of a target system.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **addr** (*int*) – start address to write to
- **data** (*list*) – list of half-words to write
- **zone** (*str*) – optional memory zone to access

Returns Number of half-words written to target.

Raises *JLinkException* – on memory access error.

memory_write32 (**args, **kwargs*)

Writes words to memory of a target system.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **addr** (*int*) – start address to write to
- **data** (*list*) – list of words to write
- **zone** (*str*) – optional memory zone to access

Returns Number of words written to target.

Raises `JLinkException` – on memory access error.

`memory_write64 (*args, **kwargs)`

Writes long words to memory of a target system.

Note: This is little-endian.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **addr** (`int`) – start address to write to
- **data** (`list`) – list of long words to write
- **zone** (`str`) – optional memory zone to access

Returns Number of long words written to target.

Raises `JLinkException` – on memory access error.

`memory_write8 (*args, **kwargs)`

Writes bytes to memory of a target system.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **addr** (`int`) – start address to write to
- **data** (`list`) – list of bytes to write
- **zone** (`str`) – optional memory zone to access

Returns Number of bytes written to target.

Raises `JLinkException` – on memory access error.

`memory_zones (*args, **kwargs)`

Gets all memory zones supported by the current target.

Some targets support multiple memory zones. This function provides the ability to get a list of all the memory zones to facilitate using the memory zone routing functions.

Parameters **self** (`JLink`) – the `JLink` instance

Returns A list of all the memory zones as `JLinkMemoryZone` structures.

Raises `JLinkException` – on hardware errors.

`minimum_required (version)`

Decorator to specify the minimum SDK version required.

Parameters **version** (`str`) – valid version string

Returns A decorator function.

`num_active_breakpoints (*args, **kwargs)`

Returns the number of currently active breakpoints.

Parameters **self** (`JLink`) – the `JLink` instance

Returns The number of breakpoints that are currently set.

num_active_watchpoints (*args, **kwargs)

Returns the number of currently active watchpoints.

Parameters **self** (JLink) – the JLink instance

Returns The number of watchpoints that are currently set.

num_available_breakpoints (*args, **kwargs)

Returns the number of available breakpoints of the specified type.

If **arm** is set, gets the number of available ARM breakpoint units. If **thumb** is set, gets the number of available THUMB breakpoint units. If **ram** is set, gets the number of available software RAM breakpoint units. If **flash** is set, gets the number of available software flash breakpoint units. If **hw** is set, gets the number of available hardware breakpoint units.

If a combination of the flags is given, then `num_available_breakpoints()` returns the number of breakpoints specified by the given flags. If no flags are specified, then the count of available breakpoint units is returned.

Parameters

- **self** (JLink) – the JLink instance
- **arm** (*bool*) – Boolean indicating to get number of ARM breakpoints.
- **thumb** (*bool*) – Boolean indicating to get number of THUMB breakpoints.
- **ram** (*bool*) – Boolean indicating to get number of SW RAM breakpoints.
- **flash** (*bool*) – Boolean indicating to get number of Flash breakpoints.
- **hw** (*bool*) – Boolean indicating to get number of Hardware breakpoints.

Returns The number of available breakpoint units of the specified type.

num_available_watchpoints (*args, **kwargs)

Returns the number of available watchpoints.

Parameters **self** (JLink) – the JLink instance

Returns The number of watchpoints that are available to be set.

num_connected_emulators ()

Returns the number of emulators which are connected via USB to the host.

Parameters **self** (JLink) – the JLink instance

Returns The number of connected emulators.

num_memory_zones (*args, **kwargs)

Returns the number of memory zones supported by the target.

Parameters **self** (JLink) – the JLink instance

Returns An integer count of the number of memory zones supported by the target.

Raises `JLinkException` – on error.

num_supported_devices ()

Returns the number of devices that are supported by the opened J-Link DLL.

Parameters **self** (JLink) – the JLink instance

Returns Number of devices the J-Link DLL supports.

oem

Retrieves and returns the OEM string of the connected J-Link.

Parameters `self` (`JLink`) – the `JLink` instance

Returns The string of the OEM. If this is an original SEGGER product, then `None` is returned instead.

Raises `JLinkException` – on hardware error.

open (`serial_no=None`, `ip_addr=None`)

Connects to the J-Link emulator (defaults to USB).

If `serial_no` and `ip_addr` are both given, this function will connect to the J-Link over TCP/IP.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `serial_no` (`int`) – serial number of the J-Link
- `ip_addr` (`str`) – IP address and port of the J-Link (e.g. 192.168.1.1:80)

Returns `None`

Raises

- `JLinkException` – if fails to open (i.e. if device is unplugged)
- `TypeError` – if `serial_no` is present, but not `int` coercible.
- `AttributeError` – if `serial_no` and `ip_addr` are both `None`.

open_required (`func`)

Decorator to specify that the J-Link DLL must be opened, and a J-Link connection must be established.

Parameters `func` (`function`) – function being decorated

Returns The wrapper function.

open_tunnel (`serial_no`, `port=19020`)

Connects to the J-Link emulator (over SEGGER tunnel).

Parameters

- `self` (`JLink`) – the `JLink` instance
- `serial_no` (`int`) – serial number of the J-Link
- `port` (`int`) – optional port number (default to 19020).

Returns `None`

opened ()

Returns whether the DLL is open.

Parameters `self` (`JLink`) – the `JLink` instance

Returns `True` if the J-Link is open, otherwise `False`.

power_off (`*args`, `**kwargs`)

Turns off the power supply over pin 19 of the JTAG connector.

If given the optional `default` parameter, deactivates the power supply by default.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `default` (`bool`) – boolean indicating if to set power off by default

Returns The current `JLink` instance

Raises `JLinkException` – if J-Link does not support powering the target.

power_on (**args*, ***kwargs*)

Turns on the power supply over pin 19 of the JTAG connector.

If given the optional `default` parameter, activates the power supply by default.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **default** (`bool`) – boolean indicating if to set power by default

Returns `None`

Raises `JLinkException` – if J-Link does not support powering the target.

product_name

Returns the product name of the connected J-Link.

Parameters **self** (`JLink`) – the `JLink` instance

Returns Product name.

register_list (**args*, ***kwargs*)

Returns a list of the indices for the CPU registers.

The returned indices can be used to read the register content or grab the register name.

Parameters **self** (`JLink`) – the `JLink` instance

Returns List of registers.

register_name (**args*, ***kwargs*)

Retrives and returns the name of an ARM CPU register.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **register_index** (`int`) – index of the register whose name to retrieve

Returns Name of the register.

register_read (**args*, ***kwargs*)

Reads the value from the given register.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **register_index** (`int/str`) – the register to read

Returns The value stored in the given register.

register_read_multiple (**args*, ***kwargs*)

Retrieves the values from the registers specified.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **register_indices** (`list`) – list of registers to read

Returns A list of values corresponding one-to-one for each of the given register indices. The returned list of values are the values in order of which the indices were specified.

Raises `JLinkException` – if a given register is invalid or an error occurs.

register_write (*args, **kwargs)

Writes into an ARM register.

Note: The data is not immediately written, but is cached before being transferred to the CPU on CPU start.

Parameters

- **self** (*JLink*) – the JLink instance
- **reg_index** (*int/str*) – the ARM register to write to
- **value** (*int*) – the value to write to the register

Returns The value written to the ARM register.

Raises *JLinkException* – on write error.

register_write_multiple (*args, **kwargs)

Writes to multiple CPU registers.

Writes the values to the given registers in order. There must be a one-to-one correspondence between the values and the registers specified.

Parameters

- **self** (*JLink*) – the JLink instance
- **register_indices** (*list*) – list of registers to write to
- **values** (*list*) – list of values to write to the registers

Returns *None*

Raises

- *ValueError* – if `len(register_indices) != len(values)`
- *JLinkException* – if a register could not be written to or on error

reset (*args, **kwargs)

Resets the target.

This method resets the target, and by default toggles the RESET and TRST pins.

Parameters

- **self** (*JLink*) – the JLink instance
- **ms** (*int*) – Amount of milliseconds to delay after reset (default: 0)
- **halt** (*bool*) – if the CPU should halt after reset (default: True)

Returns Number of bytes read.

reset_tap (*args, **kwargs)

Resets the TAP controller via TRST.

Note: This must be called at least once after power up if the TAP controller is to be used.

Parameters **self** (*JLink*) – the JLink instance

Returns None

restart (*args, **kwargs)

Restarts the CPU core and simulates/emulates instructions.

Note: This is a no-op if the CPU isn't halted.

Parameters

- **self** (JLink) – the JLink instance
- **num_instructions** (int) – number of instructions to simulate, defaults to zero
- **skip_breakpoints** (bool) – skip current breakpoint (default: False)

Returns True if device was restarted, otherwise False.

Raises ValueError – if instruction count is not a natural number.

rtt_control (*args, **kwargs)

Issues an RTT Control command.

All RTT control is done through a single API call which expects specifically laid-out configuration structures.

Parameters

- **self** (JLink) – the JLink instance
- **command** (int) – the command to issue (see enums.JLinkRTTCommand)
- **config** (ctypes type) – the configuration to pass by reference.

Returns An integer containing the result of the command.

Raises JLinkRTTException – on error.

rtt_get_buf_descriptor (*args, **kwargs)

After starting RTT, get the descriptor for an RTT control block.

Parameters

- **self** (JLink) – the JLink instance
- **buffer_index** (int) – the index of the buffer to get.
- **up** (bool) – True if buffer is an UP buffer, otherwise False.

Returns JLinkRTTTerminalBufDesc describing the buffer.

Raises JLinkRTTException – if the RTT control block has not yet been found.

rtt_get_num_down_buffers (*args, **kwargs)

After starting RTT, get the current number of down buffers.

Parameters **self** (JLink) – the JLink instance

Returns The number of configured down buffers on the target.

Raises JLinkRTTException – if the underlying JLINK_RTTERMINAL_Control call fails.

rtt_get_num_up_buffers (*args, **kwargs)

After starting RTT, get the current number of up buffers.

Parameters **self** (JLink) – the JLink instance

Returns The number of configured up buffers on the target.

Raises `JLinkRTTException` – if the underlying `JLINK_RTTERMINAL_Control` call fails.

rtt_get_status (**args, **kwargs*)

After starting RTT, get the status.

Parameters `self` (`JLink`) – the `JLink` instance

Returns The status of RTT.

Raises `JLinkRTTException` – on error.

rtt_read (**args, **kwargs*)

Reads data from the RTT buffer.

This method will read at most `num_bytes` bytes from the specified RTT buffer. The data is automatically removed from the RTT buffer. If there are not `num_bytes` bytes waiting in the RTT buffer, the entire contents of the RTT buffer will be read.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `buffer_index` (`int`) – the index of the RTT buffer to read from
- `num_bytes` (`int`) – the maximum number of bytes to read

Returns A list of bytes read from RTT.

Raises `JLinkRTTException` – if the underlying `JLINK_RTTERMINAL_Read` call fails.

rtt_start (**args, **kwargs*)

Starts RTT processing, including background read of target data.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `block_address` (`int`) – optional configuration address for the RTT block

Returns `None`

Raises `JLinkRTTException` – if the underlying `JLINK_RTTERMINAL_Control` call fails.

rtt_stop (**args, **kwargs*)

Stops RTT on the J-Link and host side.

Parameters `self` (`JLink`) – the `JLink` instance

Returns `None`

Raises `JLinkRTTException` – if the underlying `JLINK_RTTERMINAL_Control` call fails.

rtt_write (**args, **kwargs*)

Writes data to the RTT buffer.

This method will write at most `len(data)` bytes to the specified RTT buffer.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `buffer_index` (`int`) – the index of the RTT buffer to write to
- `data` (`list`) – the list of bytes to write to the RTT buffer

Returns The number of bytes successfully written to the RTT buffer.

Raises `JLinkRTTException` – if the underlying `JLINK_RTTERMINAL_Write` call fails.

scan_chain_len (**args*, ***kwargs*)

Retrieves and returns the number of bits in the scan chain.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **scan_chain** (*int*) – scan chain to be measured

Returns Number of bits in the specified scan chain.

Raises `JLinkException` – on error.

scan_len (**args*, ***kwargs*)

Retrieves and returns the length of the scan chain select register.

Parameters **self** (`JLink`) – the `JLink` instance

Returns Length of the scan chain select register.

serial_number

Returns the serial number of the connected J-Link.

Parameters **self** (`JLink`) – the `JLink` instance

Returns Serial number as an integer.

set_big_endian (**args*, ***kwargs*)

Sets the target hardware to big endian.

Parameters **self** (`JLink`) – the `JLink` instance

Returns True if target was little endian before call, otherwise False.

set_etb_trace (**args*, ***kwargs*)

Sets the trace source to ETB.

Parameters **self** (`JLink`) – the `JLink` instance.

Returns None

set_etm_trace (**args*, ***kwargs*)

Sets the trace source to ETM.

Parameters **self** (`JLink`) – the `JLink` instance.

Returns None

set_little_endian (**args*, ***kwargs*)

Sets the target hardware to little endian.

Parameters **self** (`JLink`) – the `JLink` instance

Returns True if target was big endian before call, otherwise False.

set_log_file (**args*, ***kwargs*)

Sets the log file output path. see https://wiki.segger.com/Enable_J-Link_log_file

Parameters

- **self** (`JLink`) – the `JLink` instance
- **file_path** (*str*) – the file path where the log file will be stored

Returns None

Raises `JLinkException` – if the path specified is invalid.

set_max_speed (*args, **kwargs)

Sets JTAG communication speed to the maximum supported speed.

Parameters **self** (JLink) – the JLink instance

Returns None

set_reset_pin_high (*args, **kwargs)

Sets the reset pin high.

Parameters **self** (JLink) – the JLink instance

Returns None

set_reset_pin_low (*args, **kwargs)

Sets the reset pin low.

Parameters **self** (JLink) – the JLink instance

Returns None

set_reset_strategy (*args, **kwargs)

Sets the reset strategy for the target.

The reset strategy defines what happens when the target is reset.

Parameters

- **self** (JLink) – the JLink instance
- **strategy** (int) – the reset strategy to use

Returns The previous reset strategy.

set_speed (*args, **kwargs)

Sets the speed of the JTAG communication with the ARM core.

If no arguments are present, automatically detects speed.

If a speed is provided, the speed must be no larger than `JLink.MAX_JTAG_SPEED` and no smaller than `JLink.MIN_JTAG_SPEED`. The given speed can also not be `JLink.INVALID_JTAG_SPEED`.

Parameters

- **self** (JLink) – the JLink instance
- **speed** (int) – the speed in kHz to set the communication at
- **auto** (bool) – automatically detect correct speed
- **adaptive** (bool) – select adaptive clocking as JTAG speed

Returns None

Raises

- `TypeError` – if given speed is not a natural number.
- `ValueError` – if given speed is too high, too low, or invalid.

set_tck_pin_high (*args, **kwargs)

Sets the TCK pin to the high value (1).

Parameters **self** (JLink) – the JLink instance

Returns None

Raises `JLinkException` – if the emulator does not support this feature.

set_tck_pin_low (*args, **kwargs)

Sets the TCK pin to the low value (0).

Parameters **self** (*JLink*) – the *JLink* instance

Returns None

Raises *JLinkException* – if the emulator does not support this feature.

set_tdi_pin_high (*args, **kwargs)

Sets the test data input to logical 1.

Parameters **self** (*JLink*) – the *JLink* instance

Returns None

set_tdi_pin_low (*args, **kwargs)

Clears the test data input.

TDI is set to logical 0 (Ground).

Parameters **self** (*JLink*) – the *JLink* instance

Returns None

set_tif (*args, **kwargs)

Selects the specified target interface.

Note that a restart must be triggered for this to take effect.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **interface** (*int*) – integer identifier of the interface

Returns True if target was updated, otherwise False.

Raises *JLinkException* – if the given interface is invalid or unsupported.

set_tms_pin_high (*args, **kwargs)

Sets the test mode select to logical 1.

Parameters **self** (*JLink*) – the *JLink* instance

Returns None

set_tms_pin_low (*args, **kwargs)

Clears the test mode select.

TMS is set to logical 0 (Ground).

Parameters **self** (*JLink*) – the *JLink* instance

Returns None

set_trace_source (*args, **kwargs)

Sets the source to be used for tracing.

The source must be one of the ones provided by `enums.JLinkTraceSource`.

Parameters

- **self** (*JLink*) – the *JLink* instance.
- **source** (*int*) – the source to use.

Returns None

set_trst_pin_high (*args, **kwargs)

Sets the TRST pin to high (1).

Deasserts the TRST pin.

Parameters **self** (JLink) – the JLink instance

Returns None

set_trst_pin_low (*args, **kwargs)

Sets the TRST pin to low (0).

This asserts the TRST pin.

Parameters **self** (JLink) – the JLink instance

Returns None

set_vector_catch (*args, **kwargs)

Sets vector catch bits of the processor.

The CPU will jump to a vector if the given vector catch is active, and will enter a debug state. This has the effect of halting the CPU as well, meaning the CPU must be explicitly restarted.

Parameters **self** (JLink) – the JLink instance

Returns None

Raises JLinkException – on error.

software_breakpoint_set (*args, **kwargs)

Sets a software breakpoint at the specified address.

If `thumb` is `True`, the breakpoint is set in THUMB-mode, while if `arm` is `True`, the breakpoint is set in ARM-mode, otherwise a normal breakpoint is set.

If `flash` is `True`, the breakpoint is set in flash, otherwise if `ram` is `True`, the breakpoint is set in RAM. If both are `True` or both are `False`, then the best option is chosen for setting the breakpoint in software.

Parameters

- **self** (JLink) – the JLink instance
- **addr** (*int*) – the address where the breakpoint will be set
- **thumb** (*bool*) – boolean indicating to set the breakpoint in THUMB mode
- **arm** (*bool*) – boolean indicating to set the breakpoint in ARM mode
- **flash** (*bool*) – boolean indicating to set the breakpoint in flash
- **ram** (*bool*) – boolean indicating to set the breakpoint in RAM

Returns An integer specifying the breakpoint handle. This handle should be retained for future breakpoint operations.

Raises

- `TypeError` – if the given address is not an integer.
- `JLinkException` – if the breakpoint could not be set.

speed

Returns the current JTAG connection speed.

Parameters **self** (JLink) – the JLink instance

Returns JTAG connection speed.

speed_info

Retrieves information about supported target interface speeds.

Parameters **self** (*JLink*) – the *JLink* instance

Returns The *JLinkSpeedInfo* instance describing the supported target interface speeds.

step (**args*, ***kwargs*)

Executes a single step.

Steps even if there is a breakpoint.

Parameters

- **self** (*JLink*) – the *JLink* instance
- **thumb** (*bool*) – boolean indicating if to step in thumb mode

Returns *None*

Raises *JLinkException* – on error

strace_clear (**args*, ***kwargs*)

Clears the trace event specified by the given handle.

Parameters

- **self** (*JLink*) – the *JLink* instance.
- **handle** (*int*) – handle of the trace event.

Returns *None*

Raises *JLinkException* – on error.

strace_clear_all (**args*, ***kwargs*)

Clears all STRACE events.

Parameters **self** (*JLink*) – the *JLink* instance.

Returns *None*

Raises *JLinkException* – on error.

strace_code_fetch_event (**args*, ***kwargs*)

Sets an event to trigger trace logic when an instruction is fetched.

Parameters

- **self** (*JLink*) – the *JLink* instance.
- **operation** (*int*) – one of the operations in *JLinkStraceOperation*.
- **address** (*int*) – the address of the instruction that is fetched.
- **address_range** (*int*) – optional range of address to trigger event on.

Returns An integer specifying the trace event handle. This handle should be retained in order to clear the event at a later time.

Raises *JLinkException* – on error.

strace_configure (**args*, ***kwargs*)

Configures the trace port width for tracing.

Note that configuration cannot occur while STRACE is running.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **port_width** (`int`) – the trace port width to use.

Returns `None`

Raises

- `ValueError` – if `port_width` is not 1, 2, or 4.
- `JLinkException` – on error.

strace_data_access_event (`*args, **kwargs`)

Sets an event to trigger trace logic when data access is made.

Data access corresponds to either a read or write.

Parameters

- **self** (`JLink`) – the `JLink` instance.
- **operation** (`int`) – one of the operations in `JLinkStraceOperation`.
- **address** (`int`) – the address of the load/store data.
- **data** (`int`) – the data to be compared the event data to.
- **data_mask** (`int`) – optional bitmask specifying bits to ignore in comparison.
- **access_width** (`int`) – optional access width for the data.
- **address_range** (`int`) – optional range of address to trigger event on.

Returns An integer specifying the trace event handle. This handle should be retained in order to clear the event at a later time.

Raises `JLinkException` – on error.

strace_data_load_event (`*args, **kwargs`)

Sets an event to trigger trace logic when data read access is made.

Parameters

- **self** (`JLink`) – the `JLink` instance.
- **operation** (`int`) – one of the operations in `JLinkStraceOperation`.
- **address** (`int`) – the address of the load data.
- **address_range** (`int`) – optional range of address to trigger event on.

Returns An integer specifying the trace event handle. This handle should be retained in order to clear the event at a later time.

Raises `JLinkException` – on error.

strace_data_store_event (`*args, **kwargs`)

Sets an event to trigger trace logic when data write access is made.

Parameters

- **self** (`JLink`) – the `JLink` instance.
- **operation** (`int`) – one of the operations in `JLinkStraceOperation`.
- **address** (`int`) – the address of the store data.
- **address_range** (`int`) – optional range of address to trigger event on.

Returns An integer specifying the trace event handle. This handle should be retained in order to clear the event at a later time.

Raises `JLinkException` – on error.

strace_read (*args, **kwargs)

Reads and returns a number of instructions captured by STRACE.

The number of instructions must be a non-negative value of at most 0x10000 (65536).

Parameters

- **self** (`JLink`) – the `JLink` instance.
- **num_instructions** (`int`) – number of instructions to fetch.

Returns A list of instruction addresses in order from most recently executed to oldest executed instructions. Note that the number of instructions returned can be less than the number of instructions requested in the case that there are not `num_instructions` in the trace buffer.

Raises

- `JLinkException` – on error.
- `ValueError` – if `num_instructions < 0` or `num_instructions > 0x10000`.

strace_set_buffer_size (*args, **kwargs)

Sets the STRACE buffer size.

Parameters **self** (`JLink`) – the `JLink` instance.

Returns `None`

Raises `JLinkException` – on error.

strace_start (*args, **kwargs)

Starts the capturing of STRACE data.

Parameters **self** (`JLink`) – the `JLink` instance.

Returns `None`

Raises `JLinkException` – on error.

strace_stop (*args, **kwargs)

Stops the sampling of STRACE data.

Any capturing of STRACE data is automatically stopped when the CPU is halted.

Parameters **self** (`JLink`) – the `JLink` instance.

Returns `None`

Raises `JLinkException` – on error.

supported_device (index=0)

Gets the device at the given index.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **index** (`int`) – the index of the device whose information to get

Returns A `JLinkDeviceInfo` describing the requested device.

Raises `ValueError` – if index is less than 0 or \geq supported device count.

supported_tifs (*args, **kwargs)

Returns a bitmask of the supported target interfaces.

Parameters **self** (JLink) – the JLink instance

Returns Bitfield specifying which target interfaces are supported.

swd_read16 (*args, **kwargs)

Gets a unit of 16 bits from the input buffer.

Parameters

- **self** (JLink) – the JLink instance
- **offset** (*int*) – the offset (in bits) from which to start reading

Returns The integer read from the input buffer.

swd_read32 (*args, **kwargs)

Gets a unit of 32 bits from the input buffer.

Parameters

- **self** (JLink) – the JLink instance
- **offset** (*int*) – the offset (in bits) from which to start reading

Returns The integer read from the input buffer.

swd_read8 (*args, **kwargs)

Gets a unit of 8 bits from the input buffer.

Parameters

- **self** (JLink) – the JLink instance
- **offset** (*int*) – the offset (in bits) from which to start reading

Returns The integer read from the input buffer.

swd_sync (*args, **kwargs)

Causes a flush to write all data remaining in output buffers to SWD device.

Parameters

- **self** (JLink) – the JLink instance
- **pad** (*bool*) – True if should pad the data to full byte size

Returns None

swd_write (*args, **kwargs)

Writes bytes over SWD (Serial Wire Debug).

Parameters

- **self** (JLink) – the JLink instance
- **output** (*int*) – the output buffer offset to write to
- **value** (*int*) – the value to write to the output buffer
- **nbits** (*int*) – the number of bits needed to represent the output and value

Returns The bit position of the response in the input buffer.

swd_writel6 (*args, **kwargs)

Writes two bytes over SWD (Serial Wire Debug).

Parameters

- **self** (`JLink`) – the `JLink` instance
- **output** (`int`) – the output buffer offset to write to
- **value** (`int`) – the value to write to the output buffer

Returns The bit position of the response in the input buffer.

swd_write32 (`*args, **kwargs`)

Writes four bytes over SWD (Serial Wire Debug).

Parameters

- **self** (`JLink`) – the `JLink` instance
- **output** (`int`) – the output buffer offset to write to
- **value** (`int`) – the value to write to the output buffer

Returns The bit position of the response in the input buffer.

swd_write8 (`*args, **kwargs`)

Writes one byte over SWD (Serial Wire Debug).

Parameters

- **self** (`JLink`) – the `JLink` instance
- **output** (`int`) – the output buffer offset to write to
- **value** (`int`) – the value to write to the output buffer

Returns The bit position of the response in the input buffer.

swd_disable (`*args, **kwargs`)

Disables ITM & Stimulus ports.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **port_mask** (`int`) – mask specifying which ports to disable

Returns `None`

Raises `JLinkException` – on error

swd_enable (`*args, **kwargs`)

Enables SWO output on the target device.

Configures the output protocol, the SWO output speed, and enables any ITM & stimulus ports.

This is equivalent to calling `.swd_start()`.

Note: If SWO is already enabled, it will first stop SWO before enabling it again.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **cpu_speed** (`int`) – the target CPU frequency in Hz
- **swd_speed** (`int`) – the frequency in Hz used by the target to communicate
- **port_mask** (`int`) – port mask specifying which stimulus ports to enable

Returns None

Raises `JLinkException` – on error

swo_enabled()

Returns whether or not SWO is enabled.

Parameters `self` (`JLink`) – the `JLink` instance

Returns True if SWO is enabled, otherwise False.

swo_flush(*args, **kwargs)

Flushes data from the SWO buffer.

After this method is called, the flushed part of the SWO buffer is empty.

If `num_bytes` is not present, flushes all data currently in the SWO buffer.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `num_bytes` (`int`) – the number of bytes to flush

Returns None

Raises `JLinkException` – on error

swo_num_bytes(*args, **kwargs)

Retrieves the number of bytes in the SWO buffer.

Parameters `self` (`JLink`) – the `JLink` instance

Returns Number of bytes in the SWO buffer.

Raises `JLinkException` – on error

swo_read(*args, **kwargs)

Reads data from the SWO buffer.

The data read is not automatically removed from the SWO buffer after reading unless `remove` is True. Otherwise the callee must explicitly remove the data by calling `.swo_flush()`.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `offset` (`int`) – offset of first byte to be retrieved
- `num_bytes` (`int`) – number of bytes to read
- `remove` (`bool`) – if data should be removed from buffer after read

Returns A list of bytes read from the SWO buffer.

swo_read_stimulus(*args, **kwargs)

Reads the printable data via SWO.

This method reads SWO for one stimulus port, which is all printable data.

Note: Stimulus port 0 is used for `printf` debugging.

Parameters

- `self` (`JLink`) – the `JLink` instance

- **port** (*int*) – the stimulus port to read from, 0 –31
- **num_bytes** (*int*) – number of bytes to read

Returns A list of bytes read via SWO.

Raises `ValueError` – if `port < 0` or `port > 31`

swo_set_emu_buffer_size (**args*, ***kwargs*)

Sets the size of the buffer used by the J-Link to collect SWO data.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **buf_size** (*int*) – the new size of the emulator buffer

Returns `None`

Raises `JLinkException` – on error

swo_set_host_buffer_size (**args*, ***kwargs*)

Sets the size of the buffer used by the host to collect SWO data.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **buf_size** (*int*) – the new size of the host buffer

Returns `None`

Raises `JLinkException` – on error

swo_speed_info (**args*, ***kwargs*)

Retrieves information about the supported SWO speeds.

Parameters **self** (`JLink`) – the `JLink` instance

Returns A `JLinkSWOSpeedInfo` instance describing the target’s supported SWO speeds.

Raises `JLinkException` – on error

swo_start (**args*, ***kwargs*)

Starts collecting SWO data.

Note: If SWO is already enabled, it will first stop SWO before enabling it again.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **swo_speed** (*int*) – the frequency in Hz used by the target to communicate

Returns `None`

Raises `JLinkException` – on error

swo_stop (**args*, ***kwargs*)

Stops collecting SWO data.

Parameters **self** (`JLink`) – the `JLink` instance

Returns `None`

Raises `JLinkException` – on error

swo_supported_speeds (*args, **kwargs)

Retrieves a list of SWO speeds supported by both the target and the connected J-Link.

The supported speeds are returned in order from highest to lowest.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **cpu_speed** (`int`) – the target’s CPU speed in Hz
- **num_speeds** (`int`) – the number of compatible speeds to return

Returns A list of compatible SWO speeds in Hz in order from highest to lowest.

sync_firmware (*args, **kwargs)

Syncs the emulator’s firmware version and the DLL’s firmware.

This method is useful for ensuring that the firmware running on the J-Link matches the firmware supported by the DLL.

Parameters **self** (`JLink`) – the `JLink` instance

Returns `None`

target_connected ()

Returns whether a target is connected to the J-Link.

Parameters **self** (`JLink`) – the `JLink` instance

Returns `True` if a target is connected, otherwise `False`.

test ()

Performs a self test.

Parameters **self** (`JLink`) – the `JLink` instance

Returns `True` if test passed, otherwise `False`.

tif

Returns the current target interface of the J-Link.

Parameters **self** (`JLink`) – the `JLink` instance

Returns Integer specifying the current target interface.

trace_buffer_capacity (*args, **kwargs)

Retrieves the trace buffer’s current capacity.

Parameters **self** (`JLink`) – the `JLink` instance.

Returns The current capacity of the trace buffer. This is not necessarily the maximum possible size the buffer could be configured with.

trace_flush (*args, **kwargs)

Flushes the trace buffer.

After this method is called, the trace buffer is empty. This method is best called when the device is reset.

Parameters **self** (`JLink`) – the `JLink` instance.

Returns `None`

trace_format (*args, **kwargs)

Retrieves the current format the trace buffer is using.

Parameters `self` (`JLink`) – the `JLink` instance.

Returns The current format the trace buffer is using. This is one of the attributes of `JLinkTraceFormat`.

`trace_max_buffer_capacity` (`*args`, `**kwargs`)

Retrieves the maximum size the trace buffer can be configured with.

Parameters `self` (`JLink`) – the `JLink` instance.

Returns The maximum configurable capacity for the trace buffer.

`trace_min_buffer_capacity` (`*args`, `**kwargs`)

Retrieves the minimum capacity the trace buffer can be configured with.

Parameters `self` (`JLink`) – the `JLink` instance.

Returns The minimum configurable capacity for the trace buffer.

`trace_read` (`*args`, `**kwargs`)

Reads data from the trace buffer and returns it.

Parameters

- `self` (`JLink`) – the `JLink` instance.
- `offset` (`int`) – the offset from which to start reading from the trace buffer.
- `num_items` (`int`) – number of items to read from the trace buffer.

Returns A list of `JLinkTraceData` instances corresponding to the items read from the trace buffer. Note that this list may have size less than `num_items` in the event that there are not `num_items` items in the trace buffer.

Raises `JLinkException` – on error.

`trace_region` (`*args`, `**kwargs`)

Retrieves the properties of a trace region.

Parameters

- `self` (`JLink`) – the `JLink` instance.
- `region_index` (`int`) – the trace region index.

Returns An instance of `JLinkTraceRegion` describing the specified region.

`trace_region_count` (`*args`, `**kwargs`)

Retrieves a count of the number of available trace regions.

Parameters `self` (`JLink`) – the `JLink` instance.

Returns Count of the number of available trace regions.

`trace_sample_count` (`*args`, `**kwargs`)

Retrieves the number of samples in the trace buffer.

Parameters `self` (`JLink`) – the `JLink` instance.

Returns Number of samples in the trace buffer.

`trace_set_buffer_capacity` (`*args`, `**kwargs`)

Sets the capacity for the trace buffer.

Parameters

- `self` (`JLink`) – the `JLink` instance.

- **size** (*int*) – the new capacity for the trace buffer.

Returns None

trace_set_format (**args, **kwargs*)

Sets the format for the trace buffer to use.

Parameters

- **self** (*JLink*) – the JLink instance.
- **fmt** (*int*) – format for the trace buffer; this is one of the attributes of *JLinkTraceFormat*.

Returns None

trace_start (**args, **kwargs*)

Starts collecting trace data.

Parameters **self** (*JLink*) – the JLink instance.

Returns None

trace_stop (**args, **kwargs*)

Stops collecting trace data.

Parameters **self** (*JLink*) – the JLink instance.

Returns None

unlock (**args, **kwargs*)

Unlocks the device connected to the J-Link.

Unlocking a device allows for access to read/writing memory, as well as flash programming.

Note: Unlock is not supported on all devices.

Supported Devices: Kinetis

Returns True.

Raises *JLinkException* – if the device fails to unlock.

update_firmware (**args, **kwargs*)

Performs a firmware update.

If there is a newer version of firmware available for the J-Link device, then updates the firmware.

Parameters **self** (*JLink*) – the JLink instance

Returns Checksum of the new firmware on update, 0 if the firmware was not changed.

version

Returns the device's version.

The device's version is returned as a string of the format: M.mr where M is major number, m is minor number, and r is revision character.

Parameters **self** (*JLink*) – the JLink instance

Returns Device version string.

warning_handler

Returns the warning handler function.

Parameters `self` (`JLink`) – the `JLink` instance

Returns `None` if the warning handler was not set, otherwise a `ctypes.CFUNCTYPE`.

watchpoint_clear (`*args`, `**kwargs`)

Clears the watchpoint with the specified handle.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `handle` (`int`) – the handle of the watchpoint

Returns `True` if watchpoint was removed, otherwise `False`.

watchpoint_clear_all (`*args`, `**kwargs`)

Removes all watchpoints that have been set.

Parameters `self` (`JLink`) – the `JLink` instance

Returns `True` if they were cleared, otherwise `False`.

watchpoint_info (`*args`, `**kwargs`)

Returns information about the specified watchpoint.

Note: Either `handle` or `index` can be specified. If the `index` is not provided, the `handle` must be set, and vice-versa. If both `index` and `handle` are provided, the `index` overrides the provided `handle`.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `handle` (`int`) – optional handle of a valid watchpoint.
- `index` (`int`) – optional index of a watchpoint.

Returns An instance of `JLinkWatchpointInfo` specifying information about the watchpoint if the watchpoint was found, otherwise `None`.

Raises

- `JLinkException` – on error.
- `ValueError` – if both `handle` and `index` are invalid.

watchpoint_set (`*args`, `**kwargs`)

Sets a watchpoint at the given address.

This method allows for a watchpoint to be set on an given address or range of addresses. The watchpoint can then be triggered if the data at the given address matches the specified `data` or range of data as determined by `data_mask`, on specific access size events, reads, writes, or privileged accesses.

Both `addr_mask` and `data_mask` are used to specify ranges. Bits set to 1 are masked out and not taken into consideration when comparison against an address or data value. E.g. an `addr_mask` with a value of `0x1` and `addr` with value `0xdeadbeef` means that the watchpoint will be set on addresses `0xdeadbeef` and `0xdeadbeee`. If the data was `0x11223340` and the given `data_mask` has a value of `0x0000000F`, then the watchpoint would trigger for data matching `0x11223340-0x1122334F`.

Note: If both `read` and `write` are specified, then the watchpoint will trigger on both read and write events to the given address.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **addr_mask** (`int`) – optional mask to use for determining which address the watchpoint should be set on
- **data** (`int`) – optional data to set the watchpoint on in order to have the watchpoint triggered when the value at the specified address matches the given `data`
- **data_mask** (`int`) – optional mask to use for determining the range of data on which the watchpoint should be triggered
- **access_size** (`int`) – if specified, this must be one of `{8, 16, 32}` and determines the access size for which the watchpoint should trigger
- **read** (`bool`) – if `True`, triggers the watchpoint on read events
- **write** (`bool`) – if `True`, triggers the watchpoint on write events
- **privileged** (`bool`) – if `True`, triggers the watchpoint on privileged accesses

Returns The handle of the created watchpoint.

Raises

- `ValueError` – if an invalid access size is given.
- `JLinkException` – if the watchpoint fails to be set.

Protocols

The J-Link has multiple ways of communicating with a target: Serial Wire Debug (SWD), Serial Wire Output (SWO), Memory, Coresight, Registers, etc. For some of these communication methods, there is a specific protocol that defines how the communication takes place.

This module provides definitions to facilitate communicating over the different protocols. All the methods use a `JLink` instance, but take care of the housekeeping work involved with each protocol.

5.1 Serial Wire Debug (SWD)

This subsection defines the classes and methods needed to use the SWD protocol.

class `pylink.protocols.swd.ReadRequest` (*address, ap*)

Bases: `pylink.protocols.swd.Request`

Definition for a SWD (Serial Wire Debug) Read Request.

send (*jlink*)

Starts the SWD transaction.

Steps for a Read Transaction:

1. First phase in which the request is sent.
2. Second phase in which an ACK is received. This phase consists of three bits. An OK response has the value 1.
3. Once the ACK is received, the data phase can begin. Consists of 32 data bits followed by 1 parity bit calculated based on all 32 data bits.
4. After the data phase, the interface must be clocked for at least eight cycles to clock the transaction through the SW-DP; this is done by reading an additional eight bits (eight clocks).

Parameters

- **self** (`ReadRequest`) – the `ReadRequest` instance
- **jlink** (`JLink`) – the `JLink` instance to use for write/read

Returns An `Response` instance.

class `pylink.protocols.swd.Request` (*address, ap, data=None*)

Bases: `_ctypes.Union`

Definition of a SWD (Serial Wire Debug) Request.

An SWD Request is composed of 8 bits.

start

the start bit is always one

ap_dp

indicates whether the transaction is DP (0) or AP (1).

read_write

indicates if the transaction is a read-access (1) or a write-access (0).

address

parity

the parity bit, the bit is used by the target to verify the integrity of the request. Should be 1 if bits 1-4 contain an odd number of 1's, otherwise 0.

stop

the stop bit, should always be zero.

park

the park bit, should always be one.

value

the overall value of the request.

addr2

Structure/Union member

addr3

Structure/Union member

ap_dp

Structure/Union member

bit

Structure/Union member

parity

Structure/Union member

park

Structure/Union member

read_write

Structure/Union member

send (*jlink*)

Starts the SWD transaction.

Sends the request and receives an ACK for the request.

Parameters

- **self** (*Request*) – the Request instance
- **jlink** (*JLink*) – the JLink instance to use for write/read

Returns The bit position of the ACK response.

start

Structure/Union member

stop

Structure/Union member

value
Structure/Union member

class `pylink.protocols.swd.RequestBits`

Bases: `_ctypes.Structure`

SWD request bits.

addr2
Structure/Union member

addr3
Structure/Union member

ap_dp
Structure/Union member

parity
Structure/Union member

park
Structure/Union member

read_write
Structure/Union member

start
Structure/Union member

stop
Structure/Union member

class `pylink.protocols.swd.Response` (*status, data=None*)

Bases: `object`

Response class to hold the response from the send of a SWD request.

STATUS_ACK = 1

STATUS_FAULT = 4

STATUS_INVALID = -1

STATUS_WAIT = 2

ack()
Returns whether the response was ACK'd.

Parameters `self` (`Response`) – the `Response` instance

Returns `True` if response was ACK'd, otherwise `False`.

fault()
Returns whether the response exited with fault.

Parameters `self` (`Response`) – the `Response` instance

Returns `True` if response exited with a fault, otherwise `False`.

invalid()
Returns whether the response exited with a bad result.

This occurs when the parity is invalid.

Parameters `self` (`Response`) – the `Response` instance

Returns `True` if the parity checked failed, otherwise `False`.

wait()

Returns whether the response was a wait.

Parameters **self** (*Response*) – the *Response* instance

Returns True if response exited with wait, otherwise False.

class `pylink.protocols.swd.WriteRequest` (*address, ap, data*)

Bases: `pylink.protocols.swd.Request`

Definition for a SWD (Serial Wire Debug) Write Request.

send (*jlink*)

Starts the SWD transaction.

Steps for a Write Transaction:

1. First phase in which the request is sent.
2. Second phase in which an ACK is received. This phase consists of three bits. An OK response has the value 1.
3. Everytime the SWD IO may change directions, a turnaround phase is inserted. For reads, this happens after the data phase, while for writes this happens after between the acknowledge and data phase, so we have to do the turnaround before writing data. This phase consists of two bits.
4. Write the data and parity bits.

Parameters

- **self** (*WriteRequest*) – the *WriteRequest* instance
- **jlink** (*JLink*) – the *JLink* instance to use for write/read

Returns An *Response* instance.

Unlocking

Sometimes a user error may result in a device becoming **locked**. When a device is locked, it's memory cannot be written to, nor can it's memory be read from. This is a security feature in many MCUs.

This module provides functions for unlocking a locked device.

Note: Unlocking a device results in a mass-erase. Do not unlock a device if you do not want it be erased.

`pylink.unlockers.unlock(jlink, name)`
Unlocks a J-Link's target device.

Parameters

- **jlink** (`JLink`) – the connected J-Link device
- **name** (`str`) – the MCU name (e.g. Kinetis)

Supported Names:

- Kinetis

Returns `True` if the device was unlocked, otherwise `False`.

Raises `NotImplementedError` – if no unlock method exists for the MCU.

`pylink.unlockers.unlock_kinetis.unlock_kinetis(*args, **kwargs)`
Unlock for Freescale Kinetis K40 or K60 device.

Parameters **jlink** (`JLink`) – an instance of a J-Link that is connected to a target.

Returns `True` if the device was successfully unlocked, otherwise `False`.

Raises `ValueError` – if the J-Link is not connected to a target.

Bindings

The native J-Link SDK is a C library. PyLink makes use of `ctypes` to interface with the library, and as such implements native Python structure bindings, and constants for values returned by the C SDK.

7.1 Structures

class `pylink.structs.JLinkBreakpointInfo`

Bases: `_ctypes.Structure`

Class representing information about a breakpoint.

SizeOfStruct

the size of the structure (this should not be modified).

Handle

breakpoint handle.

Addr

address of where the breakpoint has been set.

Type

type flags which were specified when the breakpoint was created.

ImpFlags

describes the current state of the breakpoint.

UseCnt

describes how often the breakpoint is set at the same address.

Addr

Structure/Union member

Handle

Structure/Union member

ImpFlags

Structure/Union member

SizeOfStruct

Structure/Union member

Type

Structure/Union member

UseCnt

Structure/Union member

hardware_breakpoint ()

Returns whether this is a hardware breakpoint.

Parameters **self** (`JLinkBreakpointInfo`) – the `JLinkBreakpointInfo` instance**Returns** `True` if the breakpoint is a hardware breakpoint, otherwise `False`.**pending ()**

Returns if this breakpoint is pending.

Parameters **self** (`JLinkBreakpointInfo`) – the `JLinkBreakpointInfo` instance**Returns** `True` if the breakpoint is still pending, otherwise `False`.**software_breakpoint ()**

Returns whether this is a software breakpoint.

Parameters **self** (`JLinkBreakpointInfo`) – the `JLinkBreakpointInfo` instance**Returns** `True` if the breakpoint is a software breakpoint, otherwise `False`.**class** `pylink.structs.JLinkConnectInfo`Bases: `_ctypes.Structure`

J-Link connection info structure.

SerialNumber

J-Link serial number.

Connectiontype of connection (e.g. `enums.JLinkHost.USB`)**USBAddr**

USB address if connected via USB.

aIPAddr

IP address if connected via IP.

Time

Time period (ms) after which UDP discover answer was received.

Time_us

Time period (uS) after which UDP discover answer was received.

HWVersion

Hardware version of J-Link, if connected via IP.

abMACAddr

MAC Address, if connected via IP.

acProduct

Product name, if connected via IP.

acNickname

Nickname, if connected via IP.

acFWString

Firmware string, if connected via IP.

IsDHCPAssignedIP

Is IP address reception via DHCP.

IsDHCPAssignedIPsValid

True if connected via IP.

NumIPConnections

Number of IP connections currently established.

NumIPConnectionsIsValid

True if connected via IP.

aPadding

Bytes reserved for future use.

Connection

Structure/Union member

HWVersion

Structure/Union member

IsDHCPAssignedIP

Structure/Union member

IsDHCPAssignedIPsValid

Structure/Union member

NumIPConnections

Structure/Union member

NumIPConnectionsIsValid

Structure/Union member

SerialNumber

Structure/Union member

Time

Structure/Union member

Time_us

Structure/Union member

USBAddr

Structure/Union member

aIPAddr

Structure/Union member

aPadding

Structure/Union member

abMACAddr

Structure/Union member

acFWString

Structure/Union member

acNickname

Structure/Union member

acProduct

Structure/Union member

class `pylink.structs.JLinkDataEvent`

Bases: `_ctypes.Structure`

Class representing a data event.

A data may halt the CPU, trigger SWO output, or trigger trace output.

SizeOfStruct

the size of the structure (this should not be modified).

Type

the type of the data event (this should not be modified).

Addr

the address on which the watchpoint was set

AddrMask

the address mask used for comparison.

Data

the data on which the watchpoint has been set.

DataMask

the data mask used for comparison.

Access

the control data on which the event has been set.

AccessMask

the control mask used for comparison.

Access

Structure/Union member

AccessMask

Structure/Union member

Addr

Structure/Union member

AddrMask

Structure/Union member

Data

Structure/Union member

DataMask

Structure/Union member

SizeOfStruct

Structure/Union member

Type

Structure/Union member

```
class pylink.structs.JLinkDeviceInfo(*args, **kwargs)
```

```
    Bases: _ctypes.Structure
```

J-Link device information.

This structure is used to represent a device that is supported by the J-Link.

SizeOfStruct

Size of the struct (DO NOT CHANGE).

sName

name of the device.

CoreId

core identifier of the device.

FlashAddr

base address of the internal flash of the device.

RAMAddr

base address of the internal RAM of the device.

EndianMode

the endian mode of the device (0 -> only little endian, 1 -> only big endian, 2 -> both).

FlashSize

total flash size in bytes.

RAMSize

total RAM size in bytes.

sManu

device manufacturer.

aFlashArea

a list of `JLinkFlashArea` instances.

aRamArea

a list of `JLinkRAMArea` instances.

Core

CPU core.

Core

Structure/Union member

CoreId

Structure/Union member

EndianMode

Structure/Union member

FlashAddr

Structure/Union member

FlashSize

Structure/Union member

RAMAddr

Structure/Union member

RAMSize

Structure/Union member

SizeofStruct

Structure/Union member

aFlashArea

Structure/Union member

aRAMArea

Structure/Union member

manufacturer

Returns the name of the manufacturer of the device.

Parameters `self` (`JLinkDeviceInfo`) – the `JLinkDeviceInfo` instance

Returns Manufacturer name.

name

Returns the name of the device.

Parameters **self** (`JLinkDeviceInfo`) – the `JLinkDeviceInfo` instance

Returns Device name.

sManu

Structure/Union member

sName

Structure/Union member

class `pylink.structs.JLinkFlashArea`

Bases: `_ctypes.Structure`

Definition for a region of Flash.

Addr

address where the flash area starts.

Size

size of the flash area.

Addr

Structure/Union member

Size

Structure/Union member

class `pylink.structs.JLinkGPIDescriptor`

Bases: `_ctypes.Structure`

Definition for the structure that details the name and capabilities of a user-controllable GPIO.

acName

name of the GPIO.

Caps

bitfield of capabilities.

Caps

Structure/Union member

acName

Structure/Union member

class `pylink.structs.JLinkHardwareStatus`

Bases: `_ctypes.Structure`

Definition for the hardware status information for a J-Link.

VTarget

target supply voltage.

tck

measured state of TCK pin.

tdi

measured state of TDI pin.

tdo

measured state of TDO pin.

tms
measured state of TMS pin.

tres
measured state of TRES pin.

trst
measured state of TRST pin.

VTarget
Structure/Union member

tck
Structure/Union member

tdi
Structure/Union member

tdo
Structure/Union member

tms
Structure/Union member

tres
Structure/Union member

trst
Structure/Union member

voltage
Returns the target supply voltage.
This is an alias for `.VTarget`.

Parameters **self** (*JLinkHardwareStatus*) – the *JLinkHardwareStatus* instance

Returns Target supply voltage as an integer.

class `pylink.structs.JLinkMOEInfo`

Bases: `_ctypes.Structure`

Structure representing the Method of Debug Entry (MOE).

The method of debug entry is a reason for which a CPU has stopped. At any given time, there may be multiple methods of debug entry.

HaltReason
reason why the CPU stopped.

Index
if cause of CPU stop was a code/data breakpoint, this identifies the index of the code/data breakpoint unit which causes the CPU to stop, otherwise it is `-1`.

HaltReason
Structure/Union member

Index
Structure/Union member

code_breakpoint ()
Returns whether this a code breakpoint.

Parameters **self** (*JLinkMOEInfo*) – the *JLinkMOEInfo* instance

Returns True if this is a code breakpoint, otherwise False.

data_breakpoint ()

Returns whether this a data breakpoint.

Parameters **self** (*JLinkMOEInfo*) – the *JLinkMOEInfo* instance

Returns True if this is a data breakpoint, otherwise False.

dbgrq ()

Returns whether this a DBGRQ.

Parameters **self** (*JLinkMOEInfo*) – the *JLinkMOEInfo* instance

Returns True if this is a DBGRQ, otherwise False.

vector_catch ()

Returns whether this a vector catch.

Parameters **self** (*JLinkMOEInfo*) – the *JLinkMOEInfo* instance

Returns True if this is a vector catch, otherwise False.

class *pylink.structs.JLinkMemoryZone*

Bases: *_ctypes.Structure*

Represents a CPU memory zone.

sName

initials of the memory zone.

sDesc

name of the memory zone.

VirtAddr

start address of the virtual address space of the memory zone.

abDummy

reserved for future use.

VirtAddr

Structure/Union member

abDummy

Structure/Union member

name

Alias for the memory zone name.

Parameters **self** (*JLinkMemoryZone*) – the *JLinkMemoryZone* instance

Returns The memory zone name.

sDesc

Structure/Union member

sName

Structure/Union member

class *pylink.structs.JLinkRAMArea*

Bases: *pylink.structs.JLinkFlashArea*

Definition for a region of RAM.

Addr

address where the flash area starts.

Size
size of the flash area.

class `pylink.structs.JLinkRTTerminalBufDesc`

Bases: `_ctypes.Structure`

Structure describing a RTT buffer.

BufferIndex
index of the buffer to request information about.

Direction
direction of the upper (*0* for up, *1* for Down).

acName
Name of the buffer.

SizeOfBuffer
size of the buffer in bytes.

Flags
flags set on the buffer.

BufferIndex
Structure/Union member

Direction
Structure/Union member

Flags
Structure/Union member

SizeOfBuffer
Structure/Union member

acName
Structure/Union member

down
Returns a boolean indicating if the buffer is an 'DOWN' buffer.

Parameters `self` (`JLinkRTTerminalBufDesc`) – the terminal buffer descriptor.

Returns `True` if the buffer is an 'DOWN' buffer, otherwise `False`.

name
Returns the name of the buffer.

Parameters `self` (`JLinkRTTerminalBufDesc`) – the terminal buffer descriptor.

Returns String name of the buffer.

up
Returns a boolean indicating if the buffer is an 'UP' buffer.

Parameters `self` (`JLinkRTTerminalBufDesc`) – the terminal buffer descriptor.

Returns `True` if the buffer is an 'UP' buffer, otherwise `False`.

class `pylink.structs.JLinkRTTerminalStart`

Bases: `_ctypes.Structure`

Structure used to configure an RTT instance.

ConfigBlockAddress
Address of the RTT block.

ConfigBlockAddress
Structure/Union member

Reserved
Structure/Union member

class `pylink.structs.JLinkRTTTerminalStatus`

Bases: `_ctypes.Structure`

Structure describing the status of the RTT terminal.

NumBytesTransferred
number of bytes sent to the client application.

NumBytesRead
number of bytes read from the target.

HostOverflowCount
number of overflows on the host.

IsRunning
if RTT is running.

NumUpBuffers
number of 'UP' buffers.

NumDownBuffers
number of 'DOWN' buffers.

HostOverflowCount
Structure/Union member

IsRunning
Structure/Union member

NumBytesRead
Structure/Union member

NumBytesTransferred
Structure/Union member

NumDownBuffers
Structure/Union member

NumUpBuffers
Structure/Union member

Reserved
Structure/Union member

class `pylink.structs.JLinkSWOSpeedInfo`

Bases: `_ctypes.Structure`

Structure representing information about target's supported SWO speeds.

To calculate the supported SWO speeds, the base frequency is taken and divide by a number in the range of [`MinDiv`,`MaxDiv`].

SizeofStruct
size of the structure.

Interface
interface type for the speed information.

BaseFreq

base frequency (Hz) used to calculate supported SWO speeds.

MinDiv

minimum divider allowed to divide the base frequency.

MaxDiv

maximum divider allowed to divide the base frequency.

MinPrescale

minimum prescaler allowed to adjust the base frequency.

MaxPrescale

maximum prescaler allowed to adjust the base frequency.

Note: You should *never* change `.SizeofStruct` or `.Interface`.

BaseFreq

Structure/Union member

Interface

Structure/Union member

MaxDiv

Structure/Union member

MaxPrescale

Structure/Union member

MinDiv

Structure/Union member

MinPrescale

Structure/Union member

SizeofStruct

Structure/Union member

class `pylink.structs.JLinkSWOStartInfo`

Bases: `_ctypes.Structure`

Represents configuration information for collecting Serial Wire Output (SWO) information.

SizeofStruct

size of the structure.

Interface

the interface type used for SWO.

Speed

the frequency used for SWO communication in Hz.

Note: You should *never* change `.SizeofStruct` or `.Interface`.

Interface

Structure/Union member

SizeofStruct

Structure/Union member

Speed

Structure/Union member

class `pylink.structs.JLinkSpeedInfo`

Bases: `_ctypes.Structure`

Represents information about an emulator's supported speeds.

The emulator can support all target interface speeds calculated by dividing the base frequency by atleast `MinDiv`.

SizeOfStruct

the size of this structure.

BaseFreq

Base frequency (in HZ) used to calculate supported speeds.

MinDiv

minimum divider allowed to divide the base frequency.

SupportAdaptive

1 if emulator supports adaptive clocking, otherwise 0.

BaseFreq

Structure/Union member

MinDiv

Structure/Union member

SizeOfStruct

Structure/Union member

SupportAdaptive

Structure/Union member

class `pylink.structs.JLinkStraceEventInfo`

Bases: `_ctypes.Structure`

Class representing the STRACE event information.

SizeOfStruct

size of the structure.

Type

type of event.

Op

the STRACE operation to perform.

AccessSize

access width for trace events.

Reserved0

reserved.

Addr

specifies the load/store address for data.

Data

the data to be compared for the operation for data access events.

DataMask

bitmask for bits of data to omit in comparison for data access events.

AddrRangeSize
address range for range events.

AccessSize
Structure/Union member

Addr
Structure/Union member

AddrRangeSize
Structure/Union member

Data
Structure/Union member

DataMask
Structure/Union member

Op
Structure/Union member

Reserved0
Structure/Union member

SizeOfStruct
Structure/Union member

Type
Structure/Union member

class `pylink.structs.JLinkTraceData`

Bases: `_ctypes.Structure`

Structure representing trace data returned by the trace buffer.

PipeStat
type of trace data.

Sync
sync point in buffer.

Packet
trace data packet.

Packet
Structure/Union member

PipeStat
Structure/Union member

Sync
Structure/Union member

branch ()
Returns whether the data corresponds to a branch execution.

Parameters `self` (`JLinkTraceData`) – the `JLinkTraceData` instance.

Returns `True` if this is trace data for a branch execution.

data_branch ()
Returns whether the data corresponds to a branch with data.

Parameters `self` (`JLinkTraceData`) – the `JLinkTraceData` instance.

Returns True if this is trace data for a branch with data.

data_instruction()

Returns whether the data corresponds to an data instruction.

Parameters **self** (`JLinkTraceData`) – the `JLinkTraceData` instance.

Returns True if this is trace data for an data instruction.

instruction()

Returns whether the data corresponds to an executed instruction.

Parameters **self** (`JLinkTraceData`) – the `JLinkTraceData` instance.

Returns True if this is trace data for an executed instruction.

non_instruction()

Returns whether the data corresponds to an un-executed instruction.

Parameters **self** (`JLinkTraceData`) – the `JLinkTraceData` instance.

Returns True if this is trace data for an un-executed instruction.

trace_disabled()

Returns whether the data corresponds to trace being disabled.

Parameters **self** (`JLinkTraceData`) – the `JLinkTraceData` instance.

Returns True if this is trace data for the trace disabled event.

trigger()

Returns whether the data corresponds to a trigger event.

Parameters **self** (`JLinkTraceData`) – the `JLinkTraceData` instance.

Returns True if this is trace data for a trigger event.

wait()

Returns whether the data corresponds to a wait.

Parameters **self** (`JLinkTraceData`) – the `JLinkTraceData` instance.

Returns True if this is trace data for a wait.

class `pylink.structs.JLinkTraceRegion`

Bases: `_ctypes.Structure`

Structure describing a trace region.

SizeOfStruct

size of the structure.

RegionIndex

index of the region.

NumSamples

number of samples in the region.

Off

offset in the trace buffer.

RegionCnt

number of trace regions.

Dummy

unused.

Timestamp
timestamp of last event written to buffer.

Dummy
Structure/Union member

NumSamples
Structure/Union member

Off
Structure/Union member

RegionCnt
Structure/Union member

RegionIndex
Structure/Union member

SizeOfStruct
Structure/Union member

Timestamp
Structure/Union member

class `pylink.structs.JLinkWatchpointInfo`
Bases: `_ctypes.Structure`

Class representing information about a watchpoint.

SizeOfStruct
the size of the structure (this should not be modified).

Handle
the watchpoint handle.

Addr
the address the watchpoint was set at.

AddrMask
the address mask used for comparison.

Data
the data on which the watchpoint was set.

DataMask
the data mask used for comparison.

Ctrl
the control data on which the breakpoint was set.

CtrlMask
the control mask used for comparison.

WPUnit
the index of the watchpoint unit.

Addr
Structure/Union member

AddrMask
Structure/Union member

Ctrl
Structure/Union member

CtrlMask
Structure/Union member

Data
Structure/Union member

DataMask
Structure/Union member

Handle
Structure/Union member

SizeOfStruct
Structure/Union member

WPUnit
Structure/Union member

7.2 Enumerations

class `pylink.enums.JLinkAccessFlags`

Bases: object

J-Link access types for data events.

These access types allow specifying the different types of access events that should be monitored.

READ
specifies to monitor read accesses.

WRITE
specifies to monitor write accesses.

PRIVILEGED
specifies to monitor privileged accesses.

SIZE_8BIT
specifies to monitor an 8-bit access width.

SIZE_16BIT
specifies to monitor an 16-bit access width.

SIZE_32BIT
specifies to monitor an 32-bit access width.

PRIV = 16

READ = 0

SIZE_16BIT = 2

SIZE_32BIT = 4

SIZE_8BIT = 0

WRITE = 1

class `pylink.enums.JLinkAccessMaskFlags`

Bases: object

J-Link access mask flags.

SIZE
specifies to not care about the access size of the event.

DIR
specifies to not care about the access direction of the event.

PRIV
specifies to not care about the access privilege of the event.

DIR = 1

PRIV = 16

SIZE = 6

class `pylink.enums.JLinkBreakpoint`

Bases: `object`

J-Link breakpoint types.

SW_RAM
Software breakpoint located in RAM.

SW_FLASH
Software breakpoint located in flash.

SW
Software breakpoint located in RAM or flash.

HW
Hardware breakpoint.

ANY
Allows specifying any time of breakpoint.

ARM
Breakpoint in ARM mode (only available on ARM 7/9 cores).

THUMB
Breakpoint in THUMB mode (only available on ARM 7/9 cores).

ANY = 4294967280

ARM = 1

HW = 4294967040

SW = 240

SW_FLASH = 32

SW_RAM = 16

THUMB = 2

class `pylink.enums.JLinkBreakpointImplementation`

Bases: `object`

J-Link breakpoint implementation types.

HARD
Hardware breakpoint using a breakpoint unit.

SOFT
Software breakpoint using a breakpoint instruction.

PENDING

Breakpoint has not been set yet.

FLASH

Breakpoint set in flash.

FLASH = 16

HARD = 1

PENDING = 4

SOFT = 2

class `pylink.enums.JLinkCPUCapabilities`

Bases: `object`

Target CPU Capabilities.

DCC = 16384

GO = 32

HALT = 128

HSS = 32768

IS_HALTED = 256

READ_MEMORY = 2

READ_REGISTERS = 8

RESET = 512

RUN_STOP = 1024

STEP = 64

TERMINAL = 2048

WRITE_MEMORY = 4

WRITE_REGISTERS = 16

class `pylink.enums.JLinkCore`

Bases: `object`

Enumeration for the different CPU core identifiers.

These are the possible cores for targets the J-Link is connected to. Note that these are bitfields.

ANY = 4294967295

ARM11 = 201326591

ARM1136 = 188153855

ARM1136J = 188089087

ARM1136JF = 188090111

ARM1136JF_S = 188090367

ARM1136J_S = 188089343

ARM1156 = 190251007

ARM1176 = 192348159

ARM1176J = 192283391
ARM1176JF = 192284415
ARM1176JF_S = 192284671
ARM1176J_S = 192283647
ARM7 = 134217727
ARM7TDMI = 117440767
ARM7TDMI_R3 = 117440575
ARM7TDMI_R4 = 117440591
ARM7TDMI_S = 117441023
ARM7TDMI_S_R3 = 117440831
ARM7TDMI_S_R4 = 117440847
ARM9 = 167772159
ARM920T = 153092351
ARM922T = 153223423
ARM926EJ_S = 153485823
ARM946E_S = 155582975
ARM966E_S = 157680127
ARM968E_S = 157811199
ARM9TDMI_S = 150995455
CIP51 = 302055423
COLDFIRE = 50331647
CORTEX_A12 = 134873343
CORTEX_A15 = 134938879
CORTEX_A17 = 135004415
CORTEX_A5 = 251658495
CORTEX_A7 = 134742271
CORTEX_A8 = 134217983
CORTEX_A9 = 134807807
CORTEX_M0 = 100663551
CORTEX_M1 = 16777471
CORTEX_M3 = 50331903
CORTEX_M3_R1P0 = 50331664
CORTEX_M3_R1P1 = 50331665
CORTEX_M3_R2P0 = 50331680
CORTEX_M4 = 234881279
CORTEX_M7 = 234946815

CORTEX_M_V8BASEL = 100729087
CORTEX_M_V8MAINL = 235012351
CORTEX_R4 = 201326847
CORTEX_R5 = 201392383
EFM8_UNSPEC = 318767103
MIPS = 301989887
MIPS_M4K = 285278207
MIPS_MICROAPTIV = 285343743
NONE = 0
POWER_PC = 285212671
POWER_PC_N1 = 285147391
POWER_PC_N2 = 285147647
RX = 234881023
RX110 = 220332031
RX111 = 220266495
RX113 = 220397567
RX210 = 219217919
RX21A = 219283455
RX220 = 219348991
RX230 = 219414527
RX231 = 219480063
RX23T = 219545599
RX610 = 218169343
RX621 = 218562559
RX62G = 218628095
RX62N = 218234879
RX62T = 218300415
RX630 = 218431487
RX631 = 218693631
RX63N = 218365951
RX63T = 218497023
RX64M = 221315071
RX71M = 221380607
SIM = 83886079
XSCALE = 100663295

```
class pylink.enums.JLinkDataErrors
    Bases: pylink.enums.JLinkGlobalErrors

    Enumeration for the error codes generated when setting a data event.

    ERROR_INVALID_ACCESS_MASK = 2147483776

    ERROR_INVALID_ADDR_MASK = 2147483680

    ERROR_INVALID_DATA_MASK = 2147483712

    ERROR_NO_MORE_ADDR_COMP = 2147483650

    ERROR_NO_MORE_DATA_COMP = 2147483652

    ERROR_NO_MORE_EVENTS = 2147483649

    ERROR_UNKNOWN = 2147483648

    classmethod to_string (error_code)
        Returns the string message for the given error code.

        Parameters
            • cls (JLinkDataErrors) – the JLinkDataErrors class
            • error_code (int) – error code to convert

        Returns An error string corresponding to the error code.

        Raises ValueError – if the error code is invalid.
```

```
class pylink.enums.JLinkDeviceFamily
    Bases: object

    Enumeration for the difference device families.

    These are the possible device families for targets that the J-Link is connected to.

    ANY = 255

    ARM10 = 10

    ARM11 = 11

    ARM7 = 7

    ARM9 = 9

    AUTO = 0

    COLDFIRE = 2

    CORTEX_A5 = 15

    CORTEX_A8 = 8

    CORTEX_A9 = 8

    CORTEX_M0 = 6

    CORTEX_M1 = 1

    CORTEX_M3 = 3

    CORTEX_M4 = 14

    CORTEX_R4 = 12

    EFM8 = 18
```

MIPS = 17

POWERPC = 16

RX = 13

SIMULATOR = 4

XSCALE = 5

class `pylink.enums.JLinkEraseErrors`

Bases: `pylink.enums.JLinkGlobalErrors`

Enumeration for the error codes generated during an erase operation.

ILLEGAL_COMMAND = -5

classmethod `to_string(error_code)`

Returns the string message for the given `error_code`.

Parameters

- **cls** (`JLinkEraseErrors`) – the `JLinkEraseErrors` class
- **error_code** (`int`) – error code to convert

Returns An error string corresponding to the error code.

Raises `ValueError` – if the error code is invalid.

class `pylink.enums.JLinkEventTypes`

Bases: `object`

J-Link data event types.

BREAKPOINT

breakpoint data event.

BREAKPOINT = 1

class `pylink.enums.JLinkFlags`

Bases: `object`

Enumeration for the different flags that are passed to the J-Link C SDK API methods.

DLG_BUTTON_CANCEL = 8

DLG_BUTTON_NO = 2

DLG_BUTTON_OK = 4

DLG_BUTTON_YES = 1

GO_OVERSTEP_BP = 1

HW_PIN_STATUS_HIGH = 1

HW_PIN_STATUS_LOW = 0

HW_PIN_STATUS_UNKNOWN = 255

class `pylink.enums.JLinkFlashErrors`

Bases: `pylink.enums.JLinkGlobalErrors`

Enumeration for the error codes generated during a flash operation.

COMPARE_ERROR = -2

PROGRAM_ERASE_ERROR = -3

VERIFICATION_ERROR = -4

classmethod `to_string` (*error_code*)

Returns the string message for the given `error_code`.

Parameters

- **cls** (`JLinkFlashErrors`) – the `JLinkFlashErrors` class
- **error_code** (*int*) – error code to convert

Returns An error string corresponding to the error code.

Raises `ValueError` – if the error code is invalid.

class `pylink.enums.JLinkFunctions`

Bases: `object`

Collection of function prototype and type builders for the J-Link SDK API calls.

FLASH_PROGRESS_PROTOTYPE

alias of `CFunctionType`

LOG_PROTOTYPE

alias of `CFunctionType`

UNSECURE_HOOK_PROTOTYPE

alias of `CFunctionType`

class `pylink.enums.JLinkGlobalErrors`

Bases: `object`

Enumeration for the error codes which any J-Link SDK DLL API-function can have as a return value.

CPU_IN_LOW_POWER_MODE = -274

DEVICE_FEATURE_NOT_SUPPORTED = -271

DLL_NOT_OPEN = -258

EMU_COMM_ERROR = -257

EMU_FEATURE_UNSUPPORTED = -262

EMU_NO_CONNECTION = -256

EMU_NO_MEMORY = -263

FLASH_PROG_COMPARE_FAILED = -265

FLASH_PROG_PROGRAM_FAILED = -266

FLASH_PROG_VERIFY_FAILED = -267

INVALID_HANDLE = -260

NO_CPU_FOUND = -261

NO_TARGET_DEVICE_SELECTED = -273

OPEN_FILE_FAILED = -268

TIF_STATUS_ERROR = -264

UNKNOWN_FILE_FORMAT = -269

UNSPECIFIED_ERROR = -1

VCC_FAILURE = -259

WRITE_TARGET_MEMORY_FAILED = -270

WRONG_USER_CONFIG = -272

classmethod to_string (*error_code*)

Returns the string message for the given *error_code*.

Parameters

- **cls** (*JlinkGlobalErrors*) – the *JlinkGlobalErrors* class
- **error_code** (*int*) – error code to convert

Returns An error string corresponding to the error code.

Raises *ValueError* – if the error code is invalid.

class `pylink.enums.JLinkHaltReasons`

Bases: `object`

Halt reasons for the CPU.

DBGREQ

CPU has been halted because DBGREQ signal asserted.

CODE_BREAKPOINT

CPU has been halted because of code breakpoint match.

DATA_BREAKPOINT

CPU has been halted because of data breakpoint match.

VECTOR_CATCH

CPU has been halted because of vector catch.

CODE_BREAKPOINT = 1

DATA_BREAKPOINT = 2

DBGREQ = 0

VECTOR_CATCH = 3

class `pylink.enums.JLinkHost`

Bases: `object`

Enumeration for the different JLink hosts: currently only IP and USB.

IP = 2

USB = 1

USB_OR_IP = 3

class `pylink.enums.JLinkInterfaces`

Bases: `object`

Target interfaces for the J-Link.

C2 = 6

FINE = 3

ICSP = 4

JTAG = 0

SPI = 5

SWD = 1

```
class pylink.enums.JLinkROMTable
    Bases: object

    The J-Link ROM tables.

    AHBAP = 270
    APBAP = 269
    DBG = 268
    DWT = 261
    ETB = 267
    ETM = 257
    FPB = 262
    ITM = 260
    MTB = 258
    NONE = 256
    NVIC = 263
    PTM = 266
    SECURE = 271
    TF = 265
    TMC = 264
    TPIU = 259

class pylink.enums.JLinkRTTCommand
    Bases: object

    RTT commands.

    GETDESC = 2
    GETNUMBUF = 3
    GETSTAT = 4
    START = 0
    STOP = 1

class pylink.enums.JLinkRTTDirection
    Bases: object

    RTT Direction.

    DOWN = 1
    UP = 0

class pylink.enums.JLinkRTTErrors
    Bases: pylink.enums.JLinkGlobalErrors

    Enumeration for error codes from RTT.

    RTT_ERROR_CONTROL_BLOCK_NOT_FOUND = -2

    classmethod to_string(error_code)
        Returns the string message for the given error code.
```

Parameters

- **cls** (`JLinkRTTErrors`) – the `JLinkRTTErrors` class
- **error_code** (`int`) – error code to convert

Returns An error string corresponding to the error code.

Raises `ValueError` – if the error code is invalid.

class `pylink.enums.JLinkReadErrors`

Bases: `pylink.enums.JLinkGlobalErrors`

Enumeration for the error codes generated during a read.

ZONE_NOT_FOUND_ERROR = -5

classmethod `to_string` (`error_code`)

Returns the string message for the given `error_code`.

Parameters

- **cls** (`JLinkReadErrors`) – the `JLinkReadErrors` class
- **error_code** (`int`) – error code to convert

Returns An error string corresponding to the error code.

Raises `ValueError` – if the error code is invalid.

class `pylink.enums.JLinkResetStrategyCortexM3`

Bases: `object`

Target reset strategies for the J-Link.

NORMAL

default reset strategy, does whatever is best to reset.

CORE

only the core is reset via the `VECTRESET` bit.

RESETPIN

pulls the reset pin low to reset the core and peripherals.

CONNECT_UNDER_RESET

J-Link connects to target while keeping reset active. This is recommended for STM32 devices.

HALT_AFTER_BTL

halt the core after the bootloader is executed.

HALT_BEFORE_BTL

halt the core before the bootloader is executed.

KINETIS

performs a normal reset, but also disables the watchdog.

ADI_HALT_AFTER_KERNEL

sets the `SYSRESETREQ` bit in the `AIRCR` in order to reset the device.

CORE_AND_PERIPHERALS

sets the `SYSRESETREQ` bit in the `AIRCR`, and the `VC_CORERESSET` bit in the `DEMCR` to make sure that the CPU is halted immediately after reset.

LPC1200

reset for LPC1200 devices.

S3FN60D

reset for Samsung S3FN60D devices.

Note: Please see the J-Link SEGGER Documentation, UM8001, for full information about the different reset strategies.

ADI_HALT_AFTER_KERNEL = 7

CONNECT_UNDER_RESET = 3

CORE = 1

CORE_AND_PERIPHERALS = 8

HALT_AFTER_BTL = 4

HALT_BEFORE_BTL = 5

KINETIS = 6

LPC1200 = 9

NORMAL = 0

RESETPIN = 2

S3FN60D = 10

class `pylink.enums.JLinkSWOCommands`

Bases: `object`

Serial Wire Output (SWO) commands.

FLUSH = 2

GET_NUM_BYTES = 10

GET_SPEED_INFO = 3

SET_BUFFER_SIZE_EMU = 21

SET_BUFFER_SIZE_HOST = 20

START = 0

STOP = 1

class `pylink.enums.JLinkSWOInterfaces`

Bases: `object`

Serial Wire Output (SWO) interfaces.

MANCHESTER = 1

UART = 0

class `pylink.enums.JLinkStraceCommand`

Bases: `object`

STRACE commands.

SET_BUFFER_SIZE = 3

TRACE_EVENT_CLR = 1

TRACE_EVENT_CLR_ALL = 2

TRACE_EVENT_SET = 0

class `pylink.enums.JLinkStraceEvent`

Bases: `object`

STRACE events.

CODE_FETCH = 0

DATA_ACCESS = 1

DATA_LOAD = 2

DATA_STORE = 3

class `pylink.enums.JLinkStraceOperation`

Bases: `object`

STRACE operation specifiers.

TRACE_EXCLUDE_RANGE = 3

TRACE_INCLUDE_RANGE = 2

TRACE_START = 0

TRACE_STOP = 1

class `pylink.enums.JLinkTraceCommand`

Bases: `object`

J-Link trace commands.

FLUSH = 2

GET_CONF_CAPACITY = 17

GET_FORMAT = 33

GET_MAX_CAPACITY = 20

GET_MIN_CAPACITY = 19

GET_NUM_REGIONS = 48

GET_NUM_SAMPLES = 16

GET_REGION_PROPS = 49

GET_REGION_PROPS_EX = 50

SET_CAPACITY = 18

SET_FORMAT = 32

START = 0

STOP = 1

class `pylink.enums.JLinkTraceFormat`

Bases: `object`

J-Link trace formats.

FORMAT_4BIT

4-bit data.

FORMAT_8BIT

8-bit data.

FORMAT_16BIT

16-bit data.

FORMAT_MULTIPLEXED

multiplexing on ETM / buffer link.

FORMAT_DEMULTIPLEXED

de-multiplexing on ETM / buffer link.

FORMAT_DOUBLE_EDGE

clock data on both ETM / buffer link edges.

FORMAT_ETM7_9

ETM7/ETM9 protocol.

FORMAT_ETM10

ETM10 protocol.

FORMAT_1BIT

1-bit data.

FORMAT_2BIT

2-bit data.

FORMAT_16BIT = 4**FORMAT_1BIT = 256****FORMAT_2BIT = 512****FORMAT_4BIT = 1****FORMAT_8BIT = 2****FORMAT_DEMULTIPLEXED = 16****FORMAT_DOUBLE_EDGE = 32****FORMAT_ETM10 = 128****FORMAT_ETM7_9 = 64****FORMAT_MULTIPLEXED = 8****class** `pylink.enums.JLinkTraceSource`Bases: `object`

Sources for tracing.

ETB = 0**ETM = 1****MTB = 2****class** `pylink.enums.JLinkVectorCatchCortexM3`Bases: `object`

Vector catch types for the ARM Cortex M3.

CORE_RESET

The CPU core reset.

MEM_ERROR

A memory management error occurred.

COPROCESSOR_ERROR

Usage fault error accessing the Coprocessor.

CHECK_ERROR

Usage fault error on enabled check.

STATE_ERROR

Usage fault state error.

BUS_ERROR

Normal bus error.

INT_ERROR

Interrupt or exception service error.

HARD_ERROR

Hard fault error.

BUS_ERROR = 256

CHECK_ERROR = 64

COPROCESSOR_ERROR = 32

CORE_RESET = 1

HARD_ERROR = 1024

INT_ERROR = 512

MEM_ERROR = 16

STATE_ERROR = 128

class `pylink.enums.JLinkWriteErrors`

Bases: `pylink.enums.JLinkGlobalErrors`

Enumeration for the error codes generated during a write.

ZONE_NOT_FOUND_ERROR = -5

classmethod `to_string` (*error_code*)

Returns the string message for the given `error_code`.

Parameters

- **cls** (`JLinkWriteErrors`) – the `JLinkWriteErrors` class
- **error_code** (*int*) – error code to convert

Returns An error string corresponding to the error code.

Raises `ValueError` – if the error code is invalid.

PyLink makes use of a number of different submodules as a part of its implementation. These submodules are *extras*, and the user should not need to use them explicitly.

8.1 Binpacker

This submodule provides functions for creating arrays of bytes from an integer.

`pylink.binpacker.pack(value, nbits=None)`

Packs a given value into an array of 8-bit unsigned integers.

If `nbits` is not present, calculates the minimal number of bits required to represent the given value. The result is little endian.

Parameters

- **value** (*int*) – the integer value to pack
- **nbits** (*int*) – optional number of bits to use to represent the value

Returns An array of `ctypes.c_uint8` representing the packed value.

Raises

- `ValueError` – if `value < 0` and `nbits` is `None` or `nbits <= 0`.
- `TypeError` – if `nbits` or `value` are not numbers.

`pylink.binpacker.pack_size(value)`

Returns the number of bytes required to represent a given value.

Parameters **value** (*int*) – the natural number whose size to get

Returns The minimal number of bytes required to represent the given integer.

Raises

- `ValueError` – if `value < 0`.
- `TypeError` – if `value` is not a number.

8.2 Decorators

This submodule provides different decorator functions.

`pylink.decorators.async_decorator` (*func*)

Asynchronous function decorator. Interprets the function as being asynchronous, so returns a function that will handle calling the Function asynchronously.

Parameters `func` (*function*) – function to be called asynchronously

Returns The wrapped function.

Raises `AttributeError` – if `func` is not callable

8.3 Registers

This submodule provides *ctypes* bindings for different registers.

class `pylink.registers.AbortRegisterBits`

Bases: `_ctypes.Structure`

This class holds the different bit mask for the Abort Register.

DAPABORT

write 1 to trigger a DAP abort.

STKCMPLR

write 1 to clear the STICKYCMP sticky compare flag (only supported on SW-DP).

STKERRCLR

write 1 to clear the STICKYERR sticky error flag (only supported on SW-DP).

WDERRCLR

write 1 to clear the WDATAERR write data error flag (only supported on SW-DP).

ORUNERRCLR

write 1 to clear the STICKYORUN overrun error flag (only supported on SW-DP).

DAPABORT

Structure/Union member

ORUNERRCLR

Structure/Union member

RESERVED

Structure/Union member

STKCMPLR

Structure/Union member

STKERRCLR

Structure/Union member

WDERRCLR

Structure/Union member

class `pylink.registers.AbortRegisterFlags`

Bases: `_ctypes.Union`

Mask for the abort register bits.

value

the value stored in the mask.

DAPABORT

Structure/Union member

ORUNERRCLR
Structure/Union member

RESERVED
Structure/Union member

STKCMPCLR
Structure/Union member

STKERRCLR
Structure/Union member

WDERRCLR
Structure/Union member

bit
Structure/Union member

value
Structure/Union member

class `pylink.registers.ControlStatusRegisterBits`

Bases: `_ctypes.Structure`

This class holds the different bit masks for the DP Control / Status Register bit assignments.

ORUNDETECT
if set, enables overrun detection.

STICKYORUN
if overrun is enabled, is set when overrun occurs.

TRNMODE
transfer mode for access port operations.

STICKYCMP
is set when a match occurs on a pushed compare or verify operation.

STICKYERR
is set when an error is returned by an access port transaction.

READOK
is set when the response to a previous access port or RDBUFF was OK.

WDATAERR
set to 1 if a Write Data Error occurs.

MASKLANE
bytes to be masked in pushed compare and verify operations.

TRNCNT
transaction counter.

RESERVED
reserved.

CDBGRSTREQ
debug reset request.

CDBGRSTACK
debug reset acknowledge.

CDBGPWRUPREQ
debug power-up request.

CDBGPWRUPACK

debug power-up acknowledge.

CSYSPWRUPREQ

system power-up request

CSYSPWRUPACK

system power-up acknowledge.

See also:

See the ARM documentation on the significance of these masks [here](#).

CDBGPWRUPACK

Structure/Union member

CDBGPWRUPREQ

Structure/Union member

CDBGRSTACK

Structure/Union member

CDBGRSTREQ

Structure/Union member

CSYSPWRUPACK

Structure/Union member

CSYSPWRUPREQ

Structure/Union member

MASKLANE

Structure/Union member

ORUNDETECT

Structure/Union member

READOK

Structure/Union member

RESERVED

Structure/Union member

STICKYCMP

Structure/Union member

STICKYERR

Structure/Union member

STICKYORUN

Structure/Union member

TRNCNT

Structure/Union member

TRNMODE

Structure/Union member

WDATAERR

Structure/Union member

```
class pylink.registers.ControlStatusRegisterFlags
```

```
    Bases: _ctypes.Union
```

```
    Mask for the control/status register bits.
```

value
the value stored in the mask.

CDBGPWRUPACK
Structure/Union member

CDBGPWRUPREQ
Structure/Union member

CDBGRSTACK
Structure/Union member

CDBGRSTREQ
Structure/Union member

CSYSPWRUPACK
Structure/Union member

CSYSPWRUPREQ
Structure/Union member

MASKLANE
Structure/Union member

ORUNDETECT
Structure/Union member

READOK
Structure/Union member

RESERVED
Structure/Union member

STICKYCMP
Structure/Union member

STICKYERR
Structure/Union member

STICKYORUN
Structure/Union member

TRNCNT
Structure/Union member

TRNMODE
Structure/Union member

WDATAERR
Structure/Union member

bit
Structure/Union member

value
Structure/Union member

class `pylink.registers.IDCodeRegisterBits`

Bases: `_ctypes.Structure`

This class holds the different bit masks for the IDCode register.

valid
validity bit, should always be 0.

manufacturer
the JEDEC Manufacturer ID.

part_no
the part number defined by the manufacturer.

version_code
the version code.

manufacturer
Structure/Union member

part_no
Structure/Union member

valid
Structure/Union member

version_code
Structure/Union member

class `pylink.registers.IDCodeRegisterFlags`

Bases: `_ctypes.Union`

Mask for the IDCode register bits.

value
the value stored in the mask.

bit
Structure/Union member

manufacturer
Structure/Union member

part_no
Structure/Union member

valid
Structure/Union member

value
Structure/Union member

version_code
Structure/Union member

class `pylink.registers.MDMAPControlRegisterBits`

Bases: `_ctypes.Structure`

This class holds the different bit masks for the MDM-AP Control Register.

flash_mass_erase
set to cause a mass erase, this is cleared automatically when a mass erase finishes.

debug_disable
set to disable debug, clear to allow debug.

debug_request
set to force the core to halt.

sys_reset_request
set to force a system reset.

core_hold_reset

set to suspend the core in reset at the end of reset sequencing.

VLLDBGREQ

set to hold the system in reset after the next recovery from VLLSx (Very Low Leakage Stop).

VLLDBGACK

set to release a system held in reset following a VLLSx (Very Low Leakage Stop) recovery.

VLLSTATAACK

set to acknowledge that the DAP LLS (Low Leakage Stop) and VLLS (Very Low Leakage Stop) status bits have read.

VLLDBGACK

Structure/Union member

VLLDBGREQ

Structure/Union member

VLLSTATAACK

Structure/Union member

core_hold_reset

Structure/Union member

debug_disable

Structure/Union member

debug_request

Structure/Union member

flash_mass_erase

Structure/Union member

sys_reset_request

Structure/Union member

class `pylink.registers.MDMAPControlRegisterFlags`

Bases: `_ctypes.Union`

Mask for the MDM-AP control register bits.

value

the value stored in the mask.

VLLDBGACK

Structure/Union member

VLLDBGREQ

Structure/Union member

VLLSTATAACK

Structure/Union member

bit

Structure/Union member

core_hold_reset

Structure/Union member

debug_disable

Structure/Union member

debug_request
Structure/Union member

flash_mass_erase
Structure/Union member

sys_reset_request
Structure/Union member

value
Structure/Union member

class `pylink.registers.MDMAPStatusRegisterBits`
Bases: `_ctypes.Structure`

Holds the bit masks for the MDM-AP Status Register.

flash_mass_erase_ack
cleared after a system reset, indicates that a flash mass erase was acknowledged.

flash_ready
indicates that flash has been initialized and can be configured.

system_security
if set, system is secure and debugger cannot access the memory or system bus.

system_reset
1 if system is in reset, otherwise 0.

mass_erase_enabled
1 if MCU can be mass erased, otherwise 0.

low_power_enabled
1 if low power stop mode is enabled, otherwise 0.

very_low_power_mode
1 if device is in very low power mode.

LLSMODEEXIT
indicates an exit from LLS mode has occurred.

VLLSxMODEEXIT
indicates an exit from VLLSx mode has occurred.

core_halted; indicates core has entered debug halt mode.

core_deep_sleep
indicates core has entered a low power mode.

core_sleeping
indicates the core has entered a low power mode.

Note: if `core_sleeping & !core_deep_sleep`, then the core is in VLPW (very low power wait) mode, otherwise if `core_sleeping & core_deep_sleep`, then it is in VLPS (very low power stop) mode.

LLSMODEEXIT
Structure/Union member

RESERVED_A
Structure/Union member

RESERVED_B
Structure/Union member

RESERVED_C
Structure/Union member

VLLSxMODEEXIT
Structure/Union member

backdoor_access_enabled
Structure/Union member

core_deep_sleep
Structure/Union member

core_halted
Structure/Union member

core_sleeping
Structure/Union member

flash_mass_erase_ack
Structure/Union member

flash_ready
Structure/Union member

low_power_enabled
Structure/Union member

mass_erase_enabled
Structure/Union member

system_reset
Structure/Union member

system_security
Structure/Union member

very_low_power_mode
Structure/Union member

class `pylink.registers.MDMAPStatusRegisterFlags`

Bases: `_ctypes.Union`

Mask for the MDM-AP status register bits.

value
the value stored in the mask.

LLSMODEEXIT
Structure/Union member

RESERVED_A
Structure/Union member

RESERVED_B
Structure/Union member

RESERVED_C
Structure/Union member

VLLSxMODEEXIT
Structure/Union member

backdoor_access_enabled

Structure/Union member

bit

Structure/Union member

core_deep_sleep

Structure/Union member

core_halted

Structure/Union member

core_sleeping

Structure/Union member

flash_mass_erase_ack

Structure/Union member

flash_ready

Structure/Union member

low_power_enabled

Structure/Union member

mass_erase_enabled

Structure/Union member

system_reset

Structure/Union member

system_security

Structure/Union member

value

Structure/Union member

very_low_power_mode

Structure/Union member

class `pylink.registers.SelectRegisterBits`

Bases: `_ctypes.Structure`

This class holds the different bit masks for the AP Select Register.

CTRLSEL

SW-DP debug port address bank select.

RESERVED_A

reserved.

APBANKSEL

selects the active four-word register window on the current access port.

RESERVED_B

reserved.

APSEL

selects the current access port.

APBANKSEL

Structure/Union member

APSEL

Structure/Union member

CTRLSEL

Structure/Union member

RESERVED_A

Structure/Union member

RESERVED_B

Structure/Union member

class `pylink.registers.SelectRegisterFlags`Bases: `_ctypes.Union`

Mask for the select register bits.

value

the value stored in the mask.

APBANKSEL

Structure/Union member

APSEL

Structure/Union member

CTRLSEL

Structure/Union member

RESERVED_A

Structure/Union member

RESERVED_B

Structure/Union member

bit

Structure/Union member

value

Structure/Union member

8.4 Threads

This submodule provides custom *threading.Thread* types.

class `pylink.threads.ThreadReturn` (*daemon=False, *args, **kwargs*)Bases: `threading.Thread`

Implementation of a thread with a return value.

See also:[StackOverflow](#).**join** (**args, **kwargs*)

Joins the thread.

Parameters

- **self** (`ThreadReturn`) – the `ThreadReturn` instance
- **args** – optional list of arguments
- **kwargs** – optional key-word arguments

Returns The return value of the exited thread.

`run()`

Runs the thread.

Parameters `self` (`ThreadReturn`) – the `ThreadReturn` instance

Returns `None`

8.5 Util

This submodule provides different utility functions.

`pylink.util.calculate_parity(n)`

Calculates and returns the parity of a number.

The parity of a number is 1 if the number has an odd number of ones in its binary representation, otherwise 0.

Parameters `n` (`int`) – the number whose parity to calculate

Returns 1 if the number has an odd number of ones, otherwise 0.

Raises `ValueError` – if `n` is less than 0.

`pylink.util.flash_progress_callback(action, progress_string, percentage)`

Callback that can be used with `JLink.flash()`.

This callback generates a progress bar in the console to show the progress of each of the steps of the flash.

Parameters

- **action** (`str`) – the current action being invoked
- **progress_string** (`str`) – the current step in the progress
- **percentage** (`int`) – the percent to which the current step has been done

Returns `None`

Note: This function ignores the compare action.

`pylink.util.is_integer(val)`

Returns whether the given value is an integer.

Parameters `val` (`object`) – value to check

Returns `True` if the given value is an integer, otherwise `False`.

`pylink.util.is_natural(val)`

Returns whether the given value is a natural number.

Parameters `val` (`object`) – value to check

Returns `True` if the given value is a natural number, otherwise `False`.

`pylink.util.is_os_64bit()`

Returns whether the current running platform is 64bit.

Returns `True` if the platform is 64bit, otherwise `False`.

`pylink.util.noop(*args, **kwargs)`

No-op. Does nothing.

Parameters

- **args** – list of arguments
- **kwargs** – keyword arguments dictionary

Returns None

`pylink.util.progress_bar(iteration, total, prefix=None, suffix=None, decs=1, length=100)`

Creates a console progress bar.

This should be called in a loop to create a progress bar.

See [StackOverflow](#).

Parameters

- **iteration** (*int*) – current iteration
- **total** (*int*) – total iterations
- **prefix** (*str*) – prefix string
- **suffix** (*str*) – suffix string
- **decs** (*int*) – positive number of decimals in percent complete
- **length** (*int*) – character length of the bar

Returns None

Note: This function assumes that nothing else is printed to the console in the interim.

`pylink.util.unsecure_hook_dialog(title, msg, flags)`

No-op that ignores the dialog.

Parameters

- **title** (*str*) – title of the unsecure dialog
- **msg** (*str*) – text of the unsecure dialog
- **flags** (*int*) – flags specifying which values can be returned

Returns `enums.JLinkFlags.DLG_BUTTON_NO`

Troubleshooting

This page details common errors people run into while using PyLink. These errors do not mean the library is not working as intended, but rather a fault on the user end. If you cannot solve your issue by following any of the steps below, feel free to reach out.

9.1 Unspecified Error

If you ever see something similar to the following:

```
Traceback (most recent call last):
  File "pylink/decorators.py", line 38, in async_wrapper
    return func(*args, **kwargs)
  File "pylink/jlink.py", line 256, in open
    raise JLinkException(result)
__main__.JLinkException: Unspecified error.
```

Then congratulations, you've run into a catch-all error. This is a limitation imposed by native C SDK in which there is a catch-all error case. There are a couple possible solutions to this, and they are detailed below.

9.1.1 Unspecified Error during `open()`

If you see the unspecified error during `open()`, it means that one of the following is true:

- Your J-Link is not connected to your computer.
- Your J-Link is connected to your computer, but is currently held open by another application.

9.1.2 Unspecified Error during `connect()`

If you see the unspecified error during `connect()`, it means that any of the following is not true:

- The target device's chip name you passed to `connect()` is not the chip name of the actual target.
- You're trying to connect to the target over JTAG when it only supports SWD.
- You're trying to connect to the target, but the target is not plugged in.
- You're trying to connect to the target using a J-Link that does not have the target plugged in under its "Target" port.
- The connection speed is bad (try 'auto' instead).

9.1.3 Unspecified Error during `erase()`

If you see the unspecified error during `erase()`, it means that your device is not properly halted. If you're using a Cortex-M device, try setting the reset strategy to `JLinkResetStrategyCortexM3.RESETPIN` to avoid your device's application running when the system is booted; this is particularly useful if your application launches the watchdog or another service which would interpret the J-Link when erasing.

9.1.4 Unspecified Error during `flash()`

If you see the unspecified error during `flash()`, it means that either:

- Your device is not properly halt. While `flash()` attempts to halt the CPU, it cannot if the device is breakpointed or similar.
- The device is locked, in which case you have to unlock the device first.

9.1.5 Unspecified Error in Coresight

If you see an unspecified error while using a Coresight method, it means that you are trying to read from / write to an invalid register.

Serial Wire Debug

Serial Wire Output (SWO) alongside Serial Wire Debug (SWD) allows for the CPU to emit real-time trace data. In particular, when used with an Instrumentation Trace Macrocell (ITM), it can be used to form a Serial Wire Viewer (SWV). The ITM ports are provided by the ARM controller. The SWV typically implements a form of `printf` style debugging for embedded systems.

10.1 Getting Started

First, get your J-Link set up by instantiating an instance of a `JLink` and connecting to your target device. Once that is established, you want to call either `swo_start()`:

```
speed = 9600
jlink.swo_start(swo_speed=speed)
```

or call `swo_enable()`:

```
swo_speed = 9600
cpu_speed = 72000000 # 72 MHz
port_mask = 0x01
jlink.swo_enable(cpu_speed, swo_speed, port_mask)
```

Once enabled, you can begin reading data from the target.

10.2 Serial Wire Methods

class `pylink.jlink.JLink` (*lib=None, log=None, detailed_log=None, error=None, warn=None, unsecure_hook=None, serial_no=None, ip_addr=None, open_tunnel=False*)

Python interface for the SEGGER J-Link.

This is a wrapper around the J-Link C SDK to provide a Python interface to it. The shared library is loaded and used to call the SDK methods.

swd_read16 (**args, **kwargs*)

Gets a unit of 16 bits from the input buffer.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **offset** (`int`) – the offset (in bits) from which to start reading

Returns The integer read from the input buffer.

swd_read32 (*args, **kwargs)

Gets a unit of 32 bits from the input buffer.

Parameters

- **self** (JLink) – the JLink instance
- **offset** (int) – the offset (in bits) from which to start reading

Returns The integer read from the input buffer.

swd_read8 (*args, **kwargs)

Gets a unit of 8 bits from the input buffer.

Parameters

- **self** (JLink) – the JLink instance
- **offset** (int) – the offset (in bits) from which to start reading

Returns The integer read from the input buffer.

swd_sync (*args, **kwargs)

Causes a flush to write all data remaining in output buffers to SWD device.

Parameters

- **self** (JLink) – the JLink instance
- **pad** (bool) – True if should pad the data to full byte size

Returns None

swd_write (*args, **kwargs)

Writes bytes over SWD (Serial Wire Debug).

Parameters

- **self** (JLink) – the JLink instance
- **output** (int) – the output buffer offset to write to
- **value** (int) – the value to write to the output buffer
- **nbits** (int) – the number of bits needed to represent the output and value

Returns The bit position of the response in the input buffer.

swd_write16 (*args, **kwargs)

Writes two bytes over SWD (Serial Wire Debug).

Parameters

- **self** (JLink) – the JLink instance
- **output** (int) – the output buffer offset to write to
- **value** (int) – the value to write to the output buffer

Returns The bit position of the response in the input buffer.

swd_write32 (*args, **kwargs)

Writes four bytes over SWD (Serial Wire Debug).

Parameters

- **self** (JLink) – the JLink instance

- **output** (*int*) – the output buffer offset to write to
- **value** (*int*) – the value to write to the output buffer

Returns The bit position of the response in the input buffer.

swd_write8 (**args, **kwargs*)

Writes one byte over SWD (Serial Wire Debug).

Parameters

- **self** (*JLink*) – the JLink instance
- **output** (*int*) – the output buffer offset to write to
- **value** (*int*) – the value to write to the output buffer

Returns The bit position of the response in the input buffer.

swo_enable (**args, **kwargs*)

Enables SWO output on the target device.

Configures the output protocol, the SWO output speed, and enables any ITM & stimulus ports.

This is equivalent to calling `.swo_start()`.

Note: If SWO is already enabled, it will first stop SWO before enabling it again.

Parameters

- **self** (*JLink*) – the JLink instance
- **cpu_speed** (*int*) – the target CPU frequency in Hz
- **swo_speed** (*int*) – the frequency in Hz used by the target to communicate
- **port_mask** (*int*) – port mask specifying which stimulus ports to enable

Returns None

Raises *JLinkException* – on error

swo_flush (**args, **kwargs*)

Flushes data from the SWO buffer.

After this method is called, the flushed part of the SWO buffer is empty.

If `num_bytes` is not present, flushes all data currently in the SWO buffer.

Parameters

- **self** (*JLink*) – the JLink instance
- **num_bytes** (*int*) – the number of bytes to flush

Returns None

Raises *JLinkException* – on error

swo_num_bytes (**args, **kwargs*)

Retrieves the number of bytes in the SWO buffer.

Parameters **self** (*JLink*) – the JLink instance

Returns Number of bytes in the SWO buffer.

Raises *JLinkException* – on error

swo_read (*args, **kwargs)

Reads data from the SWO buffer.

The data read is not automatically removed from the SWO buffer after reading unless `remove` is `True`. Otherwise the callee must explicitly remove the data by calling `.swo_flush()`.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **offset** (`int`) – offset of first byte to be retrieved
- **num_bytes** (`int`) – number of bytes to read
- **remove** (`bool`) – if data should be removed from buffer after read

Returns A list of bytes read from the SWO buffer.**swo_read_stimulus** (*args, **kwargs)

Reads the printable data via SWO.

This method reads SWO for one stimulus port, which is all printable data.

Note: Stimulus port 0 is used for `printf` debugging.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **port** (`int`) – the stimulus port to read from, 0 – 31
- **num_bytes** (`int`) – number of bytes to read

Returns A list of bytes read via SWO.**Raises** `ValueError` – if `port < 0` or `port > 31`**swo_set_emu_buffer_size** (*args, **kwargs)

Sets the size of the buffer used by the J-Link to collect SWO data.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **buf_size** (`int`) – the new size of the emulator buffer

Returns `None`**Raises** `JLinkException` – on error**swo_set_host_buffer_size** (*args, **kwargs)

Sets the size of the buffer used by the host to collect SWO data.

Parameters

- **self** (`JLink`) – the `JLink` instance
- **buf_size** (`int`) – the new size of the host buffer

Returns `None`**Raises** `JLinkException` – on error**swo_speed_info** (*args, **kwargs)

Retrieves information about the supported SWO speeds.

Parameters `self` (`JLink`) – the `JLink` instance

Returns A `JLinkSWOSpeedInfo` instance describing the target's supported SWO speeds.

Raises `JLinkException` – on error

swos_start (`*args`, `**kwargs`)
Starts collecting SWO data.

Note: If SWO is already enabled, it will first stop SWO before enabling it again.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `swos_speed` (`int`) – the frequency in Hz used by the target to communicate

Returns `None`

Raises `JLinkException` – on error

swos_stop (`*args`, `**kwargs`)
Stops collecting SWO data.

Parameters `self` (`JLink`) – the `JLink` instance

Returns `None`

Raises `JLinkException` – on error

swos_supported_speeds (`*args`, `**kwargs`)
Retrieves a list of SWO speeds supported by both the target and the connected J-Link.

The supported speeds are returned in order from highest to lowest.

Parameters

- `self` (`JLink`) – the `JLink` instance
- `cpu_speed` (`int`) – the target's CPU speed in Hz
- `num_speeds` (`int`) – the number of compatible speeds to return

Returns A list of compatible SWO speeds in Hz in order from highest to lowest.

10.3 Examples

10.3.1 Serial Wire Viewer

```

1 # -*- coding: utf-8 -*-
2 # Copyright 2017 Square, Inc.
3 #
4 # Licensed under the Apache License, Version 2.0 (the "License");
5 # you may not use this file except in compliance with the License.
6 # You may obtain a copy of the License at
7 #
8 #     http://www.apache.org/licenses/LICENSE-2.0
9 #
10 # Unless required by applicable law or agreed to in writing, software
11 # distributed under the License is distributed on an "AS IS" BASIS,

```

```
12 # WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied.
13 # See the License for the specific language governing permissions and
14 # limitations under the License.
15 #
16 #
17 # Example Serial Wire Viewer.
18 #
19 # This module demonstrates implementing a Serial Wire Viewer using the PyLink
20 # library.
21 #
22 # Usage: swv.py jlink_serial_number device
23 # Author: Ford Peprah
24 # Date: Friday, September 23rd, 2016
25 # Copyright: 2016 Square, Inc.
26
27 import pylink
28
29 try:
30     import StringIO
31 except ImportError:
32     import io as StringIO
33 import string
34 import sys
35 import time
36
37
38 def serial_wire_viewer(jlink_serial, device):
39     """Implements a Serial Wire Viewer (SWV).
40
41     A Serial Wire Viewer (SWV) allows us implement real-time logging of output
42     from a connected device over Serial Wire Output (SWO).
43
44     Args:
45         jlink_serial (str): the J-Link serial number
46         device (str): the target CPU
47
48     Returns:
49         Always returns ``0``.
50
51     Raises:
52         JLinkException: on error
53     """
54     buf = StringIO.StringIO()
55     jlink = pylink.JLink(log=buf.write, detailed_log=buf.write)
56     jlink.open(serial_no=jlink_serial)
57
58     # Use Serial Wire Debug as the target interface. Need this in order to use
59     # Serial Wire Output.
60     jlink.set_tif(pylink.enums.JLinkInterfaces.SWD)
61     jlink.connect(device, verbose=True)
62     jlink.coresight_configure()
63     jlink.set_reset_strategy(pylink.enums.JLinkResetStrategyCortexM3.RESETPIN)
64
65     # Have to halt the CPU before getting its speed.
66     jlink.reset()
67     jlink.halt()
68
69     cpu_speed = jlink.cpu_speed()
```

```
70 swo_speed = jlink.swo_supported_speeds(cpu_speed, 10)[0]
71
72 # Start logging serial wire output.
73 jlink.swo_start(swo_speed)
74 jlink.swo_flush()
75
76 # Output the information about the program.
77 sys.stdout.write('Serial Wire Viewer\n')
78 sys.stdout.write('Press Ctrl-C to Exit\n')
79 sys.stdout.write('Reading data from port 0:\n\n')
80
81 # Reset the core without halting so that it runs.
82 jlink.reset(ms=10, halt=False)
83
84 # Use the `try` loop to catch a keyboard interrupt in order to stop logging
85 # serial wire output.
86 try:
87     while True:
88         # Check for any bytes in the stream.
89         num_bytes = jlink.swo_num_bytes()
90
91         if num_bytes == 0:
92             # If no bytes exist, sleep for a bit before trying again.
93             time.sleep(1)
94             continue
95
96         data = jlink.swo_read_stimulus(0, num_bytes)
97         sys.stdout.write(''.join(map(chr, data)))
98         sys.stdout.flush()
99     except KeyboardInterrupt:
100         pass
101
102     sys.stdout.write('\n')
103
104     # Stop logging serial wire output.
105     jlink.swo_stop()
106
107     return 0
108
109 if __name__ == '__main__':
110     exit(serial_wire_viewer(sys.argv[1], sys.argv[2]))
```

About

PyLink is a Python library for interfacing with a J-Link. It leverages the J-Link C SDK. PyLink is in no way endorsed by or developed by SEGGER.

11.1 Goals

- Provide a Python interface for the J-Link C SDK.
- Provide a high-level API for flashing/running firmware via Python.
- Provide a high-level API for debugging devices.
- Provide a high-level API for unlocking locked devices.

11.2 License

PyLink is licensed under the [Apache 2.0 Open-Source License](#).

11.3 Copyright

Copyright 2017 Square, Inc.

11.4 Sponsorship

This library was made possible by [Square](#).

p

`pylink.binpacker`, 93
`pylink.decorators`, 93
`pylink.enums`, 78
`pylink.errors`, 11
`pylink.jlink`, 15
`pylink.jlock`, 14
`pylink.library`, 12
`pylink.protocols.swd`, 57
`pylink.registers`, 94
`pylink.structs`, 63
`pylink.threads`, 103
`pylink.unlockers`, 61
`pylink.unlockers.unlock_kinetis`, 61
`pylink.util`, 104

Symbols

`_standard_calls_` (pylink.library.Library attribute), 12

A

`abDummy` (pylink.structs.JLinkMemoryZone attribute), 70

`abMACAddr` (pylink.structs.JLinkConnectInfo attribute), 64, 65

`AbortRegisterBits` (class in pylink.registers), 94

`AbortRegisterFlags` (class in pylink.registers), 94

`Access` (pylink.structs.JLinkDataEvent attribute), 66

`AccessMask` (pylink.structs.JLinkDataEvent attribute), 66

`AccessSize` (pylink.structs.JLinkStraceEventInfo attribute), 74, 75

`acFWString` (pylink.structs.JLinkConnectInfo attribute), 64, 65

`ack()` (pylink.protocols.swd.Response method), 59

`acName` (pylink.structs.JLinkGPIODescriptor attribute), 68

`acName` (pylink.structs.JLinkRTTerminalBufDesc attribute), 71

`acNickname` (pylink.structs.JLinkConnectInfo attribute), 64, 65

`acProduct` (pylink.structs.JLinkConnectInfo attribute), 64, 65

`acquire()` (pylink.jlock.JLock method), 14

`acquired` (pylink.jlock.JLock attribute), 14

`ADAPTIVE_JTAG_SPEED` (pylink.jlink.JLink attribute), 15

`add_license()` (pylink.jlink.JLink method), 15

`Addr` (pylink.structs.JLinkBreakpointInfo attribute), 63

`Addr` (pylink.structs.JLinkDataEvent attribute), 66

`Addr` (pylink.structs.JLinkFlashArea attribute), 68

`Addr` (pylink.structs.JLinkRAMArea attribute), 70

`Addr` (pylink.structs.JLinkStraceEventInfo attribute), 74, 75

`Addr` (pylink.structs.JLinkWatchpointInfo attribute), 77

`addr2` (pylink.protocols.swd.Request attribute), 58

`addr2` (pylink.protocols.swd.RequestBits attribute), 59

`addr3` (pylink.protocols.swd.Request attribute), 58

`addr3` (pylink.protocols.swd.RequestBits attribute), 59

`address` (pylink.protocols.swd.Request attribute), 58

`AddrMask` (pylink.structs.JLinkDataEvent attribute), 66

`AddrMask` (pylink.structs.JLinkWatchpointInfo attribute), 77

`AddrRangeSize` (pylink.structs.JLinkStraceEventInfo attribute), 74, 75

`ADI_HALT_AFTER_KERNEL`

(pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89

`aFlashArea` (pylink.structs.JLinkDeviceInfo attribute), 67

`AHBAP` (pylink.enums.JLinkROMTable attribute), 87

`aIPAddr` (pylink.structs.JLinkConnectInfo attribute), 64, 65

`ANY` (pylink.enums.JLinkBreakpoint attribute), 79

`ANY` (pylink.enums.JLinkCore attribute), 80

`ANY` (pylink.enums.JLinkDeviceFamily attribute), 83

`ap_dp` (pylink.protocols.swd.Request attribute), 58

`ap_dp` (pylink.protocols.swd.RequestBits attribute), 59

`aPadding` (pylink.structs.JLinkConnectInfo attribute), 65

`APBANKSEL` (pylink.registers.SelectRegisterBits attribute), 102

`APBANKSEL` (pylink.registers.SelectRegisterFlags attribute), 103

`APBAP` (pylink.enums.JLinkROMTable attribute), 87

`APSEL` (pylink.registers.SelectRegisterBits attribute), 102

`APSEL` (pylink.registers.SelectRegisterFlags attribute), 103

`aRAMArea` (pylink.structs.JLinkDeviceInfo attribute), 67

`aRamArea` (pylink.structs.JLinkDeviceInfo attribute), 67

`ARM` (pylink.enums.JLinkBreakpoint attribute), 79

`ARM10` (pylink.enums.JLinkDeviceFamily attribute), 83

`ARM11` (pylink.enums.JLinkCore attribute), 80

`ARM11` (pylink.enums.JLinkDeviceFamily attribute), 83

`ARM1136` (pylink.enums.JLinkCore attribute), 80

`ARM1136J` (pylink.enums.JLinkCore attribute), 80

`ARM1136J_S` (pylink.enums.JLinkCore attribute), 80

`ARM1136JF` (pylink.enums.JLinkCore attribute), 80

`ARM1136JF_S` (pylink.enums.JLinkCore attribute), 80

ARM1156 (pylink.enums.JLinkCore attribute), 80
 ARM1176 (pylink.enums.JLinkCore attribute), 80
 ARM1176J (pylink.enums.JLinkCore attribute), 80
 ARM1176J_S (pylink.enums.JLinkCore attribute), 81
 ARM1176JF (pylink.enums.JLinkCore attribute), 81
 ARM1176JF_S (pylink.enums.JLinkCore attribute), 81
 ARM7 (pylink.enums.JLinkCore attribute), 81
 ARM7 (pylink.enums.JLinkDeviceFamily attribute), 83
 ARM7TDMI (pylink.enums.JLinkCore attribute), 81
 ARM7TDMI_R3 (pylink.enums.JLinkCore attribute), 81
 ARM7TDMI_R4 (pylink.enums.JLinkCore attribute), 81
 ARM7TDMI_S (pylink.enums.JLinkCore attribute), 81
 ARM7TDMI_S_R3 (pylink.enums.JLinkCore attribute), 81
 ARM7TDMI_S_R4 (pylink.enums.JLinkCore attribute), 81
 ARM9 (pylink.enums.JLinkCore attribute), 81
 ARM9 (pylink.enums.JLinkDeviceFamily attribute), 83
 ARM920T (pylink.enums.JLinkCore attribute), 81
 ARM922T (pylink.enums.JLinkCore attribute), 81
 ARM926EJ_S (pylink.enums.JLinkCore attribute), 81
 ARM946E_S (pylink.enums.JLinkCore attribute), 81
 ARM966E_S (pylink.enums.JLinkCore attribute), 81
 ARM968E_S (pylink.enums.JLinkCore attribute), 81
 ARM9TDMI_S (pylink.enums.JLinkCore attribute), 81
 async_decorator() (in module pylink.decorators), 93
 AUTO (pylink.enums.JLinkDeviceFamily attribute), 83
 AUTO_JTAG_SPEED (pylink.jlink.JLink attribute), 15

B

backdoor_access_enabled (pylink.registers.MDMAPStatusRegisterBits attribute), 101
 backdoor_access_enabled (pylink.registers.MDMAPStatusRegisterFlags attribute), 101
 BaseFreq (pylink.structs.JLinkSpeedInfo attribute), 74
 BaseFreq (pylink.structs.JLinkSWOSpeedInfo attribute), 72, 73
 bit (pylink.protocols.swd.Request attribute), 58
 bit (pylink.registers.AbortRegisterFlags attribute), 95
 bit (pylink.registers.ControlStatusRegisterFlags attribute), 97
 bit (pylink.registers.IDCodeRegisterFlags attribute), 98
 bit (pylink.registers.MDMAPControlRegisterFlags attribute), 99
 bit (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
 bit (pylink.registers.SelectRegisterFlags attribute), 103
 branch() (pylink.structs.JLinkTraceData method), 75
 BREAKPOINT (pylink.enums.JLinkEventTypes attribute), 84
 breakpoint_clear() (pylink.jlink.JLink method), 15
 breakpoint_clear_all() (pylink.jlink.JLink method), 15

breakpoint_find() (pylink.jlink.JLink method), 16
 breakpoint_info() (pylink.jlink.JLink method), 16
 breakpoint_set() (pylink.jlink.JLink method), 16
 BufferIndex (pylink.structs.JLinkRTTerminalBufDesc attribute), 71
 BUS_ERROR (pylink.enums.JLinkVectorCatchCortexM3 attribute), 92

C

C2 (pylink.enums.JLinkInterfaces attribute), 86
 calculate_parity() (in module pylink.util), 104
 capabilities (pylink.jlink.JLink attribute), 16
 Caps (pylink.structs.JLinkGPIODescriptor attribute), 68
 CDBGPWRUPACK (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
 CDBGPWRUPACK (pylink.registers.ControlStatusRegisterFlags attribute), 97
 CDBGPWRUPREQ (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
 CDBGPWRUPREQ (pylink.registers.ControlStatusRegisterFlags attribute), 97
 CDBGGRSTACK (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
 CDBGGRSTACK (pylink.registers.ControlStatusRegisterFlags attribute), 97
 CDBGGRSTREQ (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
 CDBGGRSTREQ (pylink.registers.ControlStatusRegisterFlags attribute), 97
 CHECK_ERROR (pylink.enums.JLinkVectorCatchCortexM3 attribute), 92
 CIP51 (pylink.enums.JLinkCore attribute), 81
 clear_error() (pylink.jlink.JLink method), 17
 close() (pylink.jlink.JLink method), 17
 CODE_BREAKPOINT (pylink.enums.JLinkHaltReasons attribute), 86
 code_breakpoint() (pylink.structs.JLinkMOEInfo method), 69
 CODE_FETCH (pylink.enums.JLinkStraceEvent attribute), 90
 code_memory_read() (pylink.jlink.JLink method), 17
 COLDFIRE (pylink.enums.JLinkCore attribute), 81
 COLDFIRE (pylink.enums.JLinkDeviceFamily attribute), 83
 comm_supported() (pylink.jlink.JLink method), 17
 COMPARE_ERROR (pylink.enums.JLinkFlashErrors attribute), 84
 compatible_firmware_version (pylink.jlink.JLink attribute), 17
 compile_date (pylink.jlink.JLink attribute), 17
 ConfigBlockAddress (pylink.structs.JLinkRTTerminalStart attribute), 71
 connect() (pylink.jlink.JLink method), 17

- CONNECT_UNDER_RESET (pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89
- connected() (pylink.jlink.JLink method), 18
- connected_emulators() (pylink.jlink.JLink method), 18
- Connection (pylink.structs.JLinkConnectInfo attribute), 64, 65
- connection_required() (pylink.jlink.JLink method), 18
- ControlStatusRegisterBits (class in pylink.registers), 95
- ControlStatusRegisterFlags (class in pylink.registers), 96
- COPROCESSOR_ERROR (pylink.enums.JLinkVectorCatchCortexM3 attribute), 91, 92
- CORE (pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89
- Core (pylink.structs.JLinkDeviceInfo attribute), 67
- CORE_AND_PERIPHERALS (pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89
- core_cpu() (pylink.jlink.JLink method), 18
- core_deep_sleep (pylink.registers.MDMAPStatusRegisterBits attribute), 100, 101
- core_deep_sleep (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
- core_halted (pylink.registers.MDMAPStatusRegisterBits attribute), 101
- core_halted (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
- core_hold_reset (pylink.registers.MDMAPControlRegisterBits attribute), 98, 99
- core_hold_reset (pylink.registers.MDMAPControlRegisterFlags attribute), 99
- core_id() (pylink.jlink.JLink method), 18
- core_name() (pylink.jlink.JLink method), 18
- CORE_RESET (pylink.enums.JLinkVectorCatchCortexM3 attribute), 91, 92
- core_sleeping (pylink.registers.MDMAPStatusRegisterBits attribute), 100, 101
- core_sleeping (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
- CoreId (pylink.structs.JLinkDeviceInfo attribute), 66, 67
- coresight_configuration_required() (pylink.jlink.JLink method), 18
- coresight_configure() (pylink.jlink.JLink method), 19
- coresight_read() (pylink.jlink.JLink method), 19
- coresight_write() (pylink.jlink.JLink method), 19
- CORTEX_A12 (pylink.enums.JLinkCore attribute), 81
- CORTEX_A15 (pylink.enums.JLinkCore attribute), 81
- CORTEX_A17 (pylink.enums.JLinkCore attribute), 81
- CORTEX_A5 (pylink.enums.JLinkCore attribute), 81
- CORTEX_A5 (pylink.enums.JLinkDeviceFamily attribute), 83
- CORTEX_A7 (pylink.enums.JLinkCore attribute), 81
- CORTEX_A8 (pylink.enums.JLinkCore attribute), 81
- CORTEX_A8 (pylink.enums.JLinkDeviceFamily attribute), 83
- CORTEX_A9 (pylink.enums.JLinkCore attribute), 81
- CORTEX_A9 (pylink.enums.JLinkDeviceFamily attribute), 83
- CORTEX_M0 (pylink.enums.JLinkCore attribute), 81
- CORTEX_M0 (pylink.enums.JLinkDeviceFamily attribute), 83
- CORTEX_M1 (pylink.enums.JLinkCore attribute), 81
- CORTEX_M1 (pylink.enums.JLinkDeviceFamily attribute), 83
- CORTEX_M3 (pylink.enums.JLinkCore attribute), 81
- CORTEX_M3 (pylink.enums.JLinkDeviceFamily attribute), 83
- CORTEX_M3_R1P0 (pylink.enums.JLinkCore attribute), 81
- CORTEX_M3_R1P1 (pylink.enums.JLinkCore attribute), 81
- CORTEX_M3_R2P0 (pylink.enums.JLinkCore attribute), 81
- CORTEX_M4 (pylink.enums.JLinkCore attribute), 81
- CORTEX_M4 (pylink.enums.JLinkDeviceFamily attribute), 83
- CORTEX_M7 (pylink.enums.JLinkCore attribute), 81
- CORTEX_M_V8BASEL (pylink.enums.JLinkCore attribute), 81
- CORTEX_M_V8MAINL (pylink.enums.JLinkCore attribute), 82
- CORTEX_R4 (pylink.enums.JLinkCore attribute), 82
- CORTEX_R4 (pylink.enums.JLinkDeviceFamily attribute), 83
- CORTEX_R5 (pylink.enums.JLinkCore attribute), 82
- cp15_present() (pylink.jlink.JLink method), 20
- cp15_register_read() (pylink.jlink.JLink method), 20
- cp15_register_write() (pylink.jlink.JLink method), 20
- cpu_capability() (pylink.jlink.JLink method), 20
- cpu_halt_reasons() (pylink.jlink.JLink method), 21
- CPU_IN_LOW_POWER_MODE (pylink.enums.JLinkGlobalErrors attribute), 85
- cpu_speed() (pylink.jlink.JLink method), 21
- CSYSPWRUPACK (pylink.registers.ControlStatusRegisterBits attribute), 96
- CSYSPWRUPACK (pylink.registers.ControlStatusRegisterFlags attribute), 97
- CSYSPWRUPREQ (pylink.registers.ControlStatusRegisterBits attribute), 96
- CSYSPWRUPREQ (pylink.registers.ControlStatusRegisterFlags attribute), 97
- Ctrl (pylink.structs.JLinkWatchpointInfo attribute), 77
- CtrlMask (pylink.structs.JLinkWatchpointInfo attribute), 77
- CTRLSEL (pylink.registers.SelectRegisterBits attribute), 102
- CTRLSEL (pylink.registers.SelectRegisterFlags attribute), 102

tribute), 103
 custom_licenses (pylink.jlink.JLink attribute), 21

D

DAPABORT (pylink.registers.AbortRegisterBits attribute), 94
 DAPABORT (pylink.registers.AbortRegisterFlags attribute), 94
 Data (pylink.structs.JLinkDataEvent attribute), 66
 Data (pylink.structs.JLinkStraceEventInfo attribute), 74, 75
 Data (pylink.structs.JLinkWatchpointInfo attribute), 77, 78
 DATA_ACCESS (pylink.enums.JLinkStraceEvent attribute), 90
 data_branch() (pylink.structs.JLinkTraceData method), 75
 DATA_BREAKPOINT (pylink.enums.JLinkHaltReasons attribute), 86
 data_breakpoint() (pylink.structs.JLinkMOEInfo method), 70
 data_instruction() (pylink.structs.JLinkTraceData method), 76
 DATA_LOAD (pylink.enums.JLinkStraceEvent attribute), 90
 DATA_STORE (pylink.enums.JLinkStraceEvent attribute), 90
 DataMask (pylink.structs.JLinkDataEvent attribute), 66
 DataMask (pylink.structs.JLinkStraceEventInfo attribute), 74, 75
 DataMask (pylink.structs.JLinkWatchpointInfo attribute), 77, 78
 DBG (pylink.enums.JLinkROMTable attribute), 87
 DBGRQ (pylink.enums.JLinkHaltReasons attribute), 86
 dbgrq() (pylink.structs.JLinkMOEInfo method), 70
 DCC (pylink.enums.JLinkCPUCapabilities attribute), 80
 debug_disable (pylink.registers.MDMAPControlRegisterBits attribute), 98, 99
 debug_disable (pylink.registers.MDMAPControlRegisterFlags attribute), 99
 debug_request (pylink.registers.MDMAPControlRegisterBits attribute), 98, 99
 debug_request (pylink.registers.MDMAPControlRegisterFlags attribute), 99
 detailed_log_handler (pylink.jlink.JLink attribute), 21
 device_family() (pylink.jlink.JLink method), 21
 DEVICE_FEATURE_NOT_SUPPORTED (pylink.enums.JLinkGlobalErrors attribute), 85
 DIR (pylink.enums.JLinkAccessMaskFlags attribute), 79
 Direction (pylink.structs.JLinkRTTerminalBufDesc attribute), 71
 disable_dialog_boxes() (pylink.jlink.JLink method), 21
 disable_reset_inits_registers() (pylink.jlink.JLink method), 21

disable_reset_pulls_reset() (pylink.jlink.JLink method), 22
 disable_reset_pulls_trst() (pylink.jlink.JLink method), 22
 disable_soft_breakpoints() (pylink.jlink.JLink method), 22
 disassemble_instruction() (pylink.jlink.JLink method), 22
 DLG_BUTTON_CANCEL (pylink.enums.JLinkFlags attribute), 84
 DLG_BUTTON_NO (pylink.enums.JLinkFlags attribute), 84
 DLG_BUTTON_OK (pylink.enums.JLinkFlags attribute), 84
 DLG_BUTTON_YES (pylink.enums.JLinkFlags attribute), 84
 dll() (pylink.library.Library method), 12
 DLL_NOT_OPEN (pylink.enums.JLinkGlobalErrors attribute), 85
 DOWN (pylink.enums.JLinkRTTDirection attribute), 87
 down (pylink.structs.JLinkRTTerminalBufDesc attribute), 71
 Dummy (pylink.structs.JLinkTraceRegion attribute), 76, 77
 DWT (pylink.enums.JLinkROMTable attribute), 87

E

EFM8 (pylink.enums.JLinkDeviceFamily attribute), 83
 EFM8_UNSPEC (pylink.enums.JLinkCore attribute), 82
 EMU_COMM_ERROR (pylink.enums.JLinkGlobalErrors attribute), 85
 EMU_FEATURE_UNSUPPORTED (pylink.enums.JLinkGlobalErrors attribute), 85
 EMU_NO_CONNECTION (pylink.enums.JLinkGlobalErrors attribute), 85
 EMU_NO_MEMORY (pylink.enums.JLinkGlobalErrors attribute), 85
 enable_dialog_boxes() (pylink.jlink.JLink method), 22
 enable_reset_inits_registers() (pylink.jlink.JLink method), 23
 enable_reset_pulls_reset() (pylink.jlink.JLink method), 23
 enable_reset_pulls_trst() (pylink.jlink.JLink method), 23
 enable_soft_breakpoints() (pylink.jlink.JLink method), 23
 EndianMode (pylink.structs.JLinkDeviceInfo attribute), 67
 erase() (pylink.jlink.JLink method), 23
 erase_licenses() (pylink.jlink.JLink method), 23
 error (pylink.jlink.JLink attribute), 23
 error_handler (pylink.jlink.JLink attribute), 24
 ERROR_INVALID_ACCESS_MASK (pylink.enums.JLinkDataErrors attribute), 83
 ERROR_INVALID_ADDR_MASK (pylink.enums.JLinkDataErrors attribute), 83

- 83
- ERROR_INVALID_DATA_MASK (pylink.enums.JLinkDataErrors attribute), 83
- ERROR_NO_MORE_ADDR_COMP (pylink.enums.JLinkDataErrors attribute), 83
- ERROR_NO_MORE_DATA_COMP (pylink.enums.JLinkDataErrors attribute), 83
- ERROR_NO_MORE_EVENTS (pylink.enums.JLinkDataErrors attribute), 83
- ERROR_UNKNOWN (pylink.enums.JLinkDataErrors attribute), 83
- ETB (pylink.enums.JLinkROMTable attribute), 87
- ETB (pylink.enums.JLinkTraceSource attribute), 91
- ETM (pylink.enums.JLinkROMTable attribute), 87
- ETM (pylink.enums.JLinkTraceSource attribute), 91
- etm_register_read() (pylink.jlink.JLink method), 24
- etm_register_write() (pylink.jlink.JLink method), 24
- etm_supported() (pylink.jlink.JLink method), 24
- exec_command() (pylink.jlink.JLink method), 24
- extended_capabilities (pylink.jlink.JLink attribute), 24
- extended_capability() (pylink.jlink.JLink method), 25
- ## F
- fault() (pylink.protocols.swd.Response method), 59
- fd (pylink.jlock.JLock attribute), 14
- features (pylink.jlink.JLink attribute), 25
- find_library_darwin() (pylink.library.Library class method), 12
- find_library_linux() (pylink.library.Library class method), 12
- find_library_windows() (pylink.library.Library class method), 13
- FINE (pylink.enums.JLinkInterfaces attribute), 86
- firmware_newer() (pylink.jlink.JLink method), 25
- firmware_outdated() (pylink.jlink.JLink method), 25
- firmware_version (pylink.jlink.JLink attribute), 25
- Flags (pylink.structs.JLinkRTTerminalBufDesc attribute), 71
- FLASH (pylink.enums.JLinkBreakpointImplementation attribute), 80
- flash() (pylink.jlink.JLink method), 25
- flash_file() (pylink.jlink.JLink method), 26
- flash_mass_erase (pylink.registers.MDMAPControlRegisterBits attribute), 98, 99
- flash_mass_erase (pylink.registers.MDMAPControlRegisterFlags attribute), 100
- flash_mass_erase_ack (pylink.registers.MDMAPStatusRegisterBits attribute), 100, 101
- flash_mass_erase_ack (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
- FLASH_PROG_COMPARE_FAILED (pylink.enums.JLinkGlobalErrors attribute), 85
- FLASH_PROG_PROGRAM_FAILED (pylink.enums.JLinkGlobalErrors attribute), 85
- FLASH_PROG_VERIFY_FAILED (pylink.enums.JLinkGlobalErrors attribute), 85
- flash_progress_callback() (in module pylink.util), 104
- FLASH_PROGRESS_PROTOTYPE (pylink.enums.JLinkFunctions attribute), 85
- flash_ready (pylink.registers.MDMAPStatusRegisterBits attribute), 100, 101
- flash_ready (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
- flash_write() (pylink.jlink.JLink method), 26
- flash_write16() (pylink.jlink.JLink method), 26
- flash_write32() (pylink.jlink.JLink method), 27
- flash_write8() (pylink.jlink.JLink method), 27
- FlashAddr (pylink.structs.JLinkDeviceInfo attribute), 66, 67
- FlashSize (pylink.structs.JLinkDeviceInfo attribute), 67
- FLUSH (pylink.enums.JLinkSWOCommands attribute), 89
- FLUSH (pylink.enums.JLinkTraceCommand attribute), 90
- FORMAT_16BIT (pylink.enums.JLinkTraceFormat attribute), 90, 91
- FORMAT_1BIT (pylink.enums.JLinkTraceFormat attribute), 91
- FORMAT_2BIT (pylink.enums.JLinkTraceFormat attribute), 91
- FORMAT_4BIT (pylink.enums.JLinkTraceFormat attribute), 90, 91
- FORMAT_8BIT (pylink.enums.JLinkTraceFormat attribute), 90, 91
- FORMAT_DEMULTIPLEXED (pylink.enums.JLinkTraceFormat attribute), 91
- FORMAT_DOUBLE_EDGE (pylink.enums.JLinkTraceFormat attribute), 91
- FORMAT_ETM10 (pylink.enums.JLinkTraceFormat attribute), 91
- FORMAT_ETM7_9 (pylink.enums.JLinkTraceFormat attribute), 91
- FORMAT_MULTIPLEXED (pylink.enums.JLinkTraceFormat attribute), 91
- FPB (pylink.enums.JLinkROMTable attribute), 87
- ## G
- get_appropriate_windows_sdk_name() (pylink.library.Library class method), 13
- GETBIC_CONF_CAPACITY (pylink.enums.JLinkTraceCommand attribute), 90
- get_device_index() (pylink.jlink.JLink method), 27

[GET_FORMAT](#) (pylink.enums.JLinkTraceCommand attribute), 90
[GET_MAX_CAPACITY](#) (pylink.enums.JLinkTraceCommand attribute), 90
[GET_MIN_CAPACITY](#) (pylink.enums.JLinkTraceCommand attribute), 90
[GET_NUM_BYTES](#) (pylink.enums.JLinkSWOCommands attribute), 89
[GET_NUM_REGIONS](#) (pylink.enums.JLinkTraceCommand attribute), 90
[GET_NUM_SAMPLES](#) (pylink.enums.JLinkTraceCommand attribute), 90
[GET_REGION_PROPS](#) (pylink.enums.JLinkTraceCommand attribute), 90
[GET_REGION_PROPS_EX](#) (pylink.enums.JLinkTraceCommand attribute), 90
[GET_SPEED_INFO](#) (pylink.enums.JLinkSWOCommands attribute), 89
[GETDESC](#) (pylink.enums.JLinkRTTCommand attribute), 87
[GETNUMBUF](#) (pylink.enums.JLinkRTTCommand attribute), 87
[GETSTAT](#) (pylink.enums.JLinkRTTCommand attribute), 87
[GO](#) (pylink.enums.JLinkCPUCapabilities attribute), 80
[GO_OVERSTEP_BP](#) (pylink.enums.JLinkFlags attribute), 84
[gpio_get\(\)](#) (pylink.jlink.JLink method), 27
[gpio_properties\(\)](#) (pylink.jlink.JLink method), 27
[gpio_set\(\)](#) (pylink.jlink.JLink method), 28
H
[HALT](#) (pylink.enums.JLinkCPUCapabilities attribute), 80
[halt\(\)](#) (pylink.jlink.JLink method), 28
[HALT_AFTER_BTL](#) (pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89
[HALT_BEFORE_BTL](#) (pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89
[halted\(\)](#) (pylink.jlink.JLink method), 28
[HaltReason](#) (pylink.structs.JLinkMOEInfo attribute), 69
[Handle](#) (pylink.structs.JLinkBreakpointInfo attribute), 63
[Handle](#) (pylink.structs.JLinkWatchpointInfo attribute), 77, 78
[HARD](#) (pylink.enums.JLinkBreakpointImplementation attribute), 79, 80
[HARD_ERROR](#) (pylink.enums.JLinkVectorCatchCortexM3 attribute), 92
[hardware_breakpoint\(\)](#) (pylink.structs.JLinkBreakpointInfo method), 64
[hardware_breakpoint_set\(\)](#) (pylink.jlink.JLink method), 28
[hardware_info](#) (pylink.jlink.JLink attribute), 28
[hardware_status](#) (pylink.jlink.JLink attribute), 29
[hardware_version](#) (pylink.jlink.JLink attribute), 29
[HostOverflowCount](#) (pylink.structs.JLinkRTTerminalStatus attribute), 72
[HSS](#) (pylink.enums.JLinkCPUCapabilities attribute), 80
[HW](#) (pylink.enums.JLinkBreakpoint attribute), 79
[HW_PIN_STATUS_HIGH](#) (pylink.enums.JLinkFlags attribute), 84
[HW_PIN_STATUS_LOW](#) (pylink.enums.JLinkFlags attribute), 84
[HW_PIN_STATUS_UNKNOWN](#) (pylink.enums.JLinkFlags attribute), 84
[HWVersion](#) (pylink.structs.JLinkConnectInfo attribute), 64, 65
I
[ice_register_read\(\)](#) (pylink.jlink.JLink method), 29
[ice_register_write\(\)](#) (pylink.jlink.JLink method), 29
[ICSP](#) (pylink.enums.JLinkInterfaces attribute), 86
[IDCodeRegisterBits](#) (class in pylink.registers), 97
[IDCodeRegisterFlags](#) (class in pylink.registers), 98
[ILLEGAL_COMMAND](#) (pylink.enums.JLinkEraseErrors attribute), 84
[ImpFlags](#) (pylink.structs.JLinkBreakpointInfo attribute), 63
[index](#) (pylink.jlink.JLink attribute), 30
[Index](#) (pylink.structs.JLinkMOEInfo attribute), 69
[instruction\(\)](#) (pylink.structs.JLinkTraceData method), 76
[INT_ERROR](#) (pylink.enums.JLinkVectorCatchCortexM3 attribute), 92
[Interface](#) (pylink.structs.JLinkSWOSpeedInfo attribute), 72, 73
[Interface](#) (pylink.structs.JLinkSWOStartInfo attribute), 73
[interface_required\(\)](#) (pylink.jlink.JLink method), 30
[invalidate\(\)](#) (pylink.protocols.swd.Response method), 59
[INVALID_HANDLE](#) (pylink.enums.JLinkGlobalErrors attribute), 85
[INVALID_JTAG_SPEED](#) (pylink.jlink.JLink attribute), 15
[invalidate_firmware\(\)](#) (pylink.jlink.JLink method), 30
[IP](#) (pylink.enums.JLinkHost attribute), 86
[IPADDR_NAME_FMT](#) (pylink.jlock.JLock attribute), 14
[ir_len\(\)](#) (pylink.jlink.JLink method), 30
[IS_HALTED](#) (pylink.enums.JLinkCPUCapabilities attribute), 80
[is_integer\(\)](#) (in module pylink.util), 104
[is_natural\(\)](#) (in module pylink.util), 104
[is_os_64bit\(\)](#) (in module pylink.util), 104
[IsDHCPAssignedIP](#) (pylink.structs.JLinkConnectInfo attribute), 64, 65

- IsDHCPAssignedIPsValid (pylink.structs.JLinkConnectInfo attribute), 64, 65
- IsRunning (pylink.structs.JLinkRTTerminalStatus attribute), 72
- ITM (pylink.enums.JLinkROMTable attribute), 87
- ## J
- JLink (class in pylink.jlink), 15
- JLINK_SDK_NAME (pylink.library.Library attribute), 12
- JLinkAccessFlags (class in pylink.enums), 78
- JLinkAccessMaskFlags (class in pylink.enums), 78
- JLinkBreakpoint (class in pylink.enums), 79
- JLinkBreakpointImplementation (class in pylink.enums), 79
- JLinkBreakpointInfo (class in pylink.structs), 63
- JLinkConnectInfo (class in pylink.structs), 64
- JLinkCore (class in pylink.enums), 80
- JLinkCPUCapabilities (class in pylink.enums), 80
- JLinkDataErrors (class in pylink.enums), 82
- JLinkDataEvent (class in pylink.structs), 65
- JLinkDataException, 11
- JLinkDeviceFamily (class in pylink.enums), 83
- JLinkDeviceInfo (class in pylink.structs), 66
- JLinkEraseErrors (class in pylink.enums), 84
- JLinkEraseException, 11
- JLinkEventTypes (class in pylink.enums), 84
- JLinkException, 11
- JLinkFlags (class in pylink.enums), 84
- JLinkFlashArea (class in pylink.structs), 68
- JLinkFlashErrors (class in pylink.enums), 84
- JLinkFlashException, 11
- JLinkFunctions (class in pylink.enums), 85
- JLinkGlobalErrors (class in pylink.enums), 85
- JLinkGPIODescriptor (class in pylink.structs), 68
- JLinkHaltReasons (class in pylink.enums), 86
- JLinkHardwareStatus (class in pylink.structs), 68
- JLinkHost (class in pylink.enums), 86
- JLinkInterfaces (class in pylink.enums), 86
- JLinkMemoryZone (class in pylink.structs), 70
- JLinkMOEInfo (class in pylink.structs), 69
- JLinkRAMArea (class in pylink.structs), 70
- JLinkReadErrors (class in pylink.enums), 88
- JLinkReadException, 11
- JLinkResetStrategyCortexM3 (class in pylink.enums), 88
- JLinkROMTable (class in pylink.enums), 86
- JLinkRTTCommand (class in pylink.enums), 87
- JLinkRTTDirection (class in pylink.enums), 87
- JLinkRTTTerminalBufDesc (class in pylink.structs), 71
- JLinkRTTTerminalStart (class in pylink.structs), 71
- JLinkRTTTerminalStatus (class in pylink.structs), 72
- JLinkRTTErrors (class in pylink.enums), 87
- JLinkRTTException, 11
- JLinkSpeedInfo (class in pylink.structs), 74
- JLinkStraceCommand (class in pylink.enums), 89
- JLinkStraceEvent (class in pylink.enums), 90
- JLinkStraceEventInfo (class in pylink.structs), 74
- JLinkStraceOperation (class in pylink.enums), 90
- JLinkSWOCommands (class in pylink.enums), 89
- JLinkSWOInterfaces (class in pylink.enums), 89
- JLinkSWOSpeedInfo (class in pylink.structs), 72
- JLinkSWOStartInfo (class in pylink.structs), 73
- JLinkTraceCommand (class in pylink.enums), 90
- JLinkTraceData (class in pylink.structs), 75
- JLinkTraceFormat (class in pylink.enums), 90
- JLinkTraceRegion (class in pylink.structs), 76
- JLinkTraceSource (class in pylink.enums), 91
- JLinkVectorCatchCortexM3 (class in pylink.enums), 91
- JLinkWatchpointInfo (class in pylink.structs), 77
- JLinkWriteErrors (class in pylink.enums), 92
- JLinkWriteException, 11
- JLock (class in pylink.jlock), 14
- join() (pylink.threads.ThreadReturn method), 103
- JTAG (pylink.enums.JLinkInterfaces attribute), 86
- jtag_configure() (pylink.jlink.JLink method), 30
- jtag_create_clock() (pylink.jlink.JLink method), 30
- jtag_flush() (pylink.jlink.JLink method), 31
- jtag_send() (pylink.jlink.JLink method), 31
- ## K
- KINETIS (pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89
- ## L
- Library (class in pylink.library), 12
- licenses (pylink.jlink.JLink attribute), 31
- LLSMODEEXIT (pylink.registers.MDMAPStatusRegisterBits attribute), 100
- LLSMODEEXIT (pylink.registers.MDMAPStatusRegisterFlags attribute), 101
- load() (pylink.library.Library method), 13
- load_default() (pylink.library.Library method), 13
- log_handler (pylink.jlink.JLink attribute), 31
- LOG_PROTOTYPE (pylink.enums.JLinkFunctions attribute), 85
- low_power_enabled (pylink.registers.MDMAPStatusRegisterBits attribute), 100, 101
- low_power_enabled (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
- LPC1200 (pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89
- ## M
- MANCHESTER (pylink.enums.JLinkSWOInterfaces attribute), 89
- manufacturer (pylink.registers.IDCodeRegisterBits attribute), 97

- manufacturer (pylink.registers.IDCodeRegisterBits attribute), 98
- manufacturer (pylink.registers.IDCodeRegisterFlags attribute), 98
- manufacturer (pylink.structs.JLinkDeviceInfo attribute), 67
- MASKLANE (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
- MASKLANE (pylink.registers.ControlStatusRegisterFlags attribute), 97
- mass_erase_enabled (pylink.registers.MDMAPStatusRegisterBits attribute), 100, 101
- mass_erase_enabled (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
- MAX_BUF_SIZE (pylink.jlink.JLink attribute), 15
- MAX_JTAG_SPEED (pylink.jlink.JLink attribute), 15
- MAX_NUM_CPU_REGISTERS (pylink.jlink.JLink attribute), 15
- MAX_NUM_MOES (pylink.jlink.JLink attribute), 15
- MaxDiv (pylink.structs.JLinkSWOSpeedInfo attribute), 73
- MaxPrescale (pylink.structs.JLinkSWOSpeedInfo attribute), 73
- MDMAPControlRegisterBits (class in pylink.registers), 98
- MDMAPControlRegisterFlags (class in pylink.registers), 99
- MDMAPStatusRegisterBits (class in pylink.registers), 100
- MDMAPStatusRegisterFlags (class in pylink.registers), 101
- MEM_ERROR (pylink.enums.JLinkVectorCatchCortexM3 attribute), 91, 92
- memory_read() (pylink.jlink.JLink method), 31
- memory_read16() (pylink.jlink.JLink method), 32
- memory_read32() (pylink.jlink.JLink method), 32
- memory_read64() (pylink.jlink.JLink method), 32
- memory_read8() (pylink.jlink.JLink method), 32
- memory_write() (pylink.jlink.JLink method), 33
- memory_write16() (pylink.jlink.JLink method), 33
- memory_write32() (pylink.jlink.JLink method), 33
- memory_write64() (pylink.jlink.JLink method), 34
- memory_write8() (pylink.jlink.JLink method), 34
- memory_zones() (pylink.jlink.JLink method), 34
- MIN_JTAG_SPEED (pylink.jlink.JLink attribute), 15
- MinDiv (pylink.structs.JLinkSpeedInfo attribute), 74
- MinDiv (pylink.structs.JLinkSWOSpeedInfo attribute), 73
- minimum_required() (pylink.jlink.JLink method), 34
- MinPrescale (pylink.structs.JLinkSWOSpeedInfo attribute), 73
- MIPS (pylink.enums.JLinkCore attribute), 82
- MIPS (pylink.enums.JLinkDeviceFamily attribute), 83
- MIPS_M4K (pylink.enums.JLinkCore attribute), 82
- MIPS_MICROAPTIV (pylink.enums.JLinkCore attribute), 82
- MTB (pylink.enums.JLinkROMTable attribute), 87
- MTB (pylink.enums.JLinkTraceSource attribute), 91
- ## N
- name (pylink.jlock.JLock attribute), 14
- name (pylink.structs.JLinkDeviceInfo attribute), 67
- name (pylink.structs.JLinkMemoryZone attribute), 70
- name (pylink.structs.JLinkRTTerminalBufDesc attribute), 71
- NO_CPU_FOUND (pylink.enums.JLinkGlobalErrors attribute), 85
- NO_TARGET_DEVICE_SELECTED (pylink.enums.JLinkGlobalErrors attribute), 85
- non_instruction() (pylink.structs.JLinkTraceData method), 76
- NONE (pylink.enums.JLinkCore attribute), 82
- NONE (pylink.enums.JLinkROMTable attribute), 87
- noop() (in module pylink.util), 104
- NORMAL (pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89
- num_active_breakpoints() (pylink.jlink.JLink method), 34
- num_active_watchpoints() (pylink.jlink.JLink method), 34
- num_available_breakpoints() (pylink.jlink.JLink method), 35
- num_available_watchpoints() (pylink.jlink.JLink method), 35
- num_connected_emulators() (pylink.jlink.JLink method), 35
- num_memory_zones() (pylink.jlink.JLink method), 35
- num_supported_devices() (pylink.jlink.JLink method), 35
- NumBytesRead (pylink.structs.JLinkRTTerminalStatus attribute), 72
- NumBytesTransferred (pylink.structs.JLinkRTTerminalStatus attribute), 72
- NumDownBuffers (pylink.structs.JLinkRTTerminalStatus attribute), 72
- NumIPConnections (pylink.structs.JLinkConnectInfo attribute), 65
- NumIPConnectionsIsValid (pylink.structs.JLinkConnectInfo attribute), 65
- NumSamples (pylink.structs.JLinkTraceRegion attribute), 76, 77
- NumUpBuffers (pylink.structs.JLinkRTTerminalStatus attribute), 72
- NVIC (pylink.enums.JLinkROMTable attribute), 87
- ## O
- oem (pylink.jlink.JLink attribute), 35
- Off (pylink.structs.JLinkTraceRegion attribute), 76, 77

- Op (pylink.structs.JLinkStraceEventInfo attribute), 74, 75
- open() (pylink.jlink.JLink method), 36
- OPEN_FILE_FAILED (pylink.enums.JLinkGlobalErrors attribute), 85
- open_required() (pylink.jlink.JLink method), 36
- open_tunnel() (pylink.jlink.JLink method), 36
- opened() (pylink.jlink.JLink method), 36
- ORUNDETECT (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
- ORUNDETECT (pylink.registers.ControlStatusRegisterFlags attribute), 97
- ORUNERRCLR (pylink.registers.AbortRegisterBits attribute), 94
- ORUNERRCLR (pylink.registers.AbortRegisterFlags attribute), 94
- ## P
- pack() (in module pylink.binpacker), 93
- pack_size() (in module pylink.binpacker), 93
- Packet (pylink.structs.JLinkTraceData attribute), 75
- parity (pylink.protocols.swd.Request attribute), 58
- parity (pylink.protocols.swd.RequestBits attribute), 59
- park (pylink.protocols.swd.Request attribute), 58
- park (pylink.protocols.swd.RequestBits attribute), 59
- part_no (pylink.registers.IDCodeRegisterBits attribute), 98
- part_no (pylink.registers.IDCodeRegisterFlags attribute), 98
- path (pylink.jlock.JLock attribute), 14
- PENDING (pylink.enums.JLinkBreakpointImplementation attribute), 79, 80
- pending() (pylink.structs.JLinkBreakpointInfo method), 64
- PipeStat (pylink.structs.JLinkTraceData attribute), 75
- power_off() (pylink.jlink.JLink method), 36
- power_on() (pylink.jlink.JLink method), 37
- POWER_PC (pylink.enums.JLinkCore attribute), 82
- POWER_PC_N1 (pylink.enums.JLinkCore attribute), 82
- POWER_PC_N2 (pylink.enums.JLinkCore attribute), 82
- POWERPC (pylink.enums.JLinkDeviceFamily attribute), 84
- PRIV (pylink.enums.JLinkAccessFlags attribute), 78
- PRIV (pylink.enums.JLinkAccessMaskFlags attribute), 79
- PRIVILEGED (pylink.enums.JLinkAccessFlags attribute), 78
- product_name (pylink.jlink.JLink attribute), 37
- PROGRAM_ERASE_ERROR (pylink.enums.JLinkFlashErrors attribute), 84
- progress_bar() (in module pylink.util), 105
- PTM (pylink.enums.JLinkROMTable attribute), 87
- pylink.binpacker (module), 93
- pylink.decorators (module), 93
- pylink.enums (module), 78
- pylink.errors (module), 11
- pylink.jlink (module), 15
- pylink.jlock (module), 14
- pylink.library (module), 12
- pylink.protocols.swd (module), 57
- pylink.registers (module), 94
- pylink.structs (module), 63
- pylink.threads (module), 103
- pylink.unlockers (module), 61
- pylink.unlockers.unlock_kinetis (module), 61
- pylink.util (module), 104
- ## R
- RAMAddr (pylink.structs.JLinkDeviceInfo attribute), 67
- RAMSize (pylink.structs.JLinkDeviceInfo attribute), 67
- READ (pylink.enums.JLinkAccessFlags attribute), 78
- READ_MEMORY (pylink.enums.JLinkCPUCapabilities attribute), 80
- READ_REGISTERS (pylink.enums.JLinkCPUCapabilities attribute), 80
- read_write (pylink.protocols.swd.Request attribute), 58
- read_write (pylink.protocols.swd.RequestBits attribute), 59
- READOK (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
- READOK (pylink.registers.ControlStatusRegisterFlags attribute), 97
- ReadRequest (class in pylink.protocols.swd), 57
- RegionCnt (pylink.structs.JLinkTraceRegion attribute), 76, 77
- RegionIndex (pylink.structs.JLinkTraceRegion attribute), 76, 77
- register_list() (pylink.jlink.JLink method), 37
- register_name() (pylink.jlink.JLink method), 37
- register_read() (pylink.jlink.JLink method), 37
- register_read_multiple() (pylink.jlink.JLink method), 37
- register_write() (pylink.jlink.JLink method), 37
- register_write_multiple() (pylink.jlink.JLink method), 38
- release() (pylink.jlock.JLock method), 14
- Request (class in pylink.protocols.swd), 57
- RequestBits (class in pylink.protocols.swd), 59
- RESERVED (pylink.registers.AbortRegisterBits attribute), 94
- RESERVED (pylink.registers.AbortRegisterFlags attribute), 95
- RESERVED (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
- RESERVED (pylink.registers.ControlStatusRegisterFlags attribute), 97
- Reserved (pylink.structs.JLinkRTTerminalStart attribute), 72
- Reserved (pylink.structs.JLinkRTTerminalStatus attribute), 72

- Reserved0 (pylink.structs.JLinkStraceEventInfo attribute), 74, 75
 - RESERVED_A (pylink.registers.MDMAPStatusRegisterBits attribute), 100
 - RESERVED_A (pylink.registers.MDMAPStatusRegisterFlags attribute), 101
 - RESERVED_A (pylink.registers.SelectRegisterBits attribute), 102, 103
 - RESERVED_A (pylink.registers.SelectRegisterFlags attribute), 103
 - RESERVED_B (pylink.registers.MDMAPStatusRegisterBits attribute), 100
 - RESERVED_B (pylink.registers.MDMAPStatusRegisterFlags attribute), 101
 - RESERVED_B (pylink.registers.SelectRegisterBits attribute), 102, 103
 - RESERVED_B (pylink.registers.SelectRegisterFlags attribute), 103
 - RESERVED_C (pylink.registers.MDMAPStatusRegisterBits attribute), 101
 - RESERVED_C (pylink.registers.MDMAPStatusRegisterFlags attribute), 101
 - RESET (pylink.enums.JLinkCPUCapabilities attribute), 80
 - reset() (pylink.jlink.JLink method), 38
 - reset_tap() (pylink.jlink.JLink method), 38
 - RESETPIN (pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89
 - Response (class in pylink.protocols.swd), 59
 - restart() (pylink.jlink.JLink method), 39
 - rtt_control() (pylink.jlink.JLink method), 39
 - RTT_ERROR_CONTROL_BLOCK_NOT_FOUND (pylink.enums.JLinkRTTErrors attribute), 87
 - rtt_get_buf_descriptor() (pylink.jlink.JLink method), 39
 - rtt_get_num_down_buffers() (pylink.jlink.JLink method), 39
 - rtt_get_num_up_buffers() (pylink.jlink.JLink method), 39
 - rtt_get_status() (pylink.jlink.JLink method), 40
 - rtt_read() (pylink.jlink.JLink method), 40
 - rtt_start() (pylink.jlink.JLink method), 40
 - rtt_stop() (pylink.jlink.JLink method), 40
 - rtt_write() (pylink.jlink.JLink method), 40
 - run() (pylink.threads.ThreadReturn method), 103
 - RUN_STOP (pylink.enums.JLinkCPUCapabilities attribute), 80
 - RX (pylink.enums.JLinkCore attribute), 82
 - RX (pylink.enums.JLinkDeviceFamily attribute), 84
 - RX110 (pylink.enums.JLinkCore attribute), 82
 - RX111 (pylink.enums.JLinkCore attribute), 82
 - RX113 (pylink.enums.JLinkCore attribute), 82
 - RX210 (pylink.enums.JLinkCore attribute), 82
 - RX21A (pylink.enums.JLinkCore attribute), 82
 - RX220 (pylink.enums.JLinkCore attribute), 82
 - RX230 (pylink.enums.JLinkCore attribute), 82
 - RX231 (pylink.enums.JLinkCore attribute), 82
 - RX23T (pylink.enums.JLinkCore attribute), 82
 - RX610 (pylink.enums.JLinkCore attribute), 82
 - RX621 (pylink.enums.JLinkCore attribute), 82
 - RX62G (pylink.enums.JLinkCore attribute), 82
 - RX62N (pylink.enums.JLinkCore attribute), 82
 - RX62T (pylink.enums.JLinkCore attribute), 82
 - RX630 (pylink.enums.JLinkCore attribute), 82
 - RX631 (pylink.enums.JLinkCore attribute), 82
 - RX63N (pylink.enums.JLinkCore attribute), 82
 - RX63T (pylink.enums.JLinkCore attribute), 82
 - RX64M (pylink.enums.JLinkCore attribute), 82
 - RX71M (pylink.enums.JLinkCore attribute), 82
- ## S
- S3FN60D (pylink.enums.JLinkResetStrategyCortexM3 attribute), 88, 89
 - scan_chain_len() (pylink.jlink.JLink method), 41
 - scan_len() (pylink.jlink.JLink method), 41
 - Desc (pylink.structs.JLinkMemoryZone attribute), 70
 - SECURE (pylink.enums.JLinkROMTable attribute), 87
 - SelectRegisterBits (class in pylink.registers), 102
 - SelectRegisterFlags (class in pylink.registers), 103
 - send() (pylink.protocols.swd.ReadRequest method), 57
 - send() (pylink.protocols.swd.Request method), 58
 - send() (pylink.protocols.swd.WriteRequest method), 60
 - SERIAL_NAME_FMT (pylink.jlock.JLock attribute), 14
 - serial_number (pylink.jlink.JLink attribute), 41
 - SerialNumber (pylink.structs.JLinkConnectInfo attribute), 64, 65
 - set_big_endian() (pylink.jlink.JLink method), 41
 - SET_BUFFER_SIZE (pylink.enums.JLinkStraceCommand attribute), 89
 - SET_BUFFER_SIZE_EMU (pylink.enums.JLinkSWOCommands attribute), 89
 - SET_BUFFER_SIZE_HOST (pylink.enums.JLinkSWOCommands attribute), 89
 - SET_CAPACITY (pylink.enums.JLinkTraceCommand attribute), 90
 - set_etb_trace() (pylink.jlink.JLink method), 41
 - set_etm_trace() (pylink.jlink.JLink method), 41
 - SET_FORMAT (pylink.enums.JLinkTraceCommand attribute), 90
 - set_little_endian() (pylink.jlink.JLink method), 41
 - set_log_file() (pylink.jlink.JLink method), 41
 - set_max_speed() (pylink.jlink.JLink method), 41
 - set_reset_pin_high() (pylink.jlink.JLink method), 42
 - set_reset_pin_low() (pylink.jlink.JLink method), 42
 - set_reset_strategy() (pylink.jlink.JLink method), 42
 - set_speed() (pylink.jlink.JLink method), 42
 - set_tck_pin_high() (pylink.jlink.JLink method), 42

- set_tck_pin_low() (pylink.jlink.JLink method), 42
 set_tdi_pin_high() (pylink.jlink.JLink method), 43
 set_tdi_pin_low() (pylink.jlink.JLink method), 43
 set_tif() (pylink.jlink.JLink method), 43
 set_tms_pin_high() (pylink.jlink.JLink method), 43
 set_tms_pin_low() (pylink.jlink.JLink method), 43
 set_trace_source() (pylink.jlink.JLink method), 43
 set_trst_pin_high() (pylink.jlink.JLink method), 43
 set_trst_pin_low() (pylink.jlink.JLink method), 44
 set_vector_catch() (pylink.jlink.JLink method), 44
 SIM (pylink.enums.JLinkCore attribute), 82
 SIMULATOR (pylink.enums.JLinkDeviceFamily attribute), 84
 SIZE (pylink.enums.JLinkAccessMaskFlags attribute), 78, 79
 Size (pylink.structs.JLinkFlashArea attribute), 68
 Size (pylink.structs.JLinkRAMArea attribute), 70
 SIZE_16BIT (pylink.enums.JLinkAccessFlags attribute), 78
 SIZE_32BIT (pylink.enums.JLinkAccessFlags attribute), 78
 SIZE_8BIT (pylink.enums.JLinkAccessFlags attribute), 78
 SizeOfBuffer (pylink.structs.JLinkRTTerminalBufDesc attribute), 71
 SizeOfStruct (pylink.structs.JLinkBreakpointInfo attribute), 63
 SizeOfStruct (pylink.structs.JLinkDataEvent attribute), 66
 SizeOfStruct (pylink.structs.JLinkDeviceInfo attribute), 66
 SizeofStruct (pylink.structs.JLinkDeviceInfo attribute), 67
 SizeOfStruct (pylink.structs.JLinkSpeedInfo attribute), 74
 SizeOfStruct (pylink.structs.JLinkStraceEventInfo attribute), 74, 75
 SizeofStruct (pylink.structs.JLinkSWOSpeedInfo attribute), 72, 73
 SizeofStruct (pylink.structs.JLinkSWOStartInfo attribute), 73
 SizeOfStruct (pylink.structs.JLinkTraceRegion attribute), 76, 77
 SizeOfStruct (pylink.structs.JLinkWatchpointInfo attribute), 77, 78
 sManu (pylink.structs.JLinkDeviceInfo attribute), 67, 68
 sName (pylink.structs.JLinkDeviceInfo attribute), 66, 68
 sName (pylink.structs.JLinkMemoryZone attribute), 70
 SOFT (pylink.enums.JLinkBreakpointImplementation attribute), 79, 80
 software_breakpoint() (pylink.structs.JLinkBreakpointInfo method), 64
 software_breakpoint_set() (pylink.jlink.JLink method), 44
 speed (pylink.jlink.JLink attribute), 44
 Speed (pylink.structs.JLinkSWOStartInfo attribute), 73
 speed_info (pylink.jlink.JLink attribute), 44
 SPI (pylink.enums.JLinkInterfaces attribute), 86
 START (pylink.enums.JLinkRTTCommand attribute), 87
 START (pylink.enums.JLinkSWOCommands attribute), 89
 START (pylink.enums.JLinkTraceCommand attribute), 90
 start (pylink.protocols.swd.Request attribute), 58
 start (pylink.protocols.swd.RequestBits attribute), 59
 STATE_ERROR (pylink.enums.JLinkVectorCatchCortexM3 attribute), 92
 STATUS_ACK (pylink.protocols.swd.Response attribute), 59
 STATUS_FAULT (pylink.protocols.swd.Response attribute), 59
 STATUS_INVALID (pylink.protocols.swd.Response attribute), 59
 STATUS_WAIT (pylink.protocols.swd.Response attribute), 59
 STEP (pylink.enums.JLinkCPUCapabilities attribute), 80
 step() (pylink.jlink.JLink method), 45
 STICKYCMP (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
 STICKYCMP (pylink.registers.ControlStatusRegisterFlags attribute), 97
 STICKYERR (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
 STICKYERR (pylink.registers.ControlStatusRegisterFlags attribute), 97
 STICKYORUN (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
 STICKYORUN (pylink.registers.ControlStatusRegisterFlags attribute), 97
 STKCMPLR (pylink.registers.AbortRegisterBits attribute), 94
 STKCMPLR (pylink.registers.AbortRegisterFlags attribute), 95
 STKERRCLR (pylink.registers.AbortRegisterBits attribute), 94
 STKERRCLR (pylink.registers.AbortRegisterFlags attribute), 95
 STOP (pylink.enums.JLinkRTTCommand attribute), 87
 STOP (pylink.enums.JLinkSWOCommands attribute), 89
 STOP (pylink.enums.JLinkTraceCommand attribute), 90
 stop (pylink.protocols.swd.Request attribute), 58
 stop (pylink.protocols.swd.RequestBits attribute), 59
 strace_clear() (pylink.jlink.JLink method), 45
 strace_clear_all() (pylink.jlink.JLink method), 45
 strace_code_fetch_event() (pylink.jlink.JLink method), 45
 strace_configure() (pylink.jlink.JLink method), 45
 strace_data_access_event() (pylink.jlink.JLink method),

- 46
- strace_data_load_event() (pylink.jlink.JLink method), 46
- strace_data_store_event() (pylink.jlink.JLink method), 46
- strace_read() (pylink.jlink.JLink method), 47
- strace_set_buffer_size() (pylink.jlink.JLink method), 47
- strace_start() (pylink.jlink.JLink method), 47
- strace_stop() (pylink.jlink.JLink method), 47
- SupportAdaptive (pylink.structs.JLinkSpeedInfo attribute), 74
- supported_device() (pylink.jlink.JLink method), 47
- supported_tifs() (pylink.jlink.JLink method), 47
- SW (pylink.enums.JLinkBreakpoint attribute), 79
- SW_FLASH (pylink.enums.JLinkBreakpoint attribute), 79
- SW_RAM (pylink.enums.JLinkBreakpoint attribute), 79
- SWD (pylink.enums.JLinkInterfaces attribute), 86
- swd_read16() (pylink.jlink.JLink method), 48
- swd_read32() (pylink.jlink.JLink method), 48
- swd_read8() (pylink.jlink.JLink method), 48
- swd_sync() (pylink.jlink.JLink method), 48
- swd_write() (pylink.jlink.JLink method), 48
- swd_write16() (pylink.jlink.JLink method), 48
- swd_write32() (pylink.jlink.JLink method), 49
- swd_write8() (pylink.jlink.JLink method), 49
- swo_disable() (pylink.jlink.JLink method), 49
- swo_enable() (pylink.jlink.JLink method), 49
- swo_enabled() (pylink.jlink.JLink method), 50
- swo_flush() (pylink.jlink.JLink method), 50
- swo_num_bytes() (pylink.jlink.JLink method), 50
- swo_read() (pylink.jlink.JLink method), 50
- swo_read_stimulus() (pylink.jlink.JLink method), 50
- swo_set_emu_buffer_size() (pylink.jlink.JLink method), 51
- swo_set_host_buffer_size() (pylink.jlink.JLink method), 51
- swo_speed_info() (pylink.jlink.JLink method), 51
- swo_start() (pylink.jlink.JLink method), 51
- swo_stop() (pylink.jlink.JLink method), 51
- swo_supported_speeds() (pylink.jlink.JLink method), 52
- Sync (pylink.structs.JLinkTraceData attribute), 75
- sync_firmware() (pylink.jlink.JLink method), 52
- sys_reset_request (pylink.registers.MDMAPControlRegisterBits attribute), 98, 99
- sys_reset_request (pylink.registers.MDMAPControlRegisterFlags attribute), 100
- system_reset (pylink.registers.MDMAPStatusRegisterBits attribute), 100, 101
- system_reset (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
- system_security (pylink.registers.MDMAPStatusRegisterBits attribute), 100, 101
- system_security (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
- T
- target_connected() (pylink.jlink.JLink method), 52
- tck (pylink.structs.JLinkHardwareStatus attribute), 68, 69
- tdi (pylink.structs.JLinkHardwareStatus attribute), 68, 69
- tdo (pylink.structs.JLinkHardwareStatus attribute), 68, 69
- TERMINAL (pylink.enums.JLinkCPUCapabilities attribute), 80
- test() (pylink.jlink.JLink method), 52
- TF (pylink.enums.JLinkROMTable attribute), 87
- ThreadReturn (class in pylink.threads), 103
- THUMB (pylink.enums.JLinkBreakpoint attribute), 79
- tif (pylink.jlink.JLink attribute), 52
- TIF_STATUS_ERROR (pylink.enums.JLinkGlobalErrors attribute), 85
- Time (pylink.structs.JLinkConnectInfo attribute), 64, 65
- Time_us (pylink.structs.JLinkConnectInfo attribute), 64, 65
- Timestamp (pylink.structs.JLinkTraceRegion attribute), 76, 77
- TMC (pylink.enums.JLinkROMTable attribute), 87
- tms (pylink.structs.JLinkHardwareStatus attribute), 68, 69
- to_string() (pylink.enums.JLinkDataErrors class method), 83
- to_string() (pylink.enums.JLinkEraseErrors class method), 84
- to_string() (pylink.enums.JLinkFlashErrors class method), 85
- to_string() (pylink.enums.JLinkGlobalErrors class method), 86
- to_string() (pylink.enums.JLinkReadErrors class method), 88
- to_string() (pylink.enums.JLinkRTTErrors class method), 87
- to_string() (pylink.enums.JLinkWriteErrors class method), 92
- TPIU (pylink.enums.JLinkROMTable attribute), 87
- trace_buffer_capacity() (pylink.jlink.JLink method), 52
- trace_disabled() (pylink.structs.JLinkTraceData method), 76
- TRACE_EVENT_CLR (pylink.enums.JLinkStraceCommand attribute), 89
- TRACE_EVENT_CLR_ALL (pylink.enums.JLinkStraceCommand attribute), 89
- TRACE_EVENT_SET (pylink.enums.JLinkStraceCommand attribute), 89
- TRACE_EXCLUDE_RANGE (pylink.enums.JLinkStraceOperation attribute), 90
- trace_flush() (pylink.jlink.JLink method), 52
- trace_format() (pylink.jlink.JLink method), 52
- TRACE_INCLUDE_RANGE (pylink.enums.JLinkStraceOperation attribute),

- 90
- trace_max_buffer_capacity() (pylink.jlink.JLink method), 53
- trace_min_buffer_capacity() (pylink.jlink.JLink method), 53
- trace_read() (pylink.jlink.JLink method), 53
- trace_region() (pylink.jlink.JLink method), 53
- trace_region_count() (pylink.jlink.JLink method), 53
- trace_sample_count() (pylink.jlink.JLink method), 53
- trace_set_buffer_capacity() (pylink.jlink.JLink method), 53
- trace_set_format() (pylink.jlink.JLink method), 54
- TRACE_START (pylink.enums.JLinkStraceOperation attribute), 90
- trace_start() (pylink.jlink.JLink method), 54
- TRACE_STOP (pylink.enums.JLinkStraceOperation attribute), 90
- trace_stop() (pylink.jlink.JLink method), 54
- tres (pylink.structs.JLinkHardwareStatus attribute), 69
- trigger() (pylink.structs.JLinkTraceData method), 76
- TRNCNT (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
- TRNCNT (pylink.registers.ControlStatusRegisterFlags attribute), 97
- TRNMODE (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
- TRNMODE (pylink.registers.ControlStatusRegisterFlags attribute), 97
- trst (pylink.structs.JLinkHardwareStatus attribute), 69
- Type (pylink.structs.JLinkBreakpointInfo attribute), 63
- Type (pylink.structs.JLinkDataEvent attribute), 66
- Type (pylink.structs.JLinkStraceEventInfo attribute), 74, 75
- ## U
- UART (pylink.enums.JLinkSWOInterfaces attribute), 89
- UNKNOWN_FILE_FORMAT (pylink.enums.JLinkGlobalErrors attribute), 85
- unload() (pylink.library.Library method), 13
- unlock() (in module pylink.unlockers), 61
- unlock() (pylink.jlink.JLink method), 54
- unlock_kinetis() (in module pylink.unlockers.unlock_kinetis), 61
- unsecure_hook_dialog() (in module pylink.util), 105
- UNSECURE_HOOK_PROTOTYPE (pylink.enums.JLinkFunctions attribute), 85
- UNSPECIFIED_ERROR (pylink.enums.JLinkGlobalErrors attribute), 85
- UP (pylink.enums.JLinkRTTDirection attribute), 87
- up (pylink.structs.JLinkRTTTerminalBufDesc attribute), 71
- update_firmware() (pylink.jlink.JLink method), 54
- USB (pylink.enums.JLinkHost attribute), 86
- USB_OR_IP (pylink.enums.JLinkHost attribute), 86
- USBAddr (pylink.structs.JLinkConnectInfo attribute), 64, 65
- UseCnt (pylink.structs.JLinkBreakpointInfo attribute), 63
- ## V
- valid (pylink.registers.IDCodeRegisterBits attribute), 97, 98
- valid (pylink.registers.IDCodeRegisterFlags attribute), 98
- value (pylink.protocols.swd.Request attribute), 58
- value (pylink.registers.AbortRegisterFlags attribute), 94, 95
- value (pylink.registers.ControlStatusRegisterFlags attribute), 96, 97
- value (pylink.registers.IDCodeRegisterFlags attribute), 98
- value (pylink.registers.MDMAPControlRegisterFlags attribute), 99, 100
- value (pylink.registers.MDMAPStatusRegisterFlags attribute), 101, 102
- value (pylink.registers.SelectRegisterFlags attribute), 103
- VCC_FAILURE (pylink.enums.JLinkGlobalErrors attribute), 85
- VECTOR_CATCH (pylink.enums.JLinkHaltReasons attribute), 86
- vector_catch() (pylink.structs.JLinkMOEInfo method), 70
- VERIFICATION_ERROR (pylink.enums.JLinkFlashErrors attribute), 84
- version (pylink.jlink.JLink attribute), 54
- version_code (pylink.registers.IDCodeRegisterBits attribute), 98
- version_code (pylink.registers.IDCodeRegisterFlags attribute), 98
- very_low_power_mode (pylink.registers.MDMAPStatusRegisterBits attribute), 100, 101
- very_low_power_mode (pylink.registers.MDMAPStatusRegisterFlags attribute), 102
- VirtAddr (pylink.structs.JLinkMemoryZone attribute), 70
- VLLDBGACK (pylink.registers.MDMAPControlRegisterBits attribute), 99
- VLLDBGACK (pylink.registers.MDMAPControlRegisterFlags attribute), 99
- VLLDBGREQ (pylink.registers.MDMAPControlRegisterBits attribute), 99
- VLLDBGREQ (pylink.registers.MDMAPControlRegisterFlags attribute), 99
- VLLSTACK (pylink.registers.MDMAPControlRegisterBits attribute), 99
- VLLSTACK (pylink.registers.MDMAPControlRegisterFlags attribute), 99
- VLLSxMODEEXIT (pylink.registers.MDMAPStatusRegisterBits attribute), 100, 101

VLLSxMODEEXIT (pylink.registers.MDMAPStatusRegisterFlags attribute), 101
voltage (pylink.structs.JLinkHardwareStatus attribute), 69
VTarget (pylink.structs.JLinkHardwareStatus attribute), 68, 69

W

wait() (pylink.protocols.swd.Response method), 59
wait() (pylink.structs.JLinkTraceData method), 76
warning_handler (pylink.jlink.JLink attribute), 54
watchpoint_clear() (pylink.jlink.JLink method), 55
watchpoint_clear_all() (pylink.jlink.JLink method), 55
watchpoint_info() (pylink.jlink.JLink method), 55
watchpoint_set() (pylink.jlink.JLink method), 55
WDATAERR (pylink.registers.ControlStatusRegisterBits attribute), 95, 96
WDATAERR (pylink.registers.ControlStatusRegisterFlags attribute), 97
WDERRCLR (pylink.registers.AbortRegisterBits attribute), 94
WDERRCLR (pylink.registers.AbortRegisterFlags attribute), 95
WINDOWS_32_JLINK_SDK_NAME (pylink.library.Library attribute), 12
WINDOWS_64_JLINK_SDK_NAME (pylink.library.Library attribute), 12
WINDOWS_JLINK_SDK_NAME (pylink.library.Library attribute), 12
WPUnt (pylink.structs.JLinkWatchpointInfo attribute), 77, 78
WRITE (pylink.enums.JLinkAccessFlags attribute), 78
WRITE_MEMORY (pylink.enums.JLinkCPUCapabilities attribute), 80
WRITE_REGISTERS (pylink.enums.JLinkCPUCapabilities attribute), 80
WRITE_TARGET_MEMORY_FAILED (pylink.enums.JLinkGlobalErrors attribute), 85
WriteRequest (class in pylink.protocols.swd), 60
WRONG_USER_CONFIG (pylink.enums.JLinkGlobalErrors attribute), 86

X

XSCALE (pylink.enums.JLinkCore attribute), 82
XSCALE (pylink.enums.JLinkDeviceFamily attribute), 84

Z

ZONE_NOT_FOUND_ERROR (pylink.enums.JLinkReadErrors attribute), 88
ZONE_NOT_FOUND_ERROR (pylink.enums.JLinkWriteErrors attribute), 92